

STRUTS & SHOCK ABSORBERS

Riding Comfort redefined



- ✓ Smooth & Comfortable drive.
- ✓ Safety & Stability of your car.
- ✓ Noise free performance.

Valeo



Type

Position



STRUTS

PASSENGER CAR

FORD	Figgo	Damper (Gas)	Front Right	412124
	Figgo	Damper (Gas)	Front Left	412125
	Figgo	Damper (Gas)	Rear Uni	412126
	Ikon Diesel	Damper	Front Left	412028
	Ikon Diesel	Damper	Front Right	412029
HONDA	Ikon Diesel	Damper	Rear	412030
	City Mark 3	Damper	Front Left	412011
	City Mark 3	Damper	Front Right	412012
	City Mark 1 & 2	Damper	Rear Left	412013
	City Mark 1 & 2	Damper	Rear Right	412014
	City Mark 1 & 2	Damper	Front Left	412015
HYUNDAI	City Mark 1 & 2	Damper	Front Right	412016
	Santero	Damper with Bush Kit	Front Left	412017
	Santero	Damper Without Bush Kit	Front Left	412149
	Santero	Damper with Bush Kit	Front Right	412018
	Santero	Damper Without Bush Kit	Front Right	412148
	Santero	Damper with Bush Kit	Front Universal	412019
	Santero	Damper Without Bush Kit	Front Universal	412150
	Accent CRDI	Damper (Gas) Without Bush Kit	Front Left	412020
	Accent CRDI	Damper (Gas) Without Bush Kit	Front Right	412021
	Accent CRDI	Damper (Gas) Without Bush Kit	Rear Left	412022
	Accent CRDI	Damper (Gas) Without Bush Kit	Rear Right	412023
	Accent Petrol	Damper (Gas) Without Bush Kit	Front Left	412024
	Accent Petrol	Damper (Gas) Without Bush Kit	Front Right	412025
	Accent Petrol	Damper (Gas) Without Bush Kit	Rear Left	412026
	Accent Petrol	Damper (Gas) Without Bush Kit	Rear Right	412027
MAHINDRA	Logan	Damper	Front	412158
	Maxximo (N/M)	Strut	Front Left	412151
	Maxximo (N/M)	Strut	Front Right	412152
	Maxximo	Strut	Front Right	412174
	Maxximo	Strut	Front Left	412175
	Maxximo	Damper	Front	412173
MARUTI	Esteem	Strut	Front Left	412034
	Esteem	Damper	Front Left	412036
	Esteem	Strut	Front Right	412035
	Esteem	Damper	Front Right	412037
	Esteem	Damper	Rear Universal	412038
	Alto	Strut	Front Universal	412039
	Alto	Damper with Bush Kit	Front Universal	412040
	Alto	Damper Without Bush Kit	Front Universal	412133
	Alto 800	Strut	Front Right	412165
	Alto 800	Strut	Front Left	412166
	800	Strut	Front Universal	412041
	800	Damper with Bush Kit	Front Universal	412042
	800	Damper Without Bush Kit	Front Universal	412127
	Omni	Strut	Front Left	412043
	Omni	Strut	Front Right	412044
	Omni	Damper with Bush Kit	Front Universal	412052
	Omni	Damper Without Bush Kit	Front Universal	412129
	Omni Type II	Strut	Front Left	412045
	Omni Type II	Damper with Bush Kit	Front Left	412047
	Omni Type II	Damper Without Bush Kit	Front Left	412130
	Omni Type II	Strut	Front Right	412046
	Omni Type II	Damper with Bush Kit	Front Right	412048
	Omni Type II	Damper Without Bush Kit	Front Right	412131
	Omni Type III	Strut	Front Left	412049
	Omni Type III	Strut	Front Right	412050
	Omni Type III	Damper with Bush Kit	Front Universal	412051
	Omni Type III	Damper Without Bush Kit	Front Universal	412132
Swift	Damper with Bush Kit	Front Left	412088	
Swift	Damper Without Bush Kit	Front Left	412135	
Swift	Damper with Bush Kit	Front Right	412089	
Swift	Damper Without Bush Kit	Front Right	412136	
Swift Petrol	Strut	Front Left	412112	
Swift Petrol	Strut	Front Right	412113	
Swift Diesel	Strut	Front Left	412114	
Swift Diesel	Strut	Front Right	412115	
Wagon R	Strut	Front Universal	412053	
Wagon R	Damper with Bush Kit	Front Universal	412054	
Wagon R	Damper Without Bush Kit	Front Universal	412134	
Wagon R	Strut (Gas)	Front Right	412122	
Wagon R	Damper Without Bush Kit (Gas)	Front Right	412116	
Wagon R	Strut (Gas)	Front Left	412123	
Wagon R	Damper Without Bush Kit (Gas)	Front Left	412117	
Zen	Strut	Front Universal	412055	
Zen	Damper with Bush Kit	Front Universal	412056	
Zen	Damper Without Bush Kit	Front Universal	412128	



Type

Position



TATA

TATA	Indica	Damper with Bush Kit	Rear Universal	412057
	Indica	Damper with Major Bush Kit (22 Dia)	Front Left	412062
	Indica	Damper Without Bush Kit (22 Dia)	Front Left	412146
	Indica	Damper with Major Bush Kit (22 Dia)	Front Right	412063
	Indica	Damper Without Bush Kit (22 Dia)	Front Right	412147
	Indica	Strut (New Hose Bracket)	Front Left	412064
	Indica	Strut (New Hose Bracket)	Front Right	412065
	Indica	Strut (22 Dia)	Front Left	412066
	Indica	Strut (22 Dia)	Front Right	412067
	Indica	Strut (20 Dia) Old Bracket	Front Left	412068
	Indica	Damper Without Bush Kit (20 Dia)	Front Left	412137
	Indica	Strut (20 Dia) Old Bracket	Front Right	412069
	Indica	Damper Without Bush Kit (20 Dia)	Front Right	412138
	Indica	Strut	Rear Left	412070
	Indica	Strut	Rear Right	412071
	Indica	Damper Without Bush Kit	Front Left	412139
	Indica	Damper Without Bush Kit	Front Right	412140
	Indica	Damper Without Bush Kit	Rear Universal	412141
	Vista	Strut (Gas)	Front Left	412110
	Vista	Strut (Gas)	Front Right	412111
	Vista	Strut (Gas)	Rear Universal	412106
	Vista	Damper Without Bush Kit	Front Left	412108
	Vista	Damper Without Bush Kit	Front Right	412109
	Vista	Damper Without Bush Kit	Rear	412107
	Indigo	Strut	Front Left	412072
	Indigo	Damper With Bush Kit	Front Left	412076
	Indigo	Damper Without Bush Kit	Front Left	412142
	Indigo	Strut	Front Right	412073
	Indigo	Damper With Bush Kit	Front Right	412077
	Indigo	Damper Without Bush Kit	Front Right	412143
	Indigo	Strut	Rear Left	412074
	Indigo	Damper With Bush Kit	Rear Left	412078
	Indigo	Damper Without Bush Kit	Rear Left	412144
Indigo	Strut	Rear Right	412075	
Indigo	Damper With Bush Kit	Rear Right	412079	
Indigo	Damper Without Bush Kit	Rear Right	412145	
Super Ace (1T)	Damper (Gas) Without Bush Kit	Front Left	412100	
Super Ace (1T)	Damper (Gas) Without Bush Kit	Front Right	412101	
Zip	Strut	Front Right	412102	
Zip	Strut	Front Left	412103	
Winger	Damper	Right	412087	
Winger	Damper	Left	412086	
TOYOTA	Innova	Damper (Gas) Without Bush Kit	Front Left	412090
	Innova	Damper (Gas) Without Bush Kit	Front Right	412091



Front

Rear

SHOCK ABSORBERS

SMALL COMMERCIAL VEHICLE

FORCE MOTORS	Minidor	411307	411308
	TempoTraveller	411903	411904
MAHINDRA	Champion	411315	411316
PIAGGIO	Ape	411320	411321
ASHOK LEYLAND	Dost	411942	411943

PASSENGER CAR

BAJAJ	Tempo traveller	411903	411904
	Tavera	411401	411402
CHEVROLET	Figgo		412126
FORD	Ambassador	411410	411411
	Isuzu-1800	411413	
HYUNDAI	Santero		411417
	Bolero Long		411424
MAHINDRA & MAHINDRA	Bolero	411428	
	Scorpio	411435	411436
	Jeep Taxi		411443
	Logan		411478
	800 Car (89 model)		411445
MARUTI	Maruti Car 98 Gas		411447
	Omni		411448
	Swift		411451
	Alto		411452
	Sx4		411453
	Wagon R		411454
	Zen Gas		411455
ICML	Rhino	411457	
TATA	Ace	411926	411927
	Sumo Taxi	411468	
	Winger	412086	412087
	Innova		411473

CABIN SHOCKERS

APPLICATION	Model	Type	Position	Part No.
TATA	LP 1210	Shox	Cabin	412170
	1526	Damper	Cabin	412171
	4925 (Non SLPR Cabin)	Damper	Non SLPR Cabin	412172
ASHOK LEYLAND	Ashok Leyland	Damper	Cabin	412167
	Ashok Leyland	Damper	Cabin	412168
	Ashok Leyland	Damper	Cabin	412169

