

DIESEL SOLUTIONS

Probable cause	Engine not starting	Hard to start engine	Runs rough at lower RPM	Lack of power	Diesel knock / pinking	Black smoke	White smoke
Fuel Quality - petrol - contamination	X	X	X	X	X		X
Faulty Diesel Injector/s	X	X	X	X	X	X	X
High Pressure Pump Faulty	X	X	X	X		X	
Faulty pressure regulator - sensor	X	X	X	X			
Injector blow-by seat leaking	X	X	X	X	X	X	
Injector wiring harness Faulty			X		X	X	X