



# ***FIRST***

# 2016

## WIPER BLADE CATALOG

valeo added 

Automotive technology, naturally

**Valeo**

# FIRST


12 PART NUMBERS ✓

LENGTHS: 14" - 28" ✓

98% MARKET COVERAGE ✓

## ALL-IN-ONE ADAPTER SYSTEM

Quick and Easy Installation



Shown with  
Multi-Connect Adapter

## 3-D SPOILER DESIGN

High Speed Performance

## AERODYNAMIC END CLIP

Reduces Drag on Windshield

## TEC2™ SYNTHETIC RUBBER + COATING

Long Lasting, All-Weather Durability

## CURVED METAL SPLINE

Optimized Contact and Wiping Performance

## FITS THESE 5 ARM TYPES:

Hook 9x3/9x4  
Side Pin  
Side Lock  
Top Lock Pinch  
(Tab)  
Top Lock Push  
(Button)


Part Number	Blade Length (in)	Blade Length (mm)	Hook Adapter	Multi-Connect Adapters	Side Pin Adapter
ONE 14	14"	350	X	X	-
ONE 15	15"	380	X	X	-
ONE 16	16"	400	X	X	X
ONE 17	17"	425	X	X	X
ONE 18	18"	450	X	X	X
ONE 19	19"	475	X	X	X
ONE 20	20"	500	X	X	X
ONE 21	21"	530	X	X	-
ONE 22	22"	550	X	X	X
ONE 24	24"	600	X	X	-
ONE 26	26"	650	X	X	-
ONE 28	28"	700	X	X	-

# ***FIRST***

## TABLE OF CONTENTS



Wiper Blade Specifications.....	<b>3</b>
Application Guide.....	<b>5</b>
Interchange Guide.....	<b>97</b>
Installation Instructions.....	<b>109</b>






# ***FIRST***

## WIPER BLADE SPECIFICATIONS



**IMPORTANT NOTICE:** In preparation for this catalog, every effort has been made to obtain accurate and complete information at the time of printing. Valeo Service assumes no responsibility or liability for any errors or omissions contained in this catalog. All references to the original manufacturer trade names and part numbers are for identification purposes only.



# WIPER BLADE SPECIFICATIONS



PRODUCT SPECIFICATIONS: Single Unit					12 SKUs			
PART NUMBER	LENGTH		MIN. ORDER QTY	SINGLE UNIT				
	IN	MM		EAN	GROSS WT. (lb)	H (in)	L (in)	W (in)
ONE14	14"	350	5	804163155757	0.29	20.00	2.76	0.79
ONE15	15"	380	5	804163155764	0.30	20.00	2.76	0.79
ONE16	16"	400	5	804163155771	0.31	20.00	2.76	0.79
ONE17	17"	430	5	804163155788	0.32	20.00	2.76	0.79
ONE18	18"	450	5	804163155795	0.32	20.00	2.76	0.79
ONE19	19"	475	5	804163155801	0.33	20.00	2.76	0.79
ONE20	20"	500	5	804163155818	0.34	20.00	2.76	0.79
ONE21	21"	530	5	804163155825	0.37	24.00	2.76	0.79
ONE22	22"	550	5	804163155832	0.38	24.00	2.76	0.79
ONE24	24"	600	5	804163155849	0.39	24.00	2.76	0.79
ONE26	26"	650	5	804163155856	0.42	28.00	2.76	0.79
ONE28	28"	700	5	804163155863	0.43	28.00	2.76	0.79


PRODUCT SPECIFICATIONS: Case					12 SKUs			
PART NUMBER	LENGTH		CASE QTY	CASE QTY				
	IN	MM		UCC	CASE WT (lb)	H (in)	L (in)	W (in)
ONE14	14"	350	5	38041631557573	1.87	22.24	4.76	2.76
ONE15	15"	380	5	38041631557641	1.92	22.24	4.76	2.76
ONE16	16"	400	5	38041631557719	1.98	22.24	4.76	2.76
ONE17	17"	430	5	38041631557887	2.03	22.24	4.76	2.76
ONE18	18"	450	5	38041631557955	2.06	22.24	4.76	2.76
ONE19	19"	475	5	38041631558013	2.10	22.24	4.76	2.76
ONE20	20"	500	5	38041631558181	2.14	22.24	4.76	2.76
ONE21	21"	530	5	38041631558259	2.35	26.18	4.76	2.76
ONE22	22"	550	5	38041631558327	2.40	26.18	4.76	2.76
ONE24	24"	600	5	38041631558495	2.46	26.18	4.76	2.76
ONE26	26"	650	5	38041631558563	2.66	30.12	4.76	2.76
ONE28	28"	700	5	38041631558631	2.74	30.12	4.76	2.76

# ***FIRST***

## APPLICATION GUIDE



**IMPORTANT NOTICE:** In preparation for this catalog, every effort has been made to obtain accurate and complete information at the time of printing. Valeo Service assumes no responsibility or liability for any errors or omissions contained in this catalog. All references to the original manufacturer trade names and part numbers are for identification purposes only.



# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>ACURA</b>		
<b>CL</b>		
2003-2001, 1999-1997	Driver	ONE24
	Passenger	ONE19
<b>CSX</b>		
2011-2008	Driver	ONE26
	Passenger	ONE22
<b>EL</b>		
2005-2001	Driver	ONE21
	Passenger	ONE19
2000-1999	Driver	ONE20
	Passenger	ONE18
1998-1997	Driver	ONE20
	Passenger	ONE18
	Rear	ONE15
<b>ILX</b>		
2015-2013	Driver	ONE26
	Passenger	ONE19
<b>Integra</b>		
2001-1994	Driver	ONE22
	Passenger	ONE18
	Rear	ONE19
1993-1990	Driver	ONE20
	Passenger	ONE19
	Rear	ONE19
1989-1986	Driver	ONE19
	Passenger	ONE19
	Rear	ONE18
<b>Legend</b>		
1995-1991	Driver	ONE22
	Passenger	ONE19
1990-1986	Driver	ONE20
	Passenger	ONE19
<b>MDX</b>		
2015-2014	Driver	ONE26
	Passenger	ONE20

<b>ACURA (cont.)</b>		
<b>MDX (cont.)</b>		
2013-2007	Driver	ONE26
	Passenger	ONE21
2006-2001	Driver	ONE24
	Passenger	ONE21
<b>NSX</b>		
2005-1991	Driver	ONE22
	Passenger	ONE21
<b>RDX</b>		
2015-2007	Driver	ONE26
	Passenger	ONE16
<b>RL</b>		
2004-1996	Driver	ONE22
	Passenger	ONE19
<b>RLX</b>		
2015-2014	Driver	ONE26
	Passenger	ONE20
<b>RSX</b>		
2006-2002	Driver	ONE24
	Passenger	ONE20
	Rear	ONE20
<b>SLX</b>		
1999-1996	Driver	ONE20
	Passenger	ONE20
	Rear	ONE15
<b>TL</b>		
2014-2004	Driver	ONE26
	Passenger	ONE19
2003-1995	Driver	ONE24
	Passenger	ONE19
<b>TLX</b>		
2015	Driver	ONE26
	Passenger	ONE17





## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>ACURA (cont.)</b>		
<b>TSX</b>		
2014-2009	Driver	ONE24
	Passenger	ONE22
2008-2004	Driver	ONE26
	Passenger	ONE16
<b>Vigor</b>		
1994-1992	Driver	ONE24
	Passenger	ONE19
<b>ZDX</b>		
2013-2010	Driver	ONE26
	Passenger	ONE19
<b>ALFA ROMEO</b>		
<b>164</b>		
1995-1991	Driver	ONE21
	Passenger	ONE21
<b>GTV-6</b>		
1986-1981	Driver	ONE18
	Passenger	ONE18
<b>Milano</b>		
1989-1987	Driver	ONE18
	Passenger	ONE18
<b>Spider</b>		
1994-1971	Driver	ONE16
	Passenger	ONE16
<b>AMERICAN MOTORS</b>		
<b>Eagle</b>		
1988-1980	Rear	ONE16
<b>Pacer</b>		
1980-1975	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>ASTON MARTIN</b>		
<b>DB9</b>		
2014-2012	Driver	ONE26
	Passenger	ONE20

<b>ASTON MARTIN (cont.)</b>		
<b>DB9 (cont.)</b>		
2011-2005	Driver	ONE24
	Passenger	ONE20
<b>DBS</b>		
2012	Driver	ONE26
	Passenger	ONE20
2011-2008	Driver	ONE24
	Passenger	ONE20
<b>Rapide</b>		
2014-2012	Driver	ONE26
	Passenger	ONE20
2011	Driver	ONE24
	Passenger	ONE20
<b>V12 Vantage</b>		
2013-2012	Driver	ONE26
	Passenger	ONE20
2011-2010	Driver	ONE24
	Passenger	ONE20
<b>V8 Vantage</b>		
2014-2012	Driver	ONE26
	Passenger	ONE20
2011-2006	Driver	ONE24
	Passenger	ONE20
<b>Vanquish</b>		
2006	Driver	ONE21
	Passenger	ONE21
<b>ASUNA</b>		
<b>GT</b>		
1993	Driver	ONE18
	Passenger	ONE18
<b>SE</b>		
1993	Driver	ONE18
	Passenger	ONE18

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>ASUNA (cont.)</b>		
<b>Sunfire</b>		
1993	Driver	ONE22
	Passenger	ONE20
<b>Sunrunner</b>		
1993-1992	Driver	ONE17
	Passenger	ONE17
<b>AUDI</b>		
<b>100</b>		
1994-1992	Driver	ONE22
	Passenger	ONE22
	Rear	ONE18
1991-1989	Driver	ONE21
	Passenger	ONE21
	Rear	ONE21
<b>100 Quattro</b>		
1994-1992	Driver	ONE22
	Passenger	ONE22
	Rear	ONE18
1991-1989	Driver	ONE21
	Passenger	ONE21
	Rear	ONE21
<b>100 Series</b>		
1977-1969	Driver	ONE16
	Passenger	ONE16
<b>200</b>		
1991-1989	Driver	ONE21
	Passenger	ONE21
	Rear	ONE21
<b>200 Quattro</b>		
1991-1989	Driver	ONE21
	Passenger	ONE21
	Rear	ONE21

<b>AUDI (cont.)</b>		
<b>4000</b>		
1987-1985	Driver	ONE21
	Passenger	ONE21
	Rear	ONE18
1984-1980	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>4000 Quattro</b>		
1987-1985	Driver	ONE21
	Passenger	ONE21
	Rear	ONE18
1984	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>5000</b>		
1988-1984	Driver	ONE21
	Passenger	ONE21
	Rear	ONE21
1983-1978	Driver	ONE18
	Passenger	ONE18
<b>5000 Quattro</b>		
1988-1986	Driver	ONE21
	Passenger	ONE21
	Rear	ONE21
<b>80</b>		
1992-1988	Driver	ONE21
	Passenger	ONE21
<b>80 Quattro</b>		
1992-1988	Driver	ONE21
	Passenger	ONE21
<b>90</b>		
1995-1993, 1991-1988	Driver	ONE21
	Passenger	ONE21



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>AUDI (cont.)</b>		
<b>90 Quattro</b>		
1995-1988	Driver	ONE21
	Passenger	ONE21
<b>A3</b>		
2013-2006	Driver	ONE24
	Passenger	ONE19
<b>A4</b>		
2001-1998	Driver	ONE21
	Passenger	ONE20
	Rear	ONE15
1997-1996	Driver	ONE21
	Passenger	ONE20
<b>A4 Quattro</b>		
2001-1998	Driver	ONE21
	Passenger	ONE20
	Rear	ONE15
1997-1996	Driver	ONE21
	Passenger	ONE20
<b>A6</b>		
2001-1999	Driver	ONE22
	Passenger	ONE22
	Rear	ONE15
1998-1995	Driver	ONE22
	Passenger	ONE22
	Rear	ONE18
<b>A6 Quattro</b>		
2001-1999	Driver	ONE22
	Passenger	ONE22
	Rear	ONE15
1998-1995	Driver	ONE22
	Passenger	ONE22
	Rear	ONE18
<b>Allroad Quattro</b>		
2001	Driver	ONE22
	Passenger	ONE22

<b>AUDI (cont.)</b>		
<b>Cabriolet</b>		
1998-1994	Driver	ONE22
	Passenger	ONE22
<b>Coupe</b>		
1987-1985	Driver	ONE21
	Passenger	ONE21
1984-1981	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>Coupe Quattro</b>		
1991-1990	Driver	ONE21
	Passenger	ONE21
<b>Fox</b>		
1979-1973	Driver	ONE16
	Passenger	ONE16
	Rear	ONE16
<b>Q7</b>		
2015-2007	Driver	ONE26
	Passenger	ONE26
<b>Quattro</b>		
1986-1984	Driver	ONE21
	Passenger	ONE21
	Rear	ONE18
1983	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>S4</b>		
2002	Driver	ONE22
	Passenger	ONE21
	Rear	ONE15
2001	Driver	ONE21
	Passenger	ONE20
	Rear	ONE15
2000	Driver	ONE21
	Passenger	ONE20

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>AUDI (cont.)</b>		
<b>S4 (cont.)</b>		
1994-1992	Driver	ONE22
	Passenger	ONE22
<b>S6</b>		
2003-2002	Rear	ONE15
1997-1995	Driver	ONE22
	Passenger	ONE22
<b>S8</b>		
2002-2001	Driver	ONE22
	Passenger	ONE22
<b>Super 90</b>		
1972-1969	Driver	ONE16
	Passenger	ONE16
<b>TT</b>		
2014-2008	Driver	ONE22
	Passenger	ONE21
2007-2004	Driver	ONE21
	Passenger	ONE21
2003-1999	Driver	ONE21
	Passenger	ONE20
<b>TT Quattro</b>		
2014-2008	Driver	ONE22
	Passenger	ONE21
2007-2004	Driver	ONE21
	Passenger	ONE21
2003-2000	Driver	ONE21
	Passenger	ONE20
<b>V8 Quattro</b>		
1994-1993	Driver	ONE22
	Passenger	ONE22
1992-1990	Driver	ONE21
	Passenger	ONE21

<b>BMW</b>		
<b>1 Series M</b>		
2011	Driver	ONE20
	Passenger	ONE20
<b>118i</b>		
2013-2012	Driver	ONE20
	Passenger	ONE20
<b>120i</b>		
2012-2008	Driver	ONE20
	Passenger	ONE20
<b>125i</b>		
2013-2012, 2010-2009	Driver	ONE20
	Passenger	ONE20
<b>128i</b>		
2013-2008	Driver	ONE20
	Passenger	ONE20
<b>130i</b>		
2010-2008	Driver	ONE20
	Passenger	ONE20
<b>135i</b>		
2013-2008	Driver	ONE20
	Passenger	ONE20
<b>135is</b>		
2013	Driver	ONE20
	Passenger	ONE20
<b>220i</b>		
2015-2014	Driver	ONE22
	Passenger	ONE18
<b>228i</b>		
2015-2014	Driver	ONE22
	Passenger	ONE18
<b>228i xDrive</b>		
2015	Driver	ONE22
	Passenger	ONE18



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>BMW (cont.)</b>		
<b>235i</b>		
2014	Driver	ONE22
	Passenger	ONE18
<b>3.0Si</b>		
1976-1975	Driver	ONE16
	Passenger	ONE16
<b>318i</b>		
1999	Driver	ONE21
	Passenger	ONE20
1991, 1985-1984	Driver	ONE20
	Passenger	ONE20
<b>318i Convertible E36</b>		
1998-1996	Driver	ONE21
	Passenger	ONE20
1995-1994, 1992	Driver	ONE22
	Passenger	ONE20
<b>318i Sedan E36</b>		
1998-1992	Driver	ONE21
	Passenger	ONE20
<b>318is</b>		
1999	Driver	ONE21
	Passenger	ONE20
1991	Driver	ONE20
	Passenger	ONE20
<b>318is Coupe E36</b>		
1998-1992	Driver	ONE21
	Passenger	ONE20
<b>318ti Hatchback E36</b>		
1999-1996	Driver	ONE21
	Passenger	ONE20
1995	Driver	ONE20
	Passenger	ONE20
<b>320i</b>		
2015	Driver	ONE24
	Passenger	ONE19

<b>BMW (cont.)</b>		
<b>320i (cont.)</b>		
1983-1980	Driver	ONE18
	Passenger	ONE18
<b>320i E46</b>		
2005-2001	Driver	ONE22
	Passenger	ONE20
<b>320i Sedan E36</b>		
1995-1992	Driver	ONE21
	Passenger	ONE20
<b>320i Sedan F30</b>		
2014-2012	Driver	ONE24
	Passenger	ONE19
<b>320i xDrive</b>		
2015	Driver	ONE24
	Passenger	ONE19
<b>320i xDrive Sedan F30</b>		
2014-2013	Driver	ONE24
	Passenger	ONE19
<b>323Ci E46</b>		
2000	Driver	ONE22
	Passenger	ONE20
<b>323i Convertible E36</b>		
1998	Driver	ONE21
	Passenger	ONE20
<b>323i E46</b>		
2000-1999	Driver	ONE22
	Passenger	ONE20
<b>323i Sedan E90</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19
<b>323is Coupe E36</b>		
1998	Driver	ONE21
	Passenger	ONE20

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>BMW (cont.)</b>		
<b>325</b>		
1988-1986	Driver	ONE20
	Passenger	ONE20
<b>325Ci E46</b>		
2005-2001	Driver	ONE22
	Passenger	ONE20
<b>325e</b>		
1987-1984	Driver	ONE20
	Passenger	ONE20
<b>325es</b>		
1987-1986	Driver	ONE20
	Passenger	ONE20
<b>325i</b>		
1991-1987	Driver	ONE20
	Passenger	ONE20
<b>325i Convertible E36</b>		
1995-1992	Driver	ONE22
	Passenger	ONE20
<b>325i E46</b>		
2005-2001	Driver	ONE22
	Passenger	ONE20
<b>325i Sedan E36</b>		
1995-1992	Driver	ONE21
	Passenger	ONE20
<b>325ix</b>		
1991-1988	Driver	ONE20
	Passenger	ONE20
<b>325is</b>		
1991-1987	Driver	ONE20
	Passenger	ONE20
<b>325is Coupe E36</b>		
1995-1992	Driver	ONE21
	Passenger	ONE20

<b>BMW (cont.)</b>		
<b>325xi E46</b>		
2005-2001	Driver	ONE22
	Passenger	ONE20
<b>328Ci E46</b>		
2000	Driver	ONE22
	Passenger	ONE20
<b>328d</b>		
2015	Driver	ONE24
	Passenger	ONE19
<b>328d Sedan F30</b>		
2014	Driver	ONE24
	Passenger	ONE19
<b>328d xDrive</b>		
2015	Driver	ONE24
	Passenger	ONE19
<b>328d xDrive Sedan F30</b>		
2014	Driver	ONE24
	Passenger	ONE19
<b>328d xDrive Sedan F31</b>		
2014	Driver	ONE24
	Passenger	ONE19
<b>328d xDrive Wagon F30</b>		
2014	Driver	ONE24
	Passenger	ONE19
<b>328d xDrive Wagon F31</b>		
2014	Driver	ONE24
	Passenger	ONE19
<b>328i</b>		
2015	Driver	ONE24
	Passenger	ONE19
<b>328i Convertible E36</b>		
1998-1996	Driver	ONE21
	Passenger	ONE20



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>BMW (cont.)</b>		
<b>328i Convertible E92</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>328i Convertible E93</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>328i Convertible F30</b>		
2013-2012	Driver	ONE24
	Passenger	ONE18
<b>328i Coupe E92</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>328i Coupe E93</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>328i Coupe F30</b>		
2013-2012	Driver	ONE24
	Passenger	ONE18
<b>328i E46</b>		
2000-1999	Driver	ONE22
	Passenger	ONE20
<b>328i GT xDrive</b>		
2015	Driver	ONE24
	Passenger	ONE19
<b>328i GT xDrive Hatchback F34</b>		
2014	Driver	ONE24
	Passenger	ONE19
<b>328i Sedan E36</b>		
1998-1996	Driver	ONE21
	Passenger	ONE20
<b>328i Sedan E90</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19

<b>BMW (cont.)</b>		
<b>328i Sedan E91</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19
<b>328i Sedan F30</b>		
2014-2012	Driver	ONE24
	Passenger	ONE19
<b>328i Wagon E90</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19
<b>328i Wagon E91</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19
<b>328i Wagon F30</b>		
2012	Driver	ONE24
	Passenger	ONE19
<b>328i xDrive</b>		
2015	Driver	ONE24
	Passenger	ONE19
<b>328i xDrive Coupe E92</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>328i xDrive Coupe F30</b>		
2013	Driver	ONE24
	Passenger	ONE18
<b>328i xDrive Sedan E90</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19
<b>328i xDrive Sedan E91</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19
<b>328i xDrive Sedan F30</b>		
2014-2013	Driver	ONE24
	Passenger	ONE19

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>BMW (cont.)</b>		
<b>328i xDrive Sedan F31</b>		
2014	Driver	ONE24
	Passenger	ONE19
<b>328i xDrive Wagon E90</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19
<b>328i xDrive Wagon E91</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19
<b>328i xDrive Wagon F30</b>		
2014	Driver	ONE24
	Passenger	ONE19
<b>328i xDrive Wagon F31</b>		
2014	Driver	ONE24
	Passenger	ONE19
<b>328is Coupe E36</b>		
1998-1996	Driver	ONE21
	Passenger	ONE20
<b>330Ci E46</b>		
2005-2001	Driver	ONE22
	Passenger	ONE20
<b>330i E46</b>		
2005-2001	Driver	ONE22
	Passenger	ONE20
<b>330xi E46</b>		
2005-2001	Driver	ONE22
	Passenger	ONE20
<b>335d Sedan E90</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19
<b>335i</b>		
2015	Driver	ONE24
	Passenger	ONE19

<b>BMW (cont.)</b>		
<b>335i Convertible E92</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>335i Convertible E93</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>335i Convertible F30</b>		
2013-2012	Driver	ONE24
	Passenger	ONE18
<b>335i Coupe E92</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>335i Coupe E93</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>335i Coupe F30</b>		
2013-2012	Driver	ONE24
	Passenger	ONE18
<b>335i GT xDrive</b>		
2015	Driver	ONE24
	Passenger	ONE19
<b>335i GT xDrive Hatchback F34</b>		
2014	Driver	ONE24
	Passenger	ONE19
<b>335i Sedan E90</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19
<b>335i Sedan F30</b>		
2014-2012	Driver	ONE24
	Passenger	ONE19
<b>335i xDrive</b>		
2015	Driver	ONE24
	Passenger	ONE19





## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>BMW (cont.)</b>		
<b>335i xDrive Coupe E92</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>335i xDrive Coupe F30</b>		
2013	Driver	ONE24
	Passenger	ONE18
<b>335i xDrive Sedan E90</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19
<b>335i xDrive Sedan F30</b>		
2014-2013	Driver	ONE24
	Passenger	ONE19
<b>335is</b>		
2013-2012	Driver	ONE24
	Passenger	ONE17
<b>335is Convertible E92</b>		
2011	Driver	ONE24
	Passenger	ONE18
<b>335is Convertible E93</b>		
2011	Driver	ONE24
	Passenger	ONE18
<b>335is Coupe E92</b>		
2011	Driver	ONE24
	Passenger	ONE18
<b>335is Coupe E93</b>		
2011	Driver	ONE24
	Passenger	ONE18
<b>428i</b>		
2015-2014	Driver	ONE24
	Passenger	ONE18
<b>428i Gran Coupe</b>		
2015	Driver	ONE24
	Passenger	ONE18

<b>BMW (cont.)</b>		
<b>428i xDrive</b>		
2015-2014	Driver	ONE24
	Passenger	ONE18
<b>428i xDrive Gran Coupe</b>		
2015	Driver	ONE24
	Passenger	ONE18
<b>435i</b>		
2015-2014	Driver	ONE24
	Passenger	ONE18
<b>435i Gran Coupe</b>		
2015	Driver	ONE24
	Passenger	ONE18
<b>435i xDrive</b>		
2015-2014	Driver	ONE24
	Passenger	ONE18
<b>435i xDrive Gran Coupe</b>		
2015	Driver	ONE24
	Passenger	ONE18
<b>524td E28</b>		
1986-1985	Driver	ONE18
	Passenger	ONE18
<b>525i</b>		
2009-2004	Driver	ONE24
	Passenger	ONE22
2003-2001	Driver	ONE26
	Passenger	ONE21
<b>525i E34</b>		
1995-1989	Driver	ONE22
	Passenger	ONE24
<b>525it E34</b>		
1993	Driver	ONE22
	Passenger	ONE24
<b>525xi</b>		
2007-2006	Driver	ONE24
	Passenger	ONE22

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>BMW (cont.)</b>		
<b>528e E28</b>		
1988-1982	Driver	ONE18
	Passenger	ONE18
<b>528i</b>		
2009-2008	Driver	ONE24
	Passenger	ONE22
2000-1997	Driver	ONE26
	Passenger	ONE21
<b>528i xDrive</b>		
2009	Driver	ONE24
	Passenger	ONE22
<b>528xi</b>		
2008	Driver	ONE24
	Passenger	ONE22
<b>530i</b>		
2009-2004	Driver	ONE24
	Passenger	ONE22
2003-2001	Driver	ONE26
	Passenger	ONE21
<b>530i E34</b>		
1995-1994	Driver	ONE22
	Passenger	ONE24
<b>530xi</b>		
2007-2006	Driver	ONE24
	Passenger	ONE22
<b>533i E28</b>		
1984-1983	Driver	ONE18
	Passenger	ONE18
<b>535i</b>		
2009-2008	Driver	ONE24
	Passenger	ONE22
<b>535i E28</b>		
1988-1985	Driver	ONE18
	Passenger	ONE18

<b>BMW (cont.)</b>		
<b>535i E34</b>		
1993-1989	Driver	ONE22
	Passenger	ONE24
<b>535i xDrive</b>		
2009	Driver	ONE24
	Passenger	ONE22
<b>535is E28</b>		
1988	Driver	ONE18
	Passenger	ONE18
<b>535xi</b>		
2008	Driver	ONE24
	Passenger	ONE22
<b>540i E34</b>		
1995-1994	Driver	ONE22
	Passenger	ONE24
<b>545i</b>		
2006-2004	Driver	ONE24
	Passenger	ONE22
<b>550i</b>		
2009-2006	Driver	ONE24
	Passenger	ONE22
<b>633CSi</b>		
1984-1980	Driver	ONE18
	Passenger	ONE18
<b>635CSi</b>		
1989-1985	Driver	ONE18
	Passenger	ONE18
<b>645Ci</b>		
2005-2004	Driver	ONE24
	Passenger	ONE22
<b>650Ci</b>		
2010-2006	Driver	ONE24
	Passenger	ONE22



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>BMW (cont.)</b>		
<b>650i</b>		
2010-2006	Driver	ONE24
	Passenger	ONE22
<b>733i</b>		
1984-1980	Driver	ONE18
	Passenger	ONE18
<b>735i</b>		
1992-1991	Driver	ONE22
	Passenger	ONE24
1990-1988	Driver	ONE24
	Passenger	ONE24
1987-1985	Driver	ONE18
	Passenger	ONE18
<b>735iL</b>		
1992-1991	Driver	ONE22
	Passenger	ONE24
1990-1988	Driver	ONE24
	Passenger	ONE24
<b>740i</b>		
2001-1997, 1995-1993	Driver	ONE22
	Passenger	ONE24
<b>740iL</b>		
2001-1993	Driver	ONE22
	Passenger	ONE24
<b>750iL</b>		
2001-1991	Driver	ONE22
	Passenger	ONE24
1990-1988	Driver	ONE24
	Passenger	ONE24
<b>L7</b>		
1987-1986	Driver	ONE18
	Passenger	ONE18
<b>M3</b>		
2015	Driver	ONE24
	Passenger	ONE19

<b>BMW (cont.)</b>		
<b>M3 (cont.)</b>		
2013-2012	Driver	ONE24
	Passenger	ONE18
1999-1994	Driver	ONE21
	Passenger	ONE20
1991-1988	Driver	ONE20
	Passenger	ONE20
<b>M3 Convertible E92</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>M3 Convertible E93</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>M3 Coupe E92</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>M3 Coupe E93</b>		
2011-2010	Driver	ONE24
	Passenger	ONE18
<b>M3 Sedan E90</b>		
2011-2010	Driver	ONE24
	Passenger	ONE19
<b>M4</b>		
2015	Driver	ONE24
	Passenger	ONE18
<b>M6</b>		
2010-2006	Driver	ONE24
	Passenger	ONE22
1988-1987	Driver	ONE18
	Passenger	ONE18
<b>X1</b>		
2015-2012	Driver	ONE24
	Passenger	ONE18

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>BMW (cont.)</b>		
<b>X3</b>		
2015-2011	Driver	ONE26
	Passenger	ONE20
2010-2004	Driver	ONE22
	Passenger	ONE20
<b>X4</b>		
2015	Driver	ONE26
	Passenger	ONE20
<b>X5</b>		
2015-2014, 2011-2007	Driver	ONE24
	Passenger	ONE20
2006-2000	Driver	ONE24
	Passenger	ONE22
	Rear	ONE18
<b>X6</b>		
2015-2008	Driver	ONE24
	Passenger	ONE20
<b>Z3</b>		
2002-1996	Driver	ONE20
	Passenger	ONE20
<b>Z4</b>		
2015-2009	Driver	ONE22
	Passenger	ONE20
2008-2003	Driver	ONE21
	Passenger	ONE20
<b>i3</b>		
2015-2014	Driver	ONE28
	Passenger	ONE21
<b>i8</b>		
2015	Driver	ONE28
	Passenger	ONE24
<b>BUICK</b>		
<b>Allure</b>		
2010	Driver	ONE26
	Passenger	ONE18

<b>BUICK (cont.)</b>		
<b>Allure (cont.)</b>		
2009-2005	Driver	ONE22
	Passenger	ONE22
<b>Apollo</b>		
1975-1973	Driver	ONE16
	Passenger	ONE16
<b>Centurion</b>		
1973-1971	Driver	ONE18
	Passenger	ONE18
<b>Century</b>		
2005-1997	Driver	ONE22
	Passenger	ONE22
1996-1984, 1981-1978	Driver	ONE18
	Passenger	ONE18
1977-1973	Driver	ONE16
	Passenger	ONE16
<b>Electra</b>		
1990-1985	Driver	ONE19
	Passenger	ONE19
1984-1968	Driver	ONE18
	Passenger	ONE18
<b>Enclave</b>		
2015-2008	Driver	ONE24
	Passenger	ONE21
<b>Encore</b>		
2015-2013	Driver	ONE26
	Passenger	ONE14
<b>Estate Wagon</b>		
1983-1970	Driver	ONE18
	Passenger	ONE18
<b>LaCrosse</b>		
2015-2010	Driver	ONE26
	Passenger	ONE18
2009-2005	Driver	ONE22
	Passenger	ONE22



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>BUICK (cont.)</b>		
<b>LeSabre</b>		
2005-1992	Driver	ONE22
	Passenger	ONE22
1991-1987	Driver	ONE19
	Passenger	ONE19
1986-1970	Driver	ONE18
	Passenger	ONE18
<b>Lucerne</b>		
2011-2006	Driver	ONE24
	Passenger	ONE21
<b>Park Avenue</b>		
2005-1991	Driver	ONE22
	Passenger	ONE22
<b>Rainier</b>		
2007-2006	Driver	ONE22
	Passenger	ONE22
2005-2004	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>Reatta</b>		
1991-1988	Driver	ONE19
	Passenger	ONE19
<b>Regal</b>		
2015-2011	Driver	ONE24
	Passenger	ONE18
2004-1997	Driver	ONE22
	Passenger	ONE22
1996-1988	Driver	ONE20
	Passenger	ONE20
1987-1978	Driver	ONE18
	Passenger	ONE18
1977-1973	Driver	ONE16
	Passenger	ONE16

<b>BUICK (cont.)</b>		
<b>Rendezvous</b>		
2007-2002	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16
<b>Riviera</b>		
1999-1995	Driver	ONE22
	Passenger	ONE22
1993-1986	Driver	ONE19
	Passenger	ONE19
1985-1971	Driver	ONE18
	Passenger	ONE18
<b>Roadmaster</b>		
1996-1991	Driver	ONE22
	Passenger	ONE17
<b>Skyhawk</b>		
1989-1983	Driver	ONE16
	Passenger	ONE16
	Rear	ONE16
<b>Skylark</b>		
1998-1986	Driver	ONE19
	Passenger	ONE19
1985-1980	Driver	ONE18
	Passenger	ONE18
1979-1975, 1972-1968	Driver	ONE16
	Passenger	ONE16
<b>Somerset</b>		
1987-1986	Driver	ONE19
	Passenger	ONE19
<b>Somerset Regal</b>		
1985	Driver	ONE19
	Passenger	ONE19
<b>Special</b>		
1969-1968	Driver	ONE16
	Passenger	ONE16

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>BUICK (cont.)</b>		
<b>Terraza</b>		
2007-2005	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16
<b>Verano</b>		
2015-2012	Driver	ONE26
	Passenger	ONE24
<b>Wildcat</b>		
1970-1968	Driver	ONE18
	Passenger	ONE18
<b>CADILLAC</b>		
<b>60 Special</b>		
1993	Driver	ONE22
	Passenger	ONE22
<b>ATS</b>		
2015-2013	Driver	ONE22
	Passenger	ONE18
<b>Allante</b>		
1993-1987	Driver	ONE20
	Passenger	ONE20
<b>Brougham</b>		
1992-1987	Driver	ONE18
	Passenger	ONE18
<b>CTS</b>		
2016-2015	Driver	ONE24
	Passenger	ONE18
2014	Passenger	ONE18
2013-2008	Driver	ONE22
	Passenger	ONE19
2007-2003	Driver	ONE22
	Passenger	ONE21
<b>CTS V</b>		
2016-2015	Driver	ONE24
	Passenger	ONE18

<b>CADILLAC (cont.)</b>		
<b>CTS V (cont.)</b>		
2013-2009	Driver	ONE22
	Passenger	ONE19
<b>Calais</b>		
1976-1970	Driver	ONE18
	Passenger	ONE18
<b>Catera</b>		
2001-1997	Driver	ONE24
	Passenger	ONE19
<b>Cimarron</b>		
1988-1982	Driver	ONE16
	Passenger	ONE16
<b>DTS</b>		
2011-2006	Driver	ONE22
	Passenger	ONE22
<b>DeVille</b>		
2005-1991	Driver	ONE22
	Passenger	ONE22
1990-1985	Driver	ONE19
	Passenger	ONE19
1984-1970	Driver	ONE18
	Passenger	ONE18
<b>ELR</b>		
2016, 2014	Driver	ONE26
	Passenger	ONE26
<b>Eldorado</b>		
2002-1992	Driver	ONE22
	Passenger	ONE22
1991-1986	Driver	ONE19
	Passenger	ONE19
1985-1970	Driver	ONE18
	Passenger	ONE18
<b>Escalade</b>		
2015-2007	Driver	ONE22
	Passenger	ONE22



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>CADILLAC (cont.)</b>		
<b>Escalade (cont.)</b>		
2006-2002	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
2000-1999	Driver	ONE18
	Passenger	ONE18
<b>Escalade ESV</b>		
2014-2007	Driver	ONE22
	Passenger	ONE22
2006-2003	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>Escalade EXT</b>		
2013-2002	Driver	ONE22
	Passenger	ONE22
<b>Fleetwood</b>		
1996-1991	Driver	ONE22
	Passenger	ONE22
1990-1989	Driver	ONE19
	Passenger	ONE19
1988-1968	Driver	ONE18
	Passenger	ONE18
<b>SRX</b>		
2015-2010	Driver	ONE26
	Passenger	ONE17
2009-2004	Driver	ONE22
	Passenger	ONE21
<b>STS</b>		
2011-2005	Driver	ONE22
	Passenger	ONE21
<b>Seville</b>		
2004-1992	Driver	ONE22
	Passenger	ONE22
1991-1986	Driver	ONE19
	Passenger	ONE19

<b>CADILLAC (cont.)</b>		
<b>Seville (cont.)</b>		
1985-1976	Driver	ONE18
	Passenger	ONE18
<b>XLR</b>		
2009-2004	Driver	ONE20
	Passenger	ONE20
<b>XTS</b>		
2015-2013	Driver	ONE26
	Passenger	ONE18
<b>CHEVROLET</b>		
<b>Astro</b>		
2005-1985	Driver	ONE18
	Passenger	ONE18
<b>Avalanche</b>		
2013-2007	Driver	ONE22
	Passenger	ONE22
<b>Avalanche 1500</b>		
2006-2002	Driver	ONE22
	Passenger	ONE22
<b>Avalanche 2500</b>		
2006-2002	Driver	ONE22
	Passenger	ONE22
<b>Aveo</b>		
2011-2009	Driver	ONE22
	Passenger	ONE18
2006-2004	Driver	ONE22
	Passenger	ONE19
	Rear	ONE15
<b>Aveo Hatchback</b>		
2007	Driver	ONE22
	Passenger	ONE19
	Rear	ONE15
<b>Aveo Sedan</b>		
2008-2007	Driver	ONE22
	Passenger	ONE18

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>CHEVROLET (cont.)</b>		
<b>Aveo5</b>		
2011-2009	Driver	ONE22
	Passenger	ONE18
	Rear	ONE15
2008-2006	Driver	ONE22
	Passenger	ONE19
	Rear	ONE15
<b>Bel Air</b>		
1981, 1975-1971	Driver	ONE18
	Passenger	ONE18
<b>Beretta</b>		
1996-1987	Driver	ONE19
	Passenger	ONE19
<b>Biscayne</b>		
1972-1971	Driver	ONE18
	Passenger	ONE18
1970-1968	Driver	ONE16
	Passenger	ONE16
<b>Blazer</b>		
2005-1995	Driver	ONE20
	Passenger	ONE20
	Rear	ONE14
1994-1992	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
1991-1987	Driver	ONE18
	Passenger	ONE18
<b>C1500</b>		
1999-1988	Driver	ONE18
	Passenger	ONE18
<b>C1500 Suburban</b>		
1999-1995	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14

<b>CHEVROLET (cont.)</b>		
<b>C1500 Suburban (cont.)</b>		
1994-1992	Driver	ONE18
	Passenger	ONE18
<b>C2500</b>		
2000-1988	Driver	ONE18
	Passenger	ONE18
<b>C2500 Suburban</b>		
1999-1995	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
1994-1992	Driver	ONE18
	Passenger	ONE18
<b>C3500</b>		
2004-2001	Driver	ONE22
	Passenger	ONE22
2000-1988	Driver	ONE18
	Passenger	ONE18
<b>C3500HD</b>		
2002-2001	Driver	ONE22
	Passenger	ONE22
2000-1995	Driver	ONE18
	Passenger	ONE18
<b>C4500 Kodiak</b>		
2008-2005	Driver	ONE22
	Passenger	ONE22
<b>C5500 Kodiak</b>		
2008-2005	Driver	ONE22
	Passenger	ONE22
<b>C6500 Kodiak</b>		
2008-2005	Driver	ONE22
	Passenger	ONE22
<b>C7500 Kodiak</b>		
2008-2005	Driver	ONE22
	Passenger	ONE22





## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>CHEVROLET (cont.)</b>		
<b>Camaro</b>		
2015-2010	Driver	ONE24
	Passenger	ONE21
2002-1998	Driver	ONE24
	Passenger	ONE24
1992-1989, 1981-1970	Driver	ONE18
	Passenger	ONE18
1988-1982	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>Caprice</b>		
2014-2011	Driver	ONE26
	Passenger	ONE15
1996-1991	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
1990	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
1989-1971	Driver	ONE18
	Passenger	ONE18
<b>Cavalier</b>		
2005-1995	Driver	ONE22
	Passenger	ONE17
1994-1990	Driver	ONE17
	Passenger	ONE17
1989	Driver	ONE16
	Passenger	ONE16
1988-1982	Driver	ONE16
	Passenger	ONE16
	Rear	ONE16
<b>Celebrity</b>		
1990	Driver	ONE18
	Passenger	ONE18

<b>CHEVROLET (cont.)</b>		
<b>Celebrity (cont.)</b>		
1989-1984	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>Chevelle</b>		
1973-1968	Driver	ONE16
	Passenger	ONE16
<b>Chevette</b>		
1987-1982	Driver	ONE16
	Passenger	ONE16
	Rear	ONE16
1981-1976	Rear	ONE16
<b>Citation</b>		
1983-1980	Driver	ONE18
	Passenger	ONE18
<b>Citation II</b>		
1985-1984	Driver	ONE18
	Passenger	ONE18
<b>Classic</b>		
2005-2004	Driver	ONE22
	Passenger	ONE19
<b>Cobalt</b>		
2010-2005	Driver	ONE22
	Passenger	ONE17
<b>Colorado</b>		
2015	Driver	ONE22
	Passenger	ONE18
2012-2004	Driver	ONE22
	Passenger	ONE19
<b>Corsica</b>		
1996-1987	Driver	ONE19
	Passenger	ONE19
<b>Corvette</b>		
2015-2014	Driver	ONE22
	Passenger	ONE20

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>CHEVROLET (cont.)</b>		
<b>Corvette (cont.)</b>		
2013-2005	Driver	ONE21
	Passenger	ONE21
2004-1997	Driver	ONE22
	Passenger	ONE22
1996-1984	Driver	ONE20
	Passenger	ONE20
1982-1968	Driver	ONE16
	Passenger	ONE16
<b>Cruze</b>		
2015-2011	Driver	ONE24
	Passenger	ONE18
<b>El Camino</b>		
1987-1978	Driver	ONE18
	Passenger	ONE18
1977-1968	Driver	ONE16
	Passenger	ONE16
<b>Epica</b>		
2006-2004	Driver	ONE22
	Passenger	ONE20
<b>Equinox</b>		
2015-2010	Driver	ONE24
	Passenger	ONE17
2009-2005	Driver	ONE24
	Passenger	ONE19
	Rear	ONE15
<b>Express 1500</b>		
2014-1996	Driver	ONE22
	Passenger	ONE22
<b>Express 2500</b>		
2015-1996	Driver	ONE22
	Passenger	ONE22
<b>Express 3500</b>		
2015-1996	Driver	ONE22
	Passenger	ONE22

<b>CHEVROLET (cont.)</b>		
<b>Express 4500</b>		
2015-2009	Driver	ONE22
	Passenger	ONE22
<b>Express Cargo</b>		
2015-2010	Driver	ONE22
	Passenger	ONE22
<b>Express Pasajeros</b>		
2014-2010	Driver	ONE22
	Passenger	ONE22
<b>G10</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>G20</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>G30</b>		
2002-2001, 1996	Driver	ONE22
	Passenger	ONE22
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>HHR</b>		
2011-2006	Driver	ONE18
	Passenger	ONE18
<b>Impala</b>		
2015-2014	Driver	ONE24
	Passenger	ONE19
2013-2011	Driver	ONE22
	Passenger	ONE21



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>CHEVROLET (cont.)</b>		
<b>Impala (cont.)</b>		
2010-2000, 1996-1994	Driver	ONE22
	Passenger	ONE22
1985-1971	Driver	ONE18
	Passenger	ONE18
<b>K1500</b>		
1999-1988	Driver	ONE18
	Passenger	ONE18
<b>K1500 Suburban</b>		
1999-1995	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
1994-1992	Driver	ONE18
	Passenger	ONE18
<b>K2500</b>		
2000-1988	Driver	ONE18
	Passenger	ONE18
<b>K2500 Suburban</b>		
1999-1995	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
1994-1992	Driver	ONE18
	Passenger	ONE18
<b>K3500</b>		
2000-1988	Driver	ONE18
	Passenger	ONE18
<b>Laguna</b>		
1976-1973	Driver	ONE16
	Passenger	ONE16
<b>Lumina</b>		
2001-1995	Driver	ONE22
	Passenger	ONE22
1994-1990	Driver	ONE20
	Passenger	ONE20

<b>CHEVROLET (cont.)</b>		
<b>Lumina APV</b>		
1996-1990	Driver	ONE22
	Passenger	ONE22
<b>Lumina Van</b>		
1996-1995	Driver	ONE22
	Passenger	ONE22
<b>Malibu</b>		
2015-2013	Driver	ONE24
	Passenger	ONE19
2012-2008	Driver	ONE24
	Passenger	ONE21
2007-2004	Driver	ONE22
	Passenger	ONE20
2003-1997	Driver	ONE22
	Passenger	ONE19
1983-1978	Driver	ONE18
	Passenger	ONE18
1977-1973	Driver	ONE16
	Passenger	ONE16
<b>Malibu Classic LS</b>		
2008	Driver	ONE22
	Passenger	ONE20
<b>Malibu Classic LT</b>		
2008	Driver	ONE22
	Passenger	ONE20
<b>Metro</b>		
2001-1998	Driver	ONE20
	Passenger	ONE19
1992	Driver	ONE20
	Passenger	ONE18
<b>Monte Carlo</b>		
2007-1995	Driver	ONE22
	Passenger	ONE22
1988-1978	Driver	ONE18
	Passenger	ONE18

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>CHEVROLET (cont.)</b>		
<b>Monte Carlo (cont.)</b>		
1977-1970	Driver	ONE16
	Passenger	ONE16
<b>Nova</b>		
1979-1969	Driver	ONE16
	Passenger	ONE16
<b>Optra</b>		
2007-2005	Driver	ONE22
	Passenger	ONE19
	Rear	ONE18
2004	Driver	ONE22
	Passenger	ONE19
<b>Prizm</b>		
2002-1998	Driver	ONE20
	Passenger	ONE18
<b>R10</b>		
1987	Driver	ONE16
	Passenger	ONE16
<b>R10 Suburban</b>		
1988-1987	Driver	ONE16
	Passenger	ONE16
<b>R1500 Suburban</b>		
1991-1989	Driver	ONE16
	Passenger	ONE16
<b>R20</b>		
1987	Driver	ONE16
	Passenger	ONE16
<b>R20 Suburban</b>		
1988-1987	Driver	ONE16
	Passenger	ONE16
<b>R2500</b>		
1989	Driver	ONE18
	Passenger	ONE18

<b>CHEVROLET (cont.)</b>		
<b>R2500 Suburban</b>		
1991-1989	Driver	ONE16
	Passenger	ONE16
<b>R30</b>		
1987	Driver	ONE16
	Passenger	ONE16
<b>R3500</b>		
1991-1989	Driver	ONE18
	Passenger	ONE18
<b>S10</b>		
2004-1994	Driver	ONE20
	Passenger	ONE20
1993-1982	Driver	ONE16
	Passenger	ONE16
<b>S10 Blazer</b>		
1994-1989	Driver	ONE16
	Passenger	ONE16
	Rear	ONE14
1988-1983	Driver	ONE16
	Passenger	ONE16
<b>SS</b>		
2015-2014	Driver	ONE26
	Passenger	ONE15
<b>SSR</b>		
2006-2003	Driver	ONE20
	Passenger	ONE19
<b>Silverado</b>		
1999	Driver	ONE22
	Passenger	ONE22
<b>Silverado 1500</b>		
2015-1999	Driver	ONE22
	Passenger	ONE22
<b>Silverado 1500 HD</b>		
2007-2005, 2003-2001	Driver	ONE22
	Passenger	ONE22



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>CHEVROLET (cont.)</b>		
<b>Silverado 2500</b>		
2014-2011, 2009-1999	Driver	ONE22
	Passenger	ONE22
<b>Silverado 2500 HD</b>		
2015-2001	Driver	ONE22
	Passenger	ONE22
<b>Silverado 3500</b>		
2015, 2013- 2011, 2009- 2001	Driver	ONE22
	Passenger	ONE22
<b>Silverado 3500 HD</b>		
2015-2007	Driver	ONE22
	Passenger	ONE22
<b>Sonic</b>		
2015-2012	Driver	ONE26
	Passenger	ONE15
<b>Spark</b>		
2015-2012	Driver	ONE24
	Passenger	ONE16
<b>Spark EV</b>		
2015-2014	Driver	ONE24
	Passenger	ONE16
<b>Spectrum</b>		
1988	Driver	ONE18
	Passenger	ONE18
<b>Sprint</b>		
1992-1989	Driver	ONE19
	Passenger	ONE18
<b>Suburban</b>		
2015-2014	Driver	ONE22
	Passenger	ONE22
<b>Suburban 1500</b>		
2014-2007	Driver	ONE22
	Passenger	ONE22

<b>CHEVROLET (cont.)</b>		
<b>Suburban 1500 (cont.)</b>		
2006-2000	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
1999-1995	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
<b>Suburban 2500</b>		
2013-2007	Driver	ONE22
	Passenger	ONE22
2006-2000	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>Tahoe</b>		
2015-2007	Driver	ONE22
	Passenger	ONE22
2006-2000	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
1999-1995	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
<b>Tracker</b>		
2004-1999	Driver	ONE19
	Passenger	ONE19
	Rear	ONE15
1998	Driver	ONE17
	Passenger	ONE17
	Rear	ONE15
<b>Trailblazer</b>		
2009-2007	Driver	ONE22
	Passenger	ONE22
2006-2002	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>CHEVROLET (cont.)</b>		
<b>Trailblazer EXT</b>		
2006-2002	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>Traverse</b>		
2015-2009	Driver	ONE24
	Passenger	ONE21
<b>Trax</b>		
2015	Driver	ONE26
	Passenger	ONE14
<b>Uplander</b>		
2009-2005	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16
<b>V10</b>		
1987	Driver	ONE16
	Passenger	ONE16
<b>V10 Suburban</b>		
1988-1987	Driver	ONE16
	Passenger	ONE16
<b>V1500 Suburban</b>		
1991-1989	Driver	ONE16
	Passenger	ONE16
<b>V20</b>		
1987	Driver	ONE16
	Passenger	ONE16
<b>V20 Suburban</b>		
1988-1987	Driver	ONE16
	Passenger	ONE16
<b>V2500 Suburban</b>		
1991-1989	Driver	ONE16
	Passenger	ONE16
<b>V30</b>		
1987	Driver	ONE16
	Passenger	ONE16

<b>CHEVROLET (cont.)</b>		
<b>V3500</b>		
1991-1989	Driver	ONE18
	Passenger	ONE18
<b>Venture</b>		
2005-1997	Driver	ONE24
	Passenger	ONE24
	Rear	ONE16
<b>Volt</b>		
2015-2011	Driver	ONE26
	Passenger	ONE26
<b>W3500 Tiltmaster</b>		
2008-2005	Driver	ONE20
	Passenger	ONE20
<b>W4500 Tiltmaster</b>		
2008-2005	Driver	ONE20
	Passenger	ONE20
<b>W5500 Tiltmaster</b>		
2008-2005	Driver	ONE20
	Passenger	ONE20
<b>W5500HD Tiltmaster</b>		
2008-2005	Driver	ONE20
	Passenger	ONE20
<b>CHRYSLER</b>		
<b>200</b>		
2015	Driver	ONE26
	Passenger	ONE19
2014-2011	Driver	ONE24
	Passenger	ONE22
<b>300</b>		
2015-2011	Driver	ONE24
	Passenger	ONE21
2010-2005	Driver	ONE22
	Passenger	ONE22
1971-1970	Driver	ONE16
	Passenger	ONE16



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>CHRYSLER (cont.)</b>		
<b>300C</b>		
2014	Driver	ONE24
	Passenger	ONE21
<b>300M</b>		
2004-1998	Driver	ONE24
	Passenger	ONE22
<b>Aspen</b>		
2009-2007	Driver	ONE26
	Passenger	ONE21
<b>Cirrus</b>		
2000-1995	Driver	ONE22
	Passenger	ONE22
<b>Concorde</b>		
2004-1997, 1994-1993	Driver	ONE24
	Passenger	ONE22
1996-1995	Driver	ONE24
	Passenger	ONE24
<b>Cordoba</b>		
1983-1975	Driver	ONE18
	Passenger	ONE18
<b>Crossfire</b>		
2008-2004	Driver	ONE20
	Passenger	ONE22
<b>Daytona</b>		
1993-1984	Driver	ONE18
	Passenger	ONE18
<b>Dynasty</b>		
1993-1988	Driver	ONE18
	Passenger	ONE18
<b>E Class</b>		
1984-1983	Driver	ONE16
	Passenger	ONE16
<b>Fifth Avenue</b>		
1989-1983	Driver	ONE18
	Passenger	ONE18

<b>CHRYSLER (cont.)</b>		
<b>Grand Voyager</b>		
2000	Driver	ONE28
	Passenger	ONE28
	Rear	ONE18
<b>Imperial</b>		
1993-1990, 1983-1981, 1975-1974	Driver	ONE18
	Passenger	ONE18
1973-1969	Driver	ONE16
	Passenger	ONE16
<b>Intrepid</b>		
2004-1993	Driver	ONE24
	Passenger	ONE22
<b>LHS</b>		
2001-1999, 1997, 1994	Driver	ONE24
	Passenger	ONE22
1996-1995	Driver	ONE24
	Passenger	ONE24
<b>Laser</b>		
1986-1984	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>LeBaron</b>		
1995-1994	Driver	ONE20
	Passenger	ONE20
1993-1989, 1979-1977	Driver	ONE18
	Passenger	ONE18
1986-1982	Driver	ONE16
	Passenger	ONE16
1981-1980	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>LeBaron Convertible</b>		
1988-1987	Driver	ONE18
	Passenger	ONE18

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>CHRYSLER (cont.)</b>		
<b>LeBaron Coupe</b>		
1988-1987	Driver	ONE18
	Passenger	ONE18
<b>LeBaron GTS</b>		
1989-1985	Driver	ONE18
	Passenger	ONE18
<b>LeBaron Sedan</b>		
1988-1987	Driver	ONE16
	Passenger	ONE16
<b>Neon</b>		
2002-2000	Driver	ONE22
	Passenger	ONE19
1997-1995	Driver	ONE21
	Passenger	ONE18
<b>New Yorker</b>		
1996-1995	Driver	ONE24
	Passenger	ONE24
1994	Driver	ONE24
	Passenger	ONE22
1993-1988, 1982-1974	Driver	ONE18
	Passenger	ONE18
1987-1983, 1973-1969	Driver	ONE16
	Passenger	ONE16
<b>Newport</b>		
1981-1974	Driver	ONE18
	Passenger	ONE18
1973-1969	Driver	ONE16
	Passenger	ONE16
<b>PT Cruiser</b>		
2010-2001	Driver	ONE20
	Passenger	ONE21
	Rear	ONE16

<b>CHRYSLER (cont.)</b>		
<b>Pacifica</b>		
2008-2004	Driver	ONE22
	Passenger	ONE22
	Rear	ONE14
<b>Prowler</b>		
2002-2001	Driver	ONE17
	Passenger	ONE19
<b>Sebring</b>		
2010-2007, 1995	Driver	ONE24
	Passenger	ONE22
2006, 2000- 1997	Driver	ONE22
	Passenger	ONE22
<b>Sebring Convertible</b>		
2005-2001	Driver	ONE22
	Passenger	ONE22
1996	Driver	ONE21
	Passenger	ONE21
<b>Sebring Coupe</b>		
2005-2001	Driver	ONE24
	Passenger	ONE21
2000-1996	Driver	ONE24
	Passenger	ONE22
<b>Sebring Sedan</b>		
2005-2001	Driver	ONE22
	Passenger	ONE22
<b>TC Maserati</b>		
1991-1989	Driver	ONE18
	Passenger	ONE18
<b>Town &amp; Country</b>		
2015-2011	Driver	ONE26
	Passenger	ONE20
	Rear	ONE16
2010-2008	Driver	ONE26
	Passenger	ONE20





## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>CHRYSLER (cont.)</b>		
<b>Town &amp; Country (cont.)</b>		
2007-2001	Driver	ONE28
	Passenger	ONE28
	Rear	ONE16
2000-1996	Driver	ONE28
	Passenger	ONE28
	Rear	ONE18
1995	Driver	ONE22
	Passenger	ONE22
	Rear	ONE18
1994	Driver	ONE22
	Passenger	ONE18
	Rear	ONE18
1993-1991	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
1990	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
1988-1981	Driver	ONE16
	Passenger	ONE16
<b>Voyager</b>		
2008-2001	Driver	ONE28
	Passenger	ONE28
	Rear	ONE16
2000	Driver	ONE28
	Passenger	ONE28
	Rear	ONE18
<b>DAEWOO</b>		
<b>Lanos</b>		
2002-1999	Driver	ONE19
	Passenger	ONE19
	Rear	ONE19

<b>DAEWOO (cont.)</b>		
<b>Leganza</b>		
2002-1999	Driver	ONE22
	Passenger	ONE19
<b>Nubira</b>		
2002-1999	Driver	ONE20
	Passenger	ONE20
<b>Nubira Hatchback</b>		
1999	Rear	ONE18
<b>Nubira Sedan</b>		
2002-1999	Rear	ONE15
<b>Nubira Wagon</b>		
2002-1999	Rear	ONE15
<b>DODGE</b>		
<b>400</b>		
1983-1982	Driver	ONE16
	Passenger	ONE16
<b>600</b>		
1988-1983	Driver	ONE16
	Passenger	ONE16
<b>Aries</b>		
1989-1981	Driver	ONE16
	Passenger	ONE16
<b>Aspen</b>		
1980-1976	Rear	ONE16
<b>Avenger</b>		
2014-2008, 2000-1995	Driver	ONE24
	Passenger	ONE22
<b>B2500</b>		
1998-1995	Driver	ONE18
	Passenger	ONE18
<b>Caliber</b>		
2012-2007	Driver	ONE24
	Passenger	ONE17

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>DODGE (cont.)</b>		
<b>Caravan</b>		
2007-2001	Driver	ONE28
	Passenger	ONE28
	Rear	ONE16
2000-1996	Driver	ONE28
	Passenger	ONE28
	Rear	ONE18
1995	Driver	ONE22
	Passenger	ONE22
	Rear	ONE18
1994	Driver	ONE22
	Passenger	ONE18
	Rear	ONE18
1993-1991	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
1990-1984	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>Challenger</b>		
2015-2008	Driver	ONE22
	Passenger	ONE22
1974-1970	Driver	ONE16
	Passenger	ONE16
<b>Charger</b>		
2015-2011	Driver	ONE24
	Passenger	ONE21
2010-2006	Driver	ONE22
	Passenger	ONE22
1978-1975	Driver	ONE18
	Passenger	ONE18
1974-1971	Driver	ONE16
	Passenger	ONE16

<b>DODGE (cont.)</b>		
<b>Colt</b>		
1995-1993	Driver	ONE20
	Passenger	ONE19
1992-1991	Driver	ONE20
	Passenger	ONE17
<b>Coronet</b>		
1976-1975	Driver	ONE18
	Passenger	ONE18
1974-1971	Driver	ONE16
	Passenger	ONE16
<b>Dakota</b>		
2010-2002	Driver	ONE21
	Passenger	ONE21
2001-1997	Driver	ONE20
	Passenger	ONE20
1996-1987	Driver	ONE18
	Passenger	ONE18
<b>Dart</b>		
2015-2013	Driver	ONE26
	Passenger	ONE18
<b>Daytona</b>		
1989-1985	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>Diplomat</b>		
1989-1977	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>Durango</b>		
2015-2011	Driver	ONE22
	Passenger	ONE21
2009-2004	Driver	ONE26
	Passenger	ONE20
2003-2002	Driver	ONE21
	Passenger	ONE21



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>DODGE (cont.)</b>		
<b>Durango (cont.)</b>		
2001-1998	Driver	ONE20
	Passenger	ONE20
	Rear	ONE16
<b>Dynasty</b>		
1993-1988	Driver	ONE18
	Passenger	ONE18
<b>Grand Caravan</b>		
2015-2011	Driver	ONE26
	Passenger	ONE20
	Rear	ONE16
2010-2008	Driver	ONE26
	Passenger	ONE20
2007-2001	Driver	ONE28
	Passenger	ONE28
	Rear	ONE16
2000-1996	Driver	ONE28
	Passenger	ONE28
	Rear	ONE18
1995	Driver	ONE22
	Passenger	ONE22
	Rear	ONE18
1994	Driver	ONE22
	Passenger	ONE18
	Rear	ONE18
1993-1991	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
1990-1987	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>Intrepid</b>		
2004-1997, 1994-1993	Driver	ONE24
	Passenger	ONE22

<b>DODGE (cont.)</b>		
<b>Intrepid (cont.)</b>		
1996-1995	Driver	ONE24
	Passenger	ONE24
<b>Journey</b>		
2015-2009	Driver	ONE24
	Passenger	ONE19
<b>Lancer</b>		
1989-1985	Driver	ONE18
	Passenger	ONE18
<b>Magnum</b>		
2008-2005	Driver	ONE22
	Passenger	ONE22
1979-1978	Driver	ONE18
	Passenger	ONE18
<b>Mini Ram</b>		
1988-1984	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>Mirada</b>		
1983-1980	Driver	ONE18
	Passenger	ONE18
<b>Monaco</b>		
1992-1990	Driver	ONE20
	Passenger	ONE20
1978-1974	Driver	ONE18
	Passenger	ONE18
1973-1969	Driver	ONE16
	Passenger	ONE16
<b>Neon</b>		
2005-2000	Driver	ONE22
	Passenger	ONE19
1999-1995	Driver	ONE21
	Passenger	ONE18

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>DODGE (cont.)</b>		
<b>Nitro</b>		
2012-2007	Driver	ONE19
	Passenger	ONE19
<b>Polara</b>		
1973-1969	Driver	ONE16
	Passenger	ONE16
<b>Ram 1500</b>		
2010-2009	Driver	ONE22
	Passenger	ONE22
2008-2002	Driver	ONE24
	Passenger	ONE24
2001-1994	Driver	ONE20
	Passenger	ONE20
<b>Ram 1500 Van</b>		
2003-1999	Driver	ONE19
	Passenger	ONE19
1998-1995	Driver	ONE18
	Passenger	ONE18
<b>Ram 2500</b>		
2010	Driver	ONE22
	Passenger	ONE22
2009-2002	Driver	ONE24
	Passenger	ONE24
2001-1994	Driver	ONE20
	Passenger	ONE20
<b>Ram 2500 Van</b>		
2003-1999	Driver	ONE19
	Passenger	ONE19
1998-1996	Driver	ONE18
	Passenger	ONE18
<b>Ram 3500</b>		
2010	Driver	ONE22
	Passenger	ONE22
2009-2002	Driver	ONE24
	Passenger	ONE24

<b>DODGE (cont.)</b>		
<b>Ram 3500 (cont.)</b>		
2001-1994	Driver	ONE20
	Passenger	ONE20
<b>Ram 3500 Van</b>		
2003-1999	Driver	ONE19
	Passenger	ONE19
1997-1996	Driver	ONE18
	Passenger	ONE18
<b>Ram 4500</b>		
2010-2009	Driver	ONE22
	Passenger	ONE22
2008	Driver	ONE24
	Passenger	ONE24
<b>Ram 5500</b>		
2010-2009	Driver	ONE22
	Passenger	ONE22
2008	Driver	ONE24
	Passenger	ONE24
<b>Ramcharger</b>		
1993-1974	Driver	ONE18
	Passenger	ONE18
<b>SX 2.0</b>		
2005-2003	Driver	ONE22
	Passenger	ONE19
<b>Shadow</b>		
1994-1987	Driver	ONE18
	Passenger	ONE18
<b>Spirit</b>		
1995-1989	Driver	ONE18
	Passenger	ONE18
<b>Sprinter 2500</b>		
2009-2007	Driver	ONE26
	Passenger	ONE24
2006-2003	Driver	ONE24
	Passenger	ONE22



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>DODGE (cont.)</b>		
<b>Sprinter 3500</b>		
2009-2007	Driver	ONE26
	Passenger	ONE24
2006-2003	Driver	ONE24
	Passenger	ONE22
<b>St. Regis</b>		
1981-1979	Driver	ONE18
	Passenger	ONE18
<b>Stealth</b>		
1996-1991	Driver	ONE21
	Passenger	ONE20
<b>Stratus Coupe</b>		
2005-2001	Driver	ONE24
	Passenger	ONE21
<b>Stratus Sedan</b>		
2006-1995	Driver	ONE22
	Passenger	ONE22
<b>Viper</b>		
2002-1992	Driver	ONE16
	Passenger	ONE16
<b>EAGLE</b>		
<b>Medallion</b>		
1989-1988	Driver	ONE20
	Passenger	ONE20
	Rear	ONE18
<b>Premier</b>		
1992-1988	Driver	ONE20
	Passenger	ONE20
<b>Summit Coupe</b>		
1996-1993	Driver	ONE20
	Passenger	ONE19
<b>Summit Hatchback</b>		
1992-1991	Driver	ONE20
	Passenger	ONE17

<b>EAGLE (cont.)</b>		
<b>Summit Sedan</b>		
1996-1993	Driver	ONE20
	Passenger	ONE19
1992-1991	Driver	ONE20
	Passenger	ONE17
<b>Summit Wagon</b>		
1996-1992	Driver	ONE22
	Passenger	ONE18
	Rear	ONE16
<b>Talon</b>		
1998-1997	Driver	ONE24
	Passenger	ONE22
	Rear	ONE18
1996-1995	Driver	ONE24
	Passenger	ONE22
	Rear	ONE19
1994-1992	Driver	ONE20
	Passenger	ONE20
<b>Vision</b>		
1997-1995	Driver	ONE24
	Passenger	ONE24
1993	Driver	ONE24
	Passenger	ONE22
<b>FERRARI</b>		
<b>348 Spider</b>		
1995	Driver	ONE20
	Passenger	ONE20
<b>512 M</b>		
1995	Driver	ONE20
	Passenger	ONE20
<b>F355</b>		
1999	Driver	ONE21
	Passenger	ONE20

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>FERRARI (cont.)</b>		
<b>F355 Berlinetta</b>		
1996-1994	Driver	ONE21
	Passenger	ONE20
<b>F355 F1</b>		
1998	Driver	ONE21
	Passenger	ONE20
<b>F355 GTS</b>		
1998-1994	Driver	ONE21
	Passenger	ONE20
<b>F355 Spider</b>		
1999-1996	Driver	ONE21
	Passenger	ONE20
<b>Mondial</b>		
1985-1983	Driver	ONE20
	Passenger	ONE20
<b>Mondial 3.2</b>		
1988-1986	Driver	ONE20
	Passenger	ONE20
<b>Mondial 8</b>		
1985-1980	Driver	ONE20
	Passenger	ONE20
<b>Mondial t</b>		
1993-1989	Driver	ONE20
	Passenger	ONE20
<b>Testarossa</b>		
1988-1985	Driver	ONE20
	Passenger	ONE20
<b>FIAT</b>		
<b>500</b>		
2015-2010	Driver	ONE24
	Passenger	ONE14
<b>500L</b>		
2015-2014	Driver	ONE26
	Passenger	ONE15

<b>FORD</b>		
<b>Aerostar</b>		
1997-1986	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>Aspire</b>		
1997-1994	Driver	ONE20
	Passenger	ONE16
<b>Bronco</b>		
1996-1980	Driver	ONE18
	Passenger	ONE18
<b>C-Max</b>		
2015-2013	Driver	ONE28
	Passenger	ONE24
<b>Contour</b>		
2000-1995	Driver	ONE22
	Passenger	ONE20
<b>Crown Victoria</b>		
2011-1992	Driver	ONE22
	Passenger	ONE22
<b>Custom</b>		
1972-1971	Driver	ONE18
	Passenger	ONE18
<b>Custom 500</b>		
1977-1971	Driver	ONE18
	Passenger	ONE18
<b>E-100 Econoline</b>		
1983-1982	Driver	ONE18
	Passenger	ONE18
1981-1975	Driver	ONE20
	Passenger	ONE20
<b>E-100 Econoline Club Wagon</b>		
1983-1982	Driver	ONE18
	Passenger	ONE18
1981-1975	Driver	ONE20
	Passenger	ONE20



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>FORD (cont.)</b>		
<b>E-150</b>		
2014-2003	Driver	ONE20
	Passenger	ONE20
<b>E-150 Club Wagon</b>		
2005-2003	Driver	ONE20
	Passenger	ONE20
<b>E-150 Econoline Club Wagon</b>		
2002-1998	Driver	ONE20
	Passenger	ONE20
1997-1992	Driver	ONE22
	Passenger	ONE22
1991-1982	Driver	ONE18
	Passenger	ONE18
<b>E-250</b>		
2014-2003	Driver	ONE20
	Passenger	ONE20
<b>E-250 Econoline</b>		
2002-1998	Driver	ONE20
	Passenger	ONE20
1997-1992	Driver	ONE22
	Passenger	ONE22
1991-1981	Driver	ONE18
	Passenger	ONE18
<b>E-250 Econoline Club Wagon</b>		
1991-1981	Driver	ONE18
	Passenger	ONE18
<b>E-250 Super Duty</b>		
2005-2004	Driver	ONE20
	Passenger	ONE20
<b>E-350</b>		
2003	Driver	ONE20
	Passenger	ONE20
<b>E-350 Club Wagon</b>		
2005-2003	Driver	ONE20
	Passenger	ONE20

<b>FORD (cont.)</b>		
<b>E-350 Econoline</b>		
2008-2007, 2002-1998	Driver	ONE20
	Passenger	ONE20
1997-1991	Driver	ONE22
	Passenger	ONE22
<b>E-350 Econoline Club Wagon</b>		
2002-1998	Driver	ONE20
	Passenger	ONE20
1997-1992	Driver	ONE22
	Passenger	ONE22
1991-1982	Driver	ONE19
	Passenger	ONE19
<b>E-350 Super Duty</b>		
2014-2004	Driver	ONE20
	Passenger	ONE20
<b>E-550 Econoline Super Duty</b>		
2002	Driver	ONE20
	Passenger	ONE20
<b>E-550 Super Duty</b>		
2003	Driver	ONE20
	Passenger	ONE20
<b>EXP</b>		
1988-1982	Driver	ONE18
	Passenger	ONE18
<b>Econoline</b>		
2006-1999	Driver	ONE20
	Passenger	ONE20
<b>Econoline Super Duty</b>		
1999-1998	Driver	ONE20
	Passenger	ONE20
1997-1996	Driver	ONE22
	Passenger	ONE22
<b>Econoline Van</b>		
2014-2010	Driver	ONE20
	Passenger	ONE20

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>FORD (cont.)</b>		
<b>Econoline Wagon</b>		
2014-2010	Driver	ONE20
	Passenger	ONE20
<b>Edge</b>		
2015	Driver	ONE28
	Passenger	ONE28
2014-2007	Driver	ONE26
	Passenger	ONE20
<b>Elite</b>		
1976-1975	Driver	ONE16
	Passenger	ONE16
<b>Escape</b>		
2015-2013	Driver	ONE28
	Passenger	ONE28
2012-2008	Driver	ONE20
	Passenger	ONE20
2007-2004	Driver	ONE20
	Passenger	ONE18
2003-2001	Driver	ONE19
	Passenger	ONE19
<b>Escort</b>		
2003-1994	Driver	ONE20
	Passenger	ONE18
1993-1991	Driver	ONE20
	Passenger	ONE18
	Rear	ONE14
1990-1981	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>Escort Wagon</b>		
1990	Rear	ONE14
1989-1986	Rear	ONE16

<b>FORD (cont.)</b>		
<b>Excursion</b>		
2005-2000	Driver	ONE20
	Passenger	ONE20
	Rear	ONE16
<b>Expedition</b>		
2015-2009	Driver	ONE22
	Passenger	ONE22
2008, 1998-1997	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
2007-2003	Driver	ONE20
	Passenger	ONE20
	Rear	ONE17
2002-1999	Driver	ONE20
	Passenger	ONE20
	Rear	ONE16
<b>Explorer</b>		
2015-2011	Driver	ONE26
	Passenger	ONE22
2010-2006	Driver	ONE20
	Passenger	ONE20
2005	Driver	ONE20
	Passenger	ONE20
	Rear	ONE16
2004-2002	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
2001-1991	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
<b>Explorer Sport</b>		
2003-2002	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14





## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>FORD (cont.)</b>		
<b>Explorer Sport Trac</b>		
2010-2007	Driver	ONE20
	Passenger	ONE20
2005-2001	Driver	ONE18
	Passenger	ONE18
<b>Explorer Sport XLS</b>		
2003	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
<b>Explorer Sport XLT</b>		
2003	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
<b>F-150</b>		
2015-2009, 1998-1997	Driver	ONE22
	Passenger	ONE22
2008-1999	Driver	ONE20
	Passenger	ONE20
1996-1980	Driver	ONE18
	Passenger	ONE18
<b>F-150 Heritage</b>		
2004	Driver	ONE20
	Passenger	ONE20
<b>F-250</b>		
2015-2009, 1998-1997	Driver	ONE22
	Passenger	ONE22
2008-1999	Driver	ONE20
	Passenger	ONE20
1996-1980	Driver	ONE18
	Passenger	ONE18
<b>F-250 Super Duty</b>		
2015-2009	Driver	ONE22
	Passenger	ONE22
2008-1999	Driver	ONE20
	Passenger	ONE20

<b>FORD (cont.)</b>		
<b>F-350</b>		
2015-2011, 2009, 1998- 1997	Driver	ONE22
	Passenger	ONE22
2008-1999	Driver	ONE20
	Passenger	ONE20
1996-1980	Driver	ONE18
	Passenger	ONE18
<b>F-350 Super Duty</b>		
2015-2009	Driver	ONE22
	Passenger	ONE22
2008-1999	Driver	ONE20
	Passenger	ONE20
<b>F-450</b>		
2015-2011, 2009, 1998- 1997	Driver	ONE22
	Passenger	ONE22
2008-1999	Driver	ONE20
	Passenger	ONE20
<b>F-450 Super Duty</b>		
2015-2009, 1997	Driver	ONE22
	Passenger	ONE22
2008-1999	Driver	ONE20
	Passenger	ONE20
<b>F-550</b>		
2015-2010	Driver	ONE22
	Passenger	ONE22
<b>F-550 Super Duty</b>		
2015-2009	Driver	ONE22
	Passenger	ONE22
2008-1999	Driver	ONE20
	Passenger	ONE20
<b>Fairlane</b>		
1970	Driver	ONE16
	Passenger	ONE16

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>FORD (cont.)</b>		
<b>Fairmont</b>		
1983-1978	Driver	ONE16
	Passenger	ONE16
	Rear	ONE16
<b>Festiva</b>		
1993-1989	Driver	ONE18
	Passenger	ONE18
	Rear	ONE15
<b>Fiesta</b>		
2015-2011	Driver	ONE24
	Passenger	ONE16
<b>Five Hundred</b>		
2007-2005	Driver	ONE24
	Passenger	ONE20
<b>Flex</b>		
2015-2009	Driver	ONE24
	Passenger	ONE22
<b>Focus</b>		
2015-2012	Driver	ONE28
	Passenger	ONE28
2011-2000	Driver	ONE22
	Passenger	ONE19
<b>Focus Hatchback</b>		
2007-2000	Driver	ONE22
	Passenger	ONE19
	Rear	ONE15
<b>Focus Wagon</b>		
2007-2000	Driver	ONE22
	Passenger	ONE19
<b>Freestar</b>		
2007-2004	Driver	ONE24
	Passenger	ONE20
	Rear	ONE16

<b>FORD (cont.)</b>		
<b>Freestyle</b>		
2007-2005	Driver	ONE24
	Passenger	ONE20
<b>Fusion</b>		
2015-2013	Driver	ONE28
	Passenger	ONE28
2012-2006	Driver	ONE24
	Passenger	ONE19
<b>Galaxie 500</b>		
1974-1970	Driver	ONE18
	Passenger	ONE18
<b>Granada</b>		
1982-1975	Driver	ONE16
	Passenger	ONE16
<b>Grand Marquis</b>		
2004-2000	Driver	ONE22
	Passenger	ONE22
<b>LTD</b>		
1986, 1983-1970	Driver	ONE18
	Passenger	ONE18
1985-1984	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>LTD II</b>		
1979-1977	Driver	ONE16
	Passenger	ONE16
<b>Maverick</b>		
1977-1969	Driver	ONE16
	Passenger	ONE16
<b>Mustang</b>		
2015-2005	Driver	ONE22
	Passenger	ONE20
2004-1994	Driver	ONE20
	Passenger	ONE20



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>FORD (cont.)</b>		
<b>Mustang (cont.)</b>		
1993-1983, 1970-1969	Driver	ONE16
	Passenger	ONE16
1982-1979	Driver	ONE16
	Passenger	ONE16
	Rear	ONE18
1973-1971	Driver	ONE18
	Passenger	ONE18
<b>Mustang Shelby</b>		
2009-2008	Driver	ONE22
	Passenger	ONE20
<b>Mustang Shelby GT</b>		
2008-2007	Driver	ONE22
	Passenger	ONE20
<b>Mustang Shelby GT500</b>		
2009-2007	Driver	ONE22
	Passenger	ONE20
<b>Mustang Shelby GT500KR</b>		
2009-2008	Driver	ONE22
	Passenger	ONE20
<b>Mystique</b>		
2000-1995	Driver	ONE22
	Passenger	ONE20
<b>Pinto</b>		
1980-1971	Driver	ONE16
	Passenger	ONE16
<b>Police Interceptor Utility</b>		
2015-2013	Driver	ONE26
	Passenger	ONE22
<b>Probe</b>		
1997-1993	Driver	ONE20
	Passenger	ONE20
	Rear	ONE20

<b>FORD (cont.)</b>		
<b>Ranchero</b>		
1979-1966	Driver	ONE16
	Passenger	ONE16
<b>Ranger</b>		
2011-1983	Driver	ONE18
	Passenger	ONE18
<b>Sable</b>		
2001-1996	Driver	ONE24
	Passenger	ONE20
	Rear	ONE18
1995	Driver	ONE20
	Passenger	ONE20
	Rear	ONE15
<b>Taurus</b>		
2015-2010	Driver	ONE26
	Passenger	ONE20
2009-2005	Driver	ONE24
	Passenger	ONE20
2004-1996	Driver	ONE24
	Passenger	ONE20
	Rear	ONE16
1995-1986	Driver	ONE20
	Passenger	ONE20
	Rear	ONE15
<b>Taurus X</b>		
2009-2008	Driver	ONE24
	Passenger	ONE20
<b>Tempo</b>		
1994-1986	Driver	ONE20
	Passenger	ONE20
1985	Driver	ONE19
	Passenger	ONE19
1984	Driver	ONE18
	Passenger	ONE18

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>FORD (cont.)</b>		
<b>Thunderbird</b>		
2005-2002	Driver	ONE24
	Passenger	ONE22
1997-1990	Driver	ONE22
	Passenger	ONE22
1989	Driver	ONE22
	Passenger	ONE20
1988-1983, 1976-1972	Driver	ONE18
	Passenger	ONE18
1982-1977, 1971-1967	Driver	ONE16
	Passenger	ONE16
<b>Torino</b>		
1976-1968	Driver	ONE16
	Passenger	ONE16
<b>Transit</b>		
2015	Driver	ONE26
	Passenger	ONE21
2014	Driver	ONE28
	Passenger	ONE21
<b>Transit Connect</b>		
2015-2014	Driver	ONE28
	Passenger	ONE28
2013-2010	Driver	ONE26
	Passenger	ONE18
	Rear	ONE14
<b>Windstar</b>		
2003-1996	Driver	ONE24
	Passenger	ONE20
	Rear	ONE16
1995	Driver	ONE24
	Passenger	ONE20
	Rear	ONE14

<b>FREIGHTLINER</b>		
<b>Sprinter 2500</b>		
2014-2007	Driver	ONE26
	Passenger	ONE24
2006-2002	Driver	ONE24
	Passenger	ONE22
<b>Sprinter 3500</b>		
2014-2007	Driver	ONE26
	Passenger	ONE24
2006-2002	Driver	ONE24
	Passenger	ONE22
<b>GMC</b>		
<b>Acadia</b>		
2015-2007	Driver	ONE24
	Passenger	ONE21
<b>C1500</b>		
1999-1988	Driver	ONE18
	Passenger	ONE18
1986-1983	Driver	ONE16
	Passenger	ONE16
<b>C1500 Suburban</b>		
1999-1995	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
1994-1992	Driver	ONE18
	Passenger	ONE18
<b>C2500</b>		
2000-1988	Driver	ONE18
	Passenger	ONE18
1986-1983	Driver	ONE16
	Passenger	ONE16
<b>C2500 Suburban</b>		
1999-1995	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>GMC (cont.)</b>		
<b>C2500 Suburban (cont.)</b>		
1994-1992	Driver	ONE18
	Passenger	ONE18
<b>C3500</b>		
2000-1988	Driver	ONE18
	Passenger	ONE18
1986-1983	Driver	ONE16
	Passenger	ONE16
<b>C3500HD</b>		
2002-2001	Driver	ONE22
	Passenger	ONE22
2000-1991	Driver	ONE18
	Passenger	ONE18
<b>C4500 Topkick</b>		
2008-2004	Driver	ONE22
	Passenger	ONE22
<b>C5500 Topkick</b>		
2008-2004	Driver	ONE22
	Passenger	ONE22
<b>C6500 Topkick</b>		
2008-2004	Driver	ONE22
	Passenger	ONE22
<b>C7500 Topkick</b>		
2008-2004	Driver	ONE22
	Passenger	ONE22
<b>Caballero</b>		
1987-1978	Driver	ONE18
	Passenger	ONE18
<b>Canyon</b>		
2015	Driver	ONE22
	Passenger	ONE18
2012-2004	Driver	ONE22
	Passenger	ONE19

<b>GMC (cont.)</b>		
<b>Envoy</b>		
2009-2007	Driver	ONE22
	Passenger	ONE22
2006-2002	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>Envoy XL</b>		
2006-2002	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>Envoy XUV</b>		
2005-2004	Driver	ONE22
	Passenger	ONE22
<b>G1500 Rally</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>G1500 Rally Custom</b>		
1984-1983	Driver	ONE16
	Passenger	ONE16
<b>G1500 Rally STX</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>G1500 Vandura</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>G2500 Rally</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>GMC (cont.)</b>		
<b>G2500 Rally (cont.)</b>		
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>G2500 Rally Custom</b>		
1984-1983	Driver	ONE16
	Passenger	ONE16
<b>G2500 Rally STX</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>G2500 Vandura</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>G3500 Rally</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>G3500 Rally Camper Special</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>G3500 Rally Custom</b>		
1984-1983	Driver	ONE16
	Passenger	ONE16
<b>G3500 Rally STX</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16

<b>GMC (cont.)</b>		
<b>G3500 Vandura</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>G3500 Vandura Special</b>		
1995-1993	Driver	ONE18
	Passenger	ONE18
1992-1983	Driver	ONE16
	Passenger	ONE16
<b>Jimmy</b>		
2005-1995	Driver	ONE20
	Passenger	ONE20
	Rear	ONE14
1994-1989	Driver	ONE16
	Passenger	ONE16
	Rear	ONE14
1988-1983	Driver	ONE16
	Passenger	ONE16
<b>K1500</b>		
1999-1988	Driver	ONE18
	Passenger	ONE18
1986-1983	Driver	ONE16
	Passenger	ONE16
<b>K1500 Suburban</b>		
1999-1995	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
1994-1992	Driver	ONE18
	Passenger	ONE18
<b>K2500</b>		
2000-1988	Driver	ONE18
	Passenger	ONE18
1986-1983	Driver	ONE16
	Passenger	ONE16



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>GMC (cont.)</b>		
<b>K2500 Suburban</b>		
1999-1995	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
1994-1992	Driver	ONE18
	Passenger	ONE18
<b>K3500</b>		
2000-1988	Driver	ONE18
	Passenger	ONE18
1986-1983	Driver	ONE16
	Passenger	ONE16
<b>P3500</b>		
1999-1991	Driver	ONE18
	Passenger	ONE18
<b>R1500</b>		
1987	Driver	ONE16
	Passenger	ONE16
<b>R1500 Suburban</b>		
1991-1987	Driver	ONE16
	Passenger	ONE16
<b>R2500</b>		
1989-1988	Driver	ONE18
	Passenger	ONE18
1987	Driver	ONE16
	Passenger	ONE16
<b>R2500 Suburban</b>		
1991-1987	Driver	ONE16
	Passenger	ONE16
<b>R3500</b>		
1991-1988	Driver	ONE18
	Passenger	ONE18
1987	Driver	ONE16
	Passenger	ONE16

<b>GMC (cont.)</b>		
<b>S15 Jimmy</b>		
1984-1983	Driver	ONE16
	Passenger	ONE16
<b>Safari</b>		
2005-1993	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
1992-1985	Driver	ONE18
	Passenger	ONE18
<b>Savana 1500</b>		
2014-1996	Driver	ONE22
	Passenger	ONE22
<b>Savana 2500</b>		
2015-1996	Driver	ONE22
	Passenger	ONE22
<b>Savana 3500</b>		
2015-1996	Driver	ONE22
	Passenger	ONE22
<b>Savana 4500</b>		
2015-2009	Driver	ONE22
	Passenger	ONE22
<b>Sierra</b>		
2015-2007	Driver	ONE22
	Passenger	ONE22
<b>Sierra 1500</b>		
2006-1999	Driver	ONE22
	Passenger	ONE22
<b>Sierra 2500</b>		
2004-1999	Driver	ONE22
	Passenger	ONE22
<b>Sierra 3500</b>		
2006-2001	Driver	ONE22
	Passenger	ONE22

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>GMC (cont.)</b>		
<b>Sonoma</b>		
2004-1994	Driver	ONE20
	Passenger	ONE20
1993-1991	Driver	ONE16
	Passenger	ONE16
<b>Sprint</b>		
1977-1971	Driver	ONE16
	Passenger	ONE16
<b>Syclone</b>		
1991	Driver	ONE16
	Passenger	ONE16
<b>Terrain</b>		
2015-2010	Driver	ONE24
	Passenger	ONE17
<b>Typhoon</b>		
1993-1992	Driver	ONE16
	Passenger	ONE16
	Rear	ONE14
<b>V1500</b>		
1987	Driver	ONE16
	Passenger	ONE16
<b>V1500 Suburban</b>		
1991-1987	Driver	ONE16
	Passenger	ONE16
<b>V2500</b>		
1987	Driver	ONE16
	Passenger	ONE16
<b>V2500 Suburban</b>		
1991-1987	Driver	ONE16
	Passenger	ONE16
<b>V3500</b>		
1991-1988	Driver	ONE18
	Passenger	ONE18
1987	Driver	ONE16
	Passenger	ONE16

<b>GMC (cont.)</b>		
<b>Yukon</b>		
2015-2007	Driver	ONE22
	Passenger	ONE22
2006-2000	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
1999-1992	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
<b>Yukon XL</b>		
2015	Driver	ONE22
	Passenger	ONE22
<b>Yukon XL 1500</b>		
2014-2007	Driver	ONE22
	Passenger	ONE22
2006-2000	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>Yukon XL 2500</b>		
2013-2007	Driver	ONE22
	Passenger	ONE22
2006-2000	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>GEO</b>		
<b>Metro</b>		
1997-1995	Driver	ONE20
	Passenger	ONE19
1994-1991	Driver	ONE20
	Passenger	ONE18
1990-1989	Driver	ONE20
	Passenger	ONE18
	Rear	ONE15





## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>GEO (cont.)</b>		
<b>Prizm</b>		
1997-1993	Driver	ONE20
	Passenger	ONE18
<b>Spectrum</b>		
1989	Driver	ONE18
	Passenger	ONE18
<b>Storm</b>		
1993-1990	Driver	ONE22
	Passenger	ONE20
<b>Tracker</b>		
1997-1995	Driver	ONE17
	Passenger	ONE17
	Rear	ONE15
1994-1993	Driver	ONE17
	Passenger	ONE17
1992-1990	Driver	ONE17
	Passenger	ONE17
	Rear	ONE16
<b>HONDA</b>		
<b>Accord</b>		
2015-2008	Driver	ONE26
	Passenger	ONE19
2007-2003	Driver	ONE26
	Passenger	ONE18
2002-1998, 1993-1990	Driver	ONE24
	Passenger	ONE19
1997-1994	Driver	ONE24
	Passenger	ONE20
1989-1986	Driver	ONE19
	Passenger	ONE19
	Rear	ONE19
<b>Accord Wagon</b>		
1997-1994	Driver	ONE24
	Passenger	ONE20
	Rear	ONE15

<b>HONDA (cont.)</b>		
<b>CR-V</b>		
2015-2007	Driver	ONE26
	Passenger	ONE16
2006-2002	Driver	ONE21
	Passenger	ONE20
2001-1997	Driver	ONE20
	Passenger	ONE19
<b>CR-Z</b>		
2015-2011	Driver	ONE26
	Passenger	ONE21
	Rear	ONE16
<b>CRX</b>		
1991-1988	Driver	ONE20
	Passenger	ONE19
	Rear	ONE17
<b>Civic</b>		
2005-2001	Driver	ONE21
	Passenger	ONE19
2000-1996	Driver	ONE20
	Passenger	ONE18
	Rear	ONE15
1995-1992	Driver	ONE22
	Passenger	ONE18
1991-1988	Driver	ONE20
	Passenger	ONE19
1987-1984	Driver	ONE18
	Passenger	ONE18
<b>Civic Coupe</b>		
2015-2006	Driver	ONE28
	Passenger	ONE24
<b>Civic Sedan</b>		
2015-2008	Driver	ONE26
	Passenger	ONE22

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>HONDA (cont.)</b>		
<b>Civic Si</b>		
2005-2002	Driver	ONE24
	Passenger	ONE16
<b>Civic Wagon</b>		
1991-1988	Driver	ONE20
	Passenger	ONE19
	Rear	ONE16
<b>Civic del Sol</b>		
1997-1993	Driver	ONE22
	Passenger	ONE19
<b>Crosstour</b>		
2015-2012	Driver	ONE26
	Passenger	ONE19
	Rear	ONE21
<b>EV Plus</b>		
1999-1998	Driver	ONE24
	Passenger	ONE22
<b>Element</b>		
2011-2003	Driver	ONE20
	Passenger	ONE20
<b>Fit</b>		
2015-2009	Driver	ONE28
	Passenger	ONE14
2008-2006	Driver	ONE24
	Passenger	ONE16
<b>Insight</b>		
2014-2012	Driver	ONE26
	Passenger	ONE18
	Rear	ONE20
2011-2010	Driver	ONE26
	Passenger	ONE18
2006-2000	Driver	ONE22
	Passenger	ONE19
	Rear	ONE16

<b>HONDA (cont.)</b>		
<b>Odyssey</b>		
2015-2005	Driver	ONE26
	Passenger	ONE22
2004-1999	Driver	ONE24
	Passenger	ONE21
	Rear	ONE17
1998-1995	Driver	ONE24
	Passenger	ONE24
	Rear	ONE15
<b>Passport</b>		
2002-1999	Driver	ONE19
	Passenger	ONE19
1998	Driver	ONE19
	Passenger	ONE19
	Rear	ONE14
1997-1994	Driver	ONE18
	Passenger	ONE18
<b>Pilot</b>		
2015-2009	Driver	ONE22
	Passenger	ONE21
2008-2003	Driver	ONE24
	Passenger	ONE21
<b>Prelude</b>		
2001-1997	Driver	ONE21
	Passenger	ONE19
1996-1992	Driver	ONE22
	Passenger	ONE18
1991-1988	Driver	ONE20
	Passenger	ONE19
<b>Ridgeline</b>		
2014-2009	Driver	ONE22
	Passenger	ONE22
2008-2006	Driver	ONE24
	Passenger	ONE22



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>HONDA (cont.)</b>		
<b>S2000</b>		
2009-2000	Driver	ONE16
	Passenger	ONE20
<b>HUMMER</b>		
<b>H2</b>		
2009-2003	Driver	ONE17
	Passenger	ONE17
<b>H3</b>		
2010-2006	Driver	ONE17
	Passenger	ONE16
<b>H3T</b>		
2010-2009	Driver	ONE17
	Passenger	ONE16
<b>HYUNDAI</b>		
<b>Accent</b>		
2015-2012	Driver	ONE26
	Passenger	ONE16
2011-2006	Driver	ONE22
	Passenger	ONE16
2005-2001, 1995	Driver	ONE20
	Passenger	ONE18
2000	Driver	ONE20
	Passenger	ONE18
	Rear	ONE18
1999-1996	Driver	ONE20
	Passenger	ONE18
	Rear	ONE20
<b>Azera</b>		
2015-2012	Driver	ONE26
	Passenger	ONE18
2011-2006	Driver	ONE24
	Passenger	ONE20
<b>Elantra</b>		
2015-2011	Driver	ONE28
	Passenger	ONE14

<b>HYUNDAI (cont.)</b>		
<b>Elantra (cont.)</b>		
2010-2007	Driver	ONE24
	Passenger	ONE18
2006-2001	Driver	ONE20
	Passenger	ONE18
	Rear	ONE20
2000-1996	Driver	ONE20
	Passenger	ONE18
1995-1992	Driver	ONE20
	Passenger	ONE19
<b>Elantra Touring</b>		
2009	Driver	ONE24
	Passenger	ONE18
<b>Entourage</b>		
2010-2007	Driver	ONE26
	Passenger	ONE18
<b>Equus</b>		
2015-2011	Driver	ONE24
	Passenger	ONE20
<b>Excel</b>		
1994-1990	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
1989-1988	Driver	ONE17
	Passenger	ONE17
	Rear	ONE17
1987-1986	Driver	ONE16
	Passenger	ONE16
	Rear	ONE16
<b>Genesis</b>		
2015	Driver	ONE26
	Passenger	ONE16
2014-2009	Driver	ONE24
	Passenger	ONE20

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>HYUNDAI (cont.)</b>		
<b>Genesis Coupe</b>		
2015-2010	Driver	ONE24
	Passenger	ONE20
<b>Santa Fe</b>		
2015-2013	Driver	ONE26
	Passenger	ONE14
2012-2007	Driver	ONE24
	Passenger	ONE18
2006-2005	Driver	ONE24
	Passenger	ONE20
2004-2001	Driver	ONE22
	Passenger	ONE20
<b>Scoupe</b>		
1995-1991	Driver	ONE19
	Passenger	ONE18
<b>Sonata</b>		
2015-2011	Driver	ONE26
	Passenger	ONE18
2010-2006	Driver	ONE24
	Passenger	ONE20
2005-1999	Driver	ONE22
	Passenger	ONE20
1998-1995	Driver	ONE20
	Passenger	ONE20
1994-1989	Driver	ONE20
	Passenger	ONE18
<b>Stellar</b>		
1987-1985	Driver	ONE18
	Passenger	ONE18
<b>Tiburon</b>		
2008-2007	Driver	ONE22
	Passenger	ONE18
2006-2003, 2001-1997	Driver	ONE22
	Passenger	ONE18
	Rear	ONE20

<b>HYUNDAI (cont.)</b>		
<b>Tucson</b>		
2015-2005	Driver	ONE24
	Passenger	ONE16
<b>Veloster</b>		
2015-2012	Driver	ONE26
	Passenger	ONE18
<b>XG300</b>		
2001	Driver	ONE22
	Passenger	ONE20
<b>XG350</b>		
2005-2002	Driver	ONE22
	Passenger	ONE20
<b>INFINITI</b>		
<b>EX35</b>		
2012-2011	Driver	ONE24
	Passenger	ONE17
2010-2008	Driver	ONE22
	Passenger	ONE18
<b>EX37</b>		
2013	Driver	ONE24
	Passenger	ONE17
<b>FX35</b>		
2012-2011	Driver	ONE24
	Passenger	ONE19
2010-2009	Driver	ONE22
	Passenger	ONE19
2008-2003	Driver	ONE22
	Passenger	ONE20
<b>FX37</b>		
2013	Driver	ONE24
	Passenger	ONE19
<b>FX45</b>		
2008-2003	Driver	ONE22
	Passenger	ONE20



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>INFINITI (cont.)</b>		
<b>FX50</b>		
2013-2011	Driver	ONE24
	Passenger	ONE19
2010-2009	Driver	ONE22
	Passenger	ONE19
<b>G20</b>		
2002-1999, 1996-1991	Driver	ONE21
	Passenger	ONE19
<b>G25</b>		
2012-2011	Driver	ONE26
	Passenger	ONE16
<b>G35 Coupe</b>		
2007-2003	Driver	ONE24
	Passenger	ONE17
<b>G35 Sedan</b>		
2008-2007	Driver	ONE26
	Passenger	ONE16
2006-2003	Driver	ONE22
	Passenger	ONE18
<b>G37</b>		
2009-2008	Driver	ONE26
	Passenger	ONE17
<b>G37 Coupe</b>		
2013-2010	Driver	ONE26
	Passenger	ONE17
<b>G37 Sedan</b>		
2013-2010	Driver	ONE26
	Passenger	ONE16
<b>I30</b>		
2001-2000	Driver	ONE26
	Passenger	ONE17
1999-1996	Driver	ONE22
	Passenger	ONE21

<b>INFINITI (cont.)</b>		
<b>I35</b>		
2004-2002	Driver	ONE26
	Passenger	ONE17
<b>JX35</b>		
2013	Driver	ONE26
	Passenger	ONE17
<b>M30</b>		
1992-1990	Driver	ONE21
	Passenger	ONE19
<b>M35</b>		
2010-2006	Driver	ONE24
	Passenger	ONE19
<b>M35h</b>		
2013-2012	Driver	ONE26
	Passenger	ONE19
<b>M37</b>		
2013-2011	Driver	ONE26
	Passenger	ONE19
<b>M45</b>		
2010-2006	Driver	ONE24
	Passenger	ONE19
2004-2003	Driver	ONE21
	Passenger	ONE19
<b>M56</b>		
2013-2011	Driver	ONE26
	Passenger	ONE19
<b>Q45</b>		
2006-2002	Driver	ONE26
	Passenger	ONE18
2001-1997	Driver	ONE22
	Passenger	ONE20
1996-1990	Driver	ONE21
	Passenger	ONE21

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>INFINITI (cont.)</b>		
<b>Q50</b>		
2015-2014	Driver	ONE26
	Passenger	ONE17
<b>Q60</b>		
2015-2014	Driver	ONE26
	Passenger	ONE17
<b>Q70</b>		
2015-2014	Driver	ONE26
	Passenger	ONE19
<b>QX4</b>		
2003-1997	Driver	ONE22
	Passenger	ONE21
<b>QX50</b>		
2015-2014	Driver	ONE24
	Passenger	ONE17
<b>QX56</b>		
2013-2011	Driver	ONE24
	Passenger	ONE19
2010-2004	Driver	ONE24
	Passenger	ONE22
<b>QX60</b>		
2015-2014	Driver	ONE26
	Passenger	ONE17
<b>QX70</b>		
2015-2014	Driver	ONE24
	Passenger	ONE19
<b>QX80</b>		
2015-2014	Driver	ONE24
	Passenger	ONE19
<b>ISUZU</b>		
<b>Amigo</b>		
2000-1998	Driver	ONE19
	Passenger	ONE19
1994-1989	Driver	ONE18
	Passenger	ONE18

<b>ISUZU (cont.)</b>		
<b>Ascender</b>		
2008-2007	Driver	ONE22
	Passenger	ONE22
2006-2003	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>Axiom</b>		
2004-2002	Driver	ONE20
	Passenger	ONE19
<b>Hombre</b>		
2000-1996	Driver	ONE20
	Passenger	ONE20
<b>Impulse</b>		
1992-1990	Driver	ONE22
	Passenger	ONE22
	Rear	ONE20
<b>Oasis</b>		
1999-1996	Driver	ONE24
	Passenger	ONE24
	Rear	ONE15
<b>Pickup</b>		
1995-1981	Driver	ONE18
	Passenger	ONE18
<b>Rodeo</b>		
2004-1998	Driver	ONE19
	Passenger	ONE19
1997-1991	Driver	ONE18
	Passenger	ONE18
<b>Stylus</b>		
1993-1991	Driver	ONE22
	Passenger	ONE20
<b>Trooper</b>		
2002-1992	Driver	ONE20
	Passenger	ONE20
	Rear	ONE15



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>ISUZU (cont.)</b>		
<b>Trooper (cont.)</b>		
1991-1984	Driver	ONE17
	Passenger	ONE17
	Rear	ONE16
<b>VehiCROSS</b>		
2001-1999	Driver	ONE24
	Passenger	ONE17
<b>i-280</b>		
2006	Driver	ONE22
	Passenger	ONE19
<b>i-290</b>		
2008-2007	Driver	ONE22
	Passenger	ONE19
<b>i-350</b>		
2006	Driver	ONE22
	Passenger	ONE19
<b>i-370</b>		
2008-2007	Driver	ONE22
	Passenger	ONE19
<b>JAGUAR</b>		
<b>F-Type</b>		
2015-2014	Driver	ONE22
	Passenger	ONE21
<b>S-Type</b>		
2003-2002	Driver	ONE24
	Passenger	ONE19
2001-1999	Driver	ONE22
	Passenger	ONE22
<b>Vanden Plas</b>		
2003-1988	Driver	ONE21
<b>X-Type</b>		
2008-2001	Driver	ONE22
	Passenger	ONE19

<b>JAGUAR (cont.)</b>		
<b>XF</b>		
2015-2009	Driver	ONE22
	Passenger	ONE19
<b>XFR</b>		
2015-2010	Driver	ONE22
	Passenger	ONE19
<b>XFR-S</b>		
2015-2013	Driver	ONE22
	Passenger	ONE19
<b>XJ</b>		
2015-2011	Driver	ONE22
	Passenger	ONE19
<b>XJ12</b>		
1996-1994, 1992-1988	Driver	ONE21
<b>XJ6</b>		
1997-1988	Driver	ONE21
<b>XJ8</b>		
2003-1998	Driver	ONE21
<b>XJR</b>		
2015-2014	Driver	ONE22
	Passenger	ONE19
<b>XJRS</b>		
1993	Driver	ONE21
<b>XK</b>		
2015-2007	Driver	ONE22
	Passenger	ONE21
<b>XK8</b>		
2006-1997	Driver	ONE21
	Passenger	ONE21
<b>XKR</b>		
2014-2007	Driver	ONE22
	Passenger	ONE21
2006-2000	Driver	ONE21
	Passenger	ONE21

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>JEEP</b>		
<b>Cherokee</b>		
2015-2014	Driver	ONE26
	Passenger	ONE18
2001-1984	Driver	ONE18
	Passenger	ONE18
1983-1974	Driver	ONE16
	Passenger	ONE16
<b>Comanche</b>		
1992-1986	Driver	ONE18
	Passenger	ONE18
<b>Commander</b>		
2010-2006	Driver	ONE18
	Passenger	ONE18
<b>Compass</b>		
2015-2007	Driver	ONE22
	Passenger	ONE20
<b>Grand Cherokee</b>		
2015-2011	Driver	ONE22
	Passenger	ONE21
2010-1999	Driver	ONE21
	Passenger	ONE21
1998-1993	Driver	ONE20
	Passenger	ONE20
<b>Grand Wagoneer</b>		
1993	Driver	ONE20
	Passenger	ONE20
1988-1984	Driver	ONE16
	Passenger	ONE16
<b>J10</b>		
1988-1974	Driver	ONE16
	Passenger	ONE16
<b>J20</b>		
1988-1974	Driver	ONE16
	Passenger	ONE16

<b>JEEP (cont.)</b>		
<b>Liberty</b>		
2012-2002	Driver	ONE19
	Passenger	ONE19
<b>Patriot</b>		
2015-2007	Driver	ONE21
	Passenger	ONE21
<b>Renegade</b>		
2015	Driver	ONE22
	Passenger	ONE20
<b>Scrambler</b>		
1985-1984	Driver	ONE16
	Passenger	ONE16
<b>TJ</b>		
2006-2005	Rear	ONE17
2004-1997	Rear	ONE18
<b>Wagoneer</b>		
1990-1984	Driver	ONE18
	Passenger	ONE18
1983-1974	Driver	ONE16
	Passenger	ONE16
<b>Wrangler</b>		
2015-2007	Driver	ONE15
	Passenger	ONE15
2006-2005	Rear	ONE17
2004-1997	Rear	ONE18
<b>KIA</b>		
<b>Amanti</b>		
2009-2004	Driver	ONE24
	Passenger	ONE18
<b>Borrego</b>		
2011-2009	Driver	ONE24
	Passenger	ONE20
<b>Cadenza</b>		
2015-2014	Driver	ONE26
	Passenger	ONE18



Make / Model / Year

<b>KIA (cont.)</b>		
<b>Forte</b>		
2015-2014	Driver	ONE28
	Passenger	ONE14
2013-2010	Driver	ONE24
	Passenger	ONE20
<b>Forte Koup</b>		
2015-2014	Driver	ONE28
	Passenger	ONE14
2013-2010	Driver	ONE24
	Passenger	ONE20
<b>K900</b>		
2015	Driver	ONE24
	Passenger	ONE20
<b>Magentis</b>		
2010-2007	Driver	ONE24
	Passenger	ONE18
2006-2001	Driver	ONE22
	Passenger	ONE20
<b>Optima</b>		
2015-2007	Driver	ONE24
	Passenger	ONE18
2006-2001	Driver	ONE22
	Passenger	ONE20
<b>Rio</b>		
2015-2012	Driver	ONE26
	Passenger	ONE16
2011-2006	Driver	ONE22
	Passenger	ONE16
2005-2001	Driver	ONE21
	Passenger	ONE18
<b>Rio5</b>		
2011-2006	Driver	ONE22
	Passenger	ONE16

<b>KIA (cont.)</b>		
<b>Rondo</b>		
2010-2007	Driver	ONE26
	Passenger	ONE16
<b>Sedona</b>		
2015-2014, 2012-2006	Driver	ONE26
	Passenger	ONE18
2005-2002	Driver	ONE24
	Passenger	ONE24
	Rear	ONE16
<b>Sephia</b>		
2001-1998	Driver	ONE21
	Passenger	ONE19
1997-1994	Driver	ONE21
	Passenger	ONE19
	Rear	ONE18
<b>Sorento</b>		
2016	Driver	ONE26
	Passenger	ONE16
2015-2011	Driver	ONE24
	Passenger	ONE20
2009-2003	Driver	ONE24
	Passenger	ONE18
	Rear	ONE14
<b>Soul</b>		
2015-2010	Driver	ONE24
	Passenger	ONE20
<b>Soul EV</b>		
2015	Driver	ONE24
	Passenger	ONE20
<b>Spectra</b>		
2009-2005	Driver	ONE24
	Passenger	ONE16
2004-2000	Driver	ONE21
	Passenger	ONE19
	Rear	ONE18

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>KIA (cont.)</b>		
<b>Spectra5</b>		
2009-2005	Driver	ONE24
	Passenger	ONE16
<b>Sportage</b>		
2014-2011	Driver	ONE24
	Passenger	ONE18
2010-2005	Driver	ONE24
	Passenger	ONE16
2002-1995	Driver	ONE20
	Passenger	ONE20
	Rear	ONE16
<b>LADA</b>		
<b>Samara</b>		
1993-1988	Driver	ONE21
	Passenger	ONE21
<b>LAFORZA</b>		
<b>Laforza</b>		
1990-1989	Driver	ONE22
	Passenger	ONE22
	Rear	ONE15
<b>LAND ROVER</b>		
<b>Discovery</b>		
1999	Driver	ONE18
	Passenger	ONE18
1998-1994	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
<b>Freelander</b>		
2006-2002	Driver	ONE22
	Passenger	ONE21
<b>LR2</b>		
2015-2008	Driver	ONE24
	Passenger	ONE20
	Rear	ONE14

<b>LAND ROVER (cont.)</b>		
<b>LR3</b>		
2009-2005	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>LR4</b>		
2015-2010	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>Range Rover</b>		
2015-2013	Driver	ONE24
	Passenger	ONE20
	Rear	ONE16
2012-2002	Rear	ONE18
2001-1995	Driver	ONE22
	Passenger	ONE22
	Rear	ONE19
1989-1987	Driver	ONE17
	Passenger	ONE17
	Rear	ONE17
<b>Range Rover Evoque</b>		
2015-2012	Driver	ONE22
	Passenger	ONE22
<b>Range Rover Sport</b>		
2015-2013	Driver	ONE24
	Passenger	ONE20
	Rear	ONE15
2012-2006	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>LEXUS</b>		
<b>CT200h</b>		
2015-2011	Driver	ONE26
	Passenger	ONE18



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>LEXUS (cont.)</b>		
<b>ES300</b>		
2003-2002	Driver	ONE24
	Passenger	ONE20
2001-1997	Driver	ONE22
	Passenger	ONE18
1996-1992	Driver	ONE21
	Passenger	ONE19
<b>ES300h</b>		
2015-2013	Driver	ONE26
	Passenger	ONE18
<b>ES330</b>		
2006-2004	Driver	ONE24
	Passenger	ONE20
<b>ES350</b>		
2015-2013	Driver	ONE26
	Passenger	ONE18
2012-2007	Driver	ONE24
	Passenger	ONE19
<b>GS300</b>		
2006	Driver	ONE24
	Passenger	ONE19
2005-1998	Driver	ONE24
	Passenger	ONE20
1997-1993	Driver	ONE21
	Passenger	ONE19
<b>GS350</b>		
2015-2013	Driver	ONE26
	Passenger	ONE18
2011-2007	Driver	ONE24
	Passenger	ONE19
<b>GS400</b>		
2000-1998	Driver	ONE24
	Passenger	ONE20

<b>LEXUS (cont.)</b>		
<b>GS430</b>		
2007-2006	Driver	ONE24
	Passenger	ONE19
2005-2001	Driver	ONE24
	Passenger	ONE20
<b>GS450h</b>		
2015-2013	Driver	ONE26
	Passenger	ONE18
2011-2007	Driver	ONE24
	Passenger	ONE19
<b>GS460</b>		
2011-2008	Driver	ONE24
	Passenger	ONE19
<b>GX460</b>		
2015-2010	Driver	ONE26
	Passenger	ONE20
<b>GX470</b>		
2009-2003	Driver	ONE22
	Passenger	ONE21
<b>HS250h</b>		
2012-2010	Driver	ONE26
	Passenger	ONE18
<b>IS F</b>		
2014-2008	Driver	ONE22
	Passenger	ONE20
<b>IS250</b>		
2015-2014	Driver	ONE24
	Passenger	ONE18
2013-2006	Driver	ONE22
	Passenger	ONE20
<b>IS250 Convertible</b>		
2014	Driver	ONE22
	Passenger	ONE20

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>LEXUS (cont.)</b>		
<b>IS300</b>		
2005-2001	Driver	ONE22
	Passenger	ONE20
<b>IS350</b>		
2015-2014	Driver	ONE24
	Passenger	ONE18
2013-2006	Driver	ONE22
	Passenger	ONE20
<b>IS350 Convertible</b>		
2014	Driver	ONE22
	Passenger	ONE20
<b>LS400</b>		
2000-1990	Driver	ONE22
	Passenger	ONE16
<b>LS430</b>		
2006-2001	Driver	ONE24
	Passenger	ONE16
<b>LS460</b>		
2015-2007	Driver	ONE24
	Passenger	ONE17
<b>LS600h</b>		
2015-2008	Driver	ONE24
	Passenger	ONE17
<b>LX450</b>		
1997-1996	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>LX470</b>		
2007-2000	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16
1999-1998	Driver	ONE20
	Passenger	ONE20
	Rear	ONE16

<b>LEXUS (cont.)</b>		
<b>LX570</b>		
2015-2013, 2011-2008	Driver	ONE24
	Passenger	ONE22
<b>RC F</b>		
2015	Driver	ONE24
	Passenger	ONE18
<b>RC350</b>		
2015	Driver	ONE24
	Passenger	ONE18
<b>RX300</b>		
2003-1999	Driver	ONE24
	Passenger	ONE21
	Rear	ONE16
<b>RX330</b>		
2006-2004	Driver	ONE26
	Passenger	ONE22
<b>RX350</b>		
2015-2007	Driver	ONE26
	Passenger	ONE22
<b>RX400h</b>		
2008-2006	Driver	ONE26
	Passenger	ONE22
<b>RX450h</b>		
2015-2010	Driver	ONE26
	Passenger	ONE22
<b>SC300</b>		
2000-1992	Driver	ONE21
	Passenger	ONE20
<b>SC400</b>		
2000-1992	Driver	ONE21
	Passenger	ONE20
<b>SC430</b>		
2010-2002	Driver	ONE24
	Passenger	ONE20



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>LINCOLN</b>		
<b>Aviator</b>		
2005-2003	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>Blackwood</b>		
2003-2002	Driver	ONE20
	Passenger	ONE20
<b>Continental</b>		
2002-1998	Driver	ONE24
	Passenger	ONE20
1997-1988	Driver	ONE20
	Passenger	ONE20
1980-1973	Driver	ONE18
	Passenger	ONE18
1972-1970	Driver	ONE19
	Passenger	ONE19
<b>LS</b>		
2006-2000	Driver	ONE24
	Passenger	ONE19
<b>MKC</b>		
2015	Driver	ONE26
	Passenger	ONE16
<b>MKS</b>		
2015-2009	Driver	ONE26
	Passenger	ONE20
<b>MKT</b>		
2015-2010	Driver	ONE24
	Passenger	ONE22
<b>MKX</b>		
2015-2007	Driver	ONE26
	Passenger	ONE20
<b>MKZ</b>		
2015-2013	Driver	ONE22
	Passenger	ONE20

<b>LINCOLN (cont.)</b>		
<b>MKZ (cont.)</b>		
2012-2007	Driver	ONE24
	Passenger	ONE19
<b>Mark III</b>		
1971-1968	Driver	ONE16
	Passenger	ONE16
<b>Mark IV</b>		
1976-1972	Driver	ONE18
	Passenger	ONE18
<b>Mark LT</b>		
2008-2006	Driver	ONE20
	Passenger	ONE20
<b>Mark V</b>		
1979-1977	Driver	ONE18
	Passenger	ONE18
<b>Mark VI</b>		
1983-1980	Driver	ONE18
	Passenger	ONE18
<b>Mark VII</b>		
1992-1984	Driver	ONE18
	Passenger	ONE18
<b>Mark VIII</b>		
1998-1993	Driver	ONE22
	Passenger	ONE22
<b>Navigator</b>		
2015-2009	Driver	ONE22
	Passenger	ONE22
2008	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
2007-2003	Driver	ONE20
	Passenger	ONE20
	Rear	ONE17

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>LINCOLN (cont.)</b>		
<b>Navigator (cont.)</b>		
2002-1998	Driver	ONE20
	Passenger	ONE20
	Rear	ONE16
<b>Town Car</b>		
2011-1990	Driver	ONE22
	Passenger	ONE22
1989-1981	Driver	ONE18
	Passenger	ONE18
<b>Versailles</b>		
1980-1977	Driver	ONE16
	Passenger	ONE16
<b>Zephyr</b>		
2006	Driver	ONE24
	Passenger	ONE19
<b>LOTUS</b>		
<b>Elise</b>		
2011-2004	Driver	ONE26
<b>Evora</b>		
2013-2010	Driver	ONE26
<b>Exige</b>		
2010-2005	Driver	ONE26
<b>MASERATI</b>		
<b>228i</b>		
1990-1989	Driver	ONE20
	Passenger	ONE20
<b>3200 GT</b>		
2003-1999	Driver	ONE22
	Passenger	ONE22
<b>430i</b>		
1989	Driver	ONE20
	Passenger	ONE20
<b>Biturbo</b>		
1987-1983	Driver	ONE20
	Passenger	ONE20

<b>MASERATI (cont.)</b>		
<b>Coupe</b>		
2007-2003	Driver	ONE22
	Passenger	ONE22
<b>Spyder</b>		
2004-2002	Driver	ONE22
	Passenger	ONE22
<b>MAZDA</b>		
<b>2</b>		
2015-2011	Driver	ONE24
	Passenger	ONE14
<b>3</b>		
2015-2014	Driver	ONE24
	Passenger	ONE18
2013-2010	Driver	ONE24
	Passenger	ONE19
2009-2004	Driver	ONE21
	Passenger	ONE19
<b>323</b>		
1995-1990	Driver	ONE21
	Passenger	ONE18
1989-1986	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>5</b>		
2015-2012, 2010-2006	Driver	ONE26
	Passenger	ONE16
<b>6</b>		
2015-2009	Driver	ONE24
	Passenger	ONE18
2008	Driver	ONE22
	Passenger	ONE18
	Rear	ONE20
2007-2003	Driver	ONE22
	Passenger	ONE18



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>MAZDA (cont.)</b>		
<b>6 Hatchback</b>		
2007-2004	Driver	ONE22
	Passenger	ONE18
	Rear	ONE20
<b>626</b>		
2002-1998	Driver	ONE20
	Passenger	ONE19
1997-1993	Driver	ONE21
	Passenger	ONE20
1992-1988	Driver	ONE19
	Passenger	ONE19
	Rear	ONE22
1987-1986	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>929</b>		
1995-1992	Driver	ONE21
	Passenger	ONE20
1991-1988	Driver	ONE20
	Passenger	ONE19
<b>B2200</b>		
1993-1988	Driver	ONE18
	Passenger	ONE18
<b>B2300</b>		
2010-2001, 1997-1994	Driver	ONE18
	Passenger	ONE18
<b>B2500</b>		
2001-1998	Driver	ONE18
	Passenger	ONE18
<b>B2600</b>		
1993-1988	Driver	ONE18
	Passenger	ONE18
<b>B3000</b>		
2008-1994	Driver	ONE18
	Passenger	ONE18

<b>MAZDA (cont.)</b>		
<b>B4000</b>		
2010-1994	Driver	ONE18
	Passenger	ONE18
<b>CX-5</b>		
2015-2013	Driver	ONE24
	Passenger	ONE18
<b>CX-7</b>		
2012-2007	Driver	ONE26
	Passenger	ONE16
<b>CX-9</b>		
2015-2007	Driver	ONE26
	Passenger	ONE17
<b>MPV</b>		
2006-2000	Driver	ONE24
	Passenger	ONE24
	Rear	ONE16
1998-1996	Driver	ONE22
	Passenger	ONE20
	Rear	ONE17
1995-1989	Driver	ONE22
	Passenger	ONE20
	Rear	ONE16
<b>MX-3</b>		
1996-1992	Driver	ONE21
	Passenger	ONE18
	Rear	ONE21
<b>MX-5 Convertible</b>		
2015	Driver	ONE18
	Passenger	ONE18
<b>MX-5 Miata</b>		
2014-2006	Driver	ONE18
	Passenger	ONE18
<b>MX-5 Miata Convertible</b>		
2015	Driver	ONE18
	Passenger	ONE18

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>MAZDA (cont.)</b>		
<b>MX-6</b>		
1997-1993	Driver	ONE20
	Passenger	ONE20
1992-1988	Driver	ONE19
	Passenger	ONE19
<b>Millenia</b>		
2002-1995	Driver	ONE21
	Passenger	ONE20
<b>Navajo</b>		
1994-1991	Driver	ONE18
	Passenger	ONE18
<b>Protege</b>		
2003-2002	Driver	ONE21
	Passenger	ONE19
	Rear	ONE14
2001-1999	Driver	ONE21
	Passenger	ONE19
1998-1990	Driver	ONE21
	Passenger	ONE18
<b>Protege5</b>		
2003-2002	Driver	ONE21
	Passenger	ONE19
	Rear	ONE14
<b>RX-4</b>		
1978-1974	Driver	ONE17
	Passenger	ONE17
<b>RX-7</b>		
1995-1994	Driver	ONE20
	Passenger	ONE20
1993	Driver	ONE20
	Passenger	ONE20
	Rear	ONE18
<b>RX-8</b>		
2011-2004	Driver	ONE20
	Passenger	ONE18

<b>MAZDA (cont.)</b>		
<b>Tribute</b>		
2011-2008	Driver	ONE20
	Passenger	ONE20
2006-2005	Driver	ONE20
	Passenger	ONE18
2004-2001	Driver	ONE19
	Passenger	ONE19
<b>MERCEDES-BENZ</b>		
<b>190D</b>		
1989-1986	Driver	ONE24
1985-1984	Driver	ONE24
	Passenger	ONE20
<b>190E</b>		
1993-1986	Driver	ONE24
1985-1984	Driver	ONE20
<b>230</b>		
1978-1977	Driver	ONE20
	Passenger	ONE20
1976-1974	Driver	ONE16
	Passenger	ONE16
<b>240D</b>		
1983-1974	Driver	ONE20
	Passenger	ONE20
<b>250</b>		
1972-1968	Driver	ONE16
	Passenger	ONE16
<b>260E</b>		
1989-1987	Driver	ONE24
<b>280</b>		
1976-1973	Driver	ONE16
	Passenger	ONE16
<b>280C</b>		
1976-1973	Driver	ONE16
	Passenger	ONE16





## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>MERCEDES-BENZ (cont.)</b>		
<b>280CE</b>		
1981-1978	Driver	ONE20
	Passenger	ONE20
<b>280E</b>		
1981-1977	Driver	ONE20
	Passenger	ONE20
<b>280S</b>		
1976-1975	Driver	ONE19
	Passenger	ONE18
<b>280SE</b>		
1980-1977	Driver	ONE19
	Passenger	ONE18
<b>300CD</b>		
1985-1978	Driver	ONE20
	Passenger	ONE20
<b>300CE</b>		
1993-1988	Driver	ONE24
<b>300D</b>		
1993-1990	Driver	ONE24
1985-1977	Driver	ONE20
	Passenger	ONE20
1976-1975	Driver	ONE16
	Passenger	ONE16
<b>300E</b>		
1993-1988	Driver	ONE24
<b>300SD</b>		
1993-1992	Driver	ONE24
1980-1978	Driver	ONE19
	Passenger	ONE18
<b>300SE</b>		
1993-1988	Driver	ONE24
<b>300SEL</b>		
1973-1968	Driver	ONE16
	Passenger	ONE16

<b>MERCEDES-BENZ (cont.)</b>		
<b>300SL</b>		
1993-1990	Driver	ONE24
<b>300TD</b>		
1987	Driver	ONE24
1985-1979	Driver	ONE20
	Passenger	ONE20
	Rear	ONE16
<b>300TE</b>		
1993-1988	Driver	ONE24
	Rear	ONE18
<b>380SL</b>		
1985-1981	Driver	ONE19
	Passenger	ONE19
<b>380SLC</b>		
1981	Driver	ONE19
	Passenger	ONE19
<b>400E</b>		
1993-1992	Driver	ONE24
<b>400SE</b>		
1992	Driver	ONE24
	Passenger	ONE28
<b>400SEL</b>		
1993	Driver	ONE24
<b>450SE</b>		
1976-1973	Driver	ONE19
	Passenger	ONE18
<b>450SEL</b>		
1980-1973	Driver	ONE19
	Passenger	ONE18
<b>450SL</b>		
1980-1976	Driver	ONE19
	Passenger	ONE19
1975-1973	Driver	ONE18
	Passenger	ONE18

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>MERCEDES-BENZ (cont.)</b>		
<b>450SLC</b>		
1980-1976	Driver	ONE19
	Passenger	ONE19
1975-1973	Driver	ONE18
	Passenger	ONE18
<b>500E</b>		
1993-1992	Driver	ONE24
<b>500SEC</b>		
1993	Driver	ONE24
	Passenger	ONE28
<b>500SEL</b>		
1993-1992	Driver	ONE24
	Passenger	ONE28
<b>500SL</b>		
1993-1990	Driver	ONE24
<b>560SL</b>		
1989-1986	Driver	ONE18
	Passenger	ONE18
<b>600SEC</b>		
1993	Driver	ONE24
<b>600SEL</b>		
1993-1992	Driver	ONE24
<b>600SL</b>		
1993	Driver	ONE24
<b>A180</b>		
2014	Driver	ONE26
	Passenger	ONE24
<b>A200</b>		
2014	Driver	ONE26
	Passenger	ONE24
<b>A250</b>		
2014	Driver	ONE26
	Passenger	ONE24

<b>MERCEDES-BENZ (cont.)</b>		
<b>A45 AMG</b>		
2014	Driver	ONE26
	Passenger	ONE24
<b>B Electric Drive</b>		
2015	Driver	ONE26
	Passenger	ONE19
<b>B180</b>		
2015-2014	Driver	ONE26
	Passenger	ONE19
2012	Driver	ONE26
	Passenger	ONE24
<b>B200</b>		
2011	Driver	ONE26
	Passenger	ONE24
2010-2006	Driver	ONE26
	Passenger	ONE22
<b>B250</b>		
2015-2013	Driver	ONE26
	Passenger	ONE19
<b>C180</b>		
2015	Driver	ONE22
	Passenger	ONE22
2014-2011	Driver	ONE24
	Passenger	ONE24
<b>C200</b>		
2015	Driver	ONE22
	Passenger	ONE22
2014-2010	Driver	ONE24
	Passenger	ONE24
2003-2001	Driver	ONE24
	Passenger	ONE22
<b>C220</b>		
1997-1994	Driver	ONE24



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>MERCEDES-BENZ (cont.)</b>		
<b>C230</b>		
2009	Driver	ONE24
	Passenger	ONE24
2003-2002	Driver	ONE24
	Passenger	ONE22
2000-1996	Driver	ONE24
<b>C240</b>		
2003-2001	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16
<b>C240 Wagon</b>		
2005-2004	Rear	ONE16
<b>C250</b>		
2015	Driver	ONE22
	Passenger	ONE22
2014-2010	Driver	ONE24
	Passenger	ONE24
<b>C280</b>		
2009	Driver	ONE24
	Passenger	ONE24
2000-1994	Driver	ONE24
<b>C300</b>		
2014-2009	Driver	ONE24
	Passenger	ONE24
<b>C32 AMG</b>		
2003-2002	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16
<b>C320</b>		
2003-2001	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16
<b>C320 Wagon</b>		
2004-2002	Rear	ONE16

<b>MERCEDES-BENZ (cont.)</b>		
<b>C350</b>		
2014-2009	Driver	ONE24
	Passenger	ONE24
<b>C36 AMG</b>		
1997-1995	Driver	ONE24
<b>C43 AMG</b>		
2000-1998	Driver	ONE24
<b>C63 AMG</b>		
2014-2009	Driver	ONE24
	Passenger	ONE24
<b>CL200</b>		
2003-2002	Driver	ONE28
	Passenger	ONE28
<b>CL230</b>		
2005-2002	Driver	ONE28
	Passenger	ONE28
<b>CL500</b>		
2006-2001	Driver	ONE28
	Passenger	ONE28
1999-1997	Driver	ONE24
	Passenger	ONE24
<b>CL55 AMG</b>		
2006-2001	Driver	ONE28
	Passenger	ONE28
<b>CL550</b>		
2014-2010, 2007	Driver	ONE28
	Passenger	ONE28
2009-2008	Driver	ONE26
	Passenger	ONE26
<b>CL600</b>		
2014-2010, 2007-2001	Driver	ONE28
	Passenger	ONE28
2009-2008	Driver	ONE26
	Passenger	ONE26

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>MERCEDES-BENZ (cont.)</b>		
<b>CL600 (cont.)</b>		
1999-1997	Driver	ONE24
	Passenger	ONE24
<b>CL63 AMG</b>		
2014-2010	Driver	ONE28
	Passenger	ONE28
2009-2008	Driver	ONE26
	Passenger	ONE26
<b>CL65 AMG</b>		
2014-2010, 2006-2005	Driver	ONE28
	Passenger	ONE28
2009-2008	Driver	ONE26
	Passenger	ONE26
<b>CLA200</b>		
2015-2014	Driver	ONE24
	Passenger	ONE19
<b>CLA250</b>		
2015-2014	Driver	ONE24
	Passenger	ONE19
<b>CLA45 AMG</b>		
2015-2014	Driver	ONE24
	Passenger	ONE19
<b>CLK320</b>		
2003-1998	Driver	ONE24
<b>CLK430</b>		
2003-1999	Driver	ONE24
<b>CLK500</b>		
2003	Driver	ONE24
<b>CLK55 AMG</b>		
2003-2001	Driver	ONE24
<b>CLS350</b>		
2014-2012	Driver	ONE24
	Passenger	ONE24
2011-2007	Driver	ONE26
	Passenger	ONE26

<b>MERCEDES-BENZ (cont.)</b>		
<b>CLS400</b>		
2015	Driver	ONE24
	Passenger	ONE24
<b>CLS500</b>		
2006	Driver	ONE26
	Passenger	ONE26
<b>CLS55 AMG</b>		
2006	Driver	ONE26
	Passenger	ONE26
<b>CLS550</b>		
2015-2012	Driver	ONE24
	Passenger	ONE24
2011-2007	Driver	ONE26
	Passenger	ONE26
<b>CLS63 AMG</b>		
2014-2012	Driver	ONE24
	Passenger	ONE24
2011-2007	Driver	ONE26
	Passenger	ONE26
<b>CLS63 AMG S</b>		
2015-2014	Driver	ONE24
	Passenger	ONE24
<b>E200</b>		
2015-2012	Driver	ONE24
	Passenger	ONE24
<b>E250</b>		
2015-2011	Driver	ONE24
	Passenger	ONE24
<b>E280</b>		
2009-2007	Driver	ONE26
	Passenger	ONE26
1999	Driver	ONE24
<b>E300</b>		
2015, 2013- 2012, 2010	Driver	ONE24
	Passenger	ONE24



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>MERCEDES-BENZ (cont.)</b>		
<b>E300 (cont.)</b>		
2009-2008	Driver	ONE26
	Passenger	ONE26
1999-1998	Driver	ONE24
	Rear	ONE16
1997-1995	Driver	ONE24
	Rear	ONE18
<b>E320</b>		
2009-2003	Driver	ONE26
	Passenger	ONE26
2002-1994	Driver	ONE24
<b>E320 Wagon</b>		
2005-2003	Rear	ONE17
2002-1998	Rear	ONE16
1995-1994	Rear	ONE18
<b>E350</b>		
2015-2010	Driver	ONE24
	Passenger	ONE24
2009-2006	Driver	ONE26
	Passenger	ONE26
<b>E350 Wagon</b>		
2009-2006	Rear	ONE17
<b>E400</b>		
2015-2013	Driver	ONE24
	Passenger	ONE24
<b>E420</b>		
1999-1997, 1995-1994	Driver	ONE24
<b>E430</b>		
2002-1998	Driver	ONE24
<b>E500</b>		
2015-2013	Driver	ONE24
	Passenger	ONE24
2009-2007	Driver	ONE26
	Passenger	ONE26

<b>MERCEDES-BENZ (cont.)</b>		
<b>E500 (cont.)</b>		
2006-2003	Driver	ONE26
	Passenger	ONE26
	Rear	ONE17
2002, 1997, 1994	Driver	ONE24
<b>E500 Wagon</b>		
2006-2004	Rear	ONE17
<b>E55 AMG</b>		
2006-2003	Driver	ONE26
	Passenger	ONE26
2002-1998	Driver	ONE24
<b>E55 AMG Wagon</b>		
2006	Rear	ONE17
<b>E550</b>		
2015-2010	Driver	ONE24
	Passenger	ONE24
2009-2007	Driver	ONE26
	Passenger	ONE26
<b>E63 AMG</b>		
2015-2010	Driver	ONE24
	Passenger	ONE24
2009-2007	Driver	ONE26
	Passenger	ONE26
<b>E63 AMG S</b>		
2015-2014	Driver	ONE24
	Passenger	ONE24
<b>E63 AMG Wagon</b>		
2009-2007	Rear	ONE17
<b>G500</b>		
2015-2013, 2011-2002	Driver	ONE16
	Passenger	ONE16
	Rear	ONE15

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>MERCEDES-BENZ (cont.)</b>		
<b>G55 AMG</b>		
2011-2003	Driver	ONE16
	Passenger	ONE16
	Rear	ONE15
<b>G550</b>		
2015-2009	Driver	ONE16
	Passenger	ONE16
	Rear	ONE15
<b>G63 AMG</b>		
2015-2013	Driver	ONE16
	Passenger	ONE16
	Rear	ONE15
<b>G65 AMG</b>		
2015-2014	Driver	ONE16
	Passenger	ONE16
	Rear	ONE15
<b>GL320</b>		
2009-2007	Driver	ONE28
	Passenger	ONE21
<b>GL350</b>		
2015-2013	Driver	ONE26
	Passenger	ONE22
2012-2010	Driver	ONE28
	Passenger	ONE21
<b>GL450</b>		
2015-2013	Driver	ONE26
	Passenger	ONE22
2012-2007	Driver	ONE28
	Passenger	ONE21
<b>GL500</b>		
2015-2014	Driver	ONE26
	Passenger	ONE22
2012-2008	Driver	ONE28
	Passenger	ONE21

<b>MERCEDES-BENZ (cont.)</b>		
<b>GL550</b>		
2015-2013	Driver	ONE26
	Passenger	ONE22
2012-2008	Driver	ONE28
	Passenger	ONE21
<b>GL63 AMG</b>		
2015-2013	Driver	ONE26
	Passenger	ONE22
<b>GLA250</b>		
2015	Driver	ONE24
	Passenger	ONE19
<b>GLA45 AMG</b>		
2015	Driver	ONE24
	Passenger	ONE19
<b>GLK250</b>		
2015-2013	Driver	ONE22
	Passenger	ONE19
<b>GLK280</b>		
2009	Driver	ONE22
	Passenger	ONE19
<b>GLK300</b>		
2015-2014, 2012-2010	Driver	ONE22
	Passenger	ONE19
<b>GLK350</b>		
2015-2009	Driver	ONE22
	Passenger	ONE19
<b>ML250</b>		
2015	Driver	ONE26
	Passenger	ONE22
<b>ML320</b>		
2009-2007	Driver	ONE28
	Passenger	ONE21
2003-2000	Driver	ONE22
	Passenger	ONE22
	Rear	ONE17



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>MERCEDES-BENZ (cont.)</b>		
<b>ML320 (cont.)</b>		
1999-1998	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>ML350</b>		
2015-2012	Driver	ONE26
	Passenger	ONE22
2011-2006	Driver	ONE28
	Passenger	ONE21
2005-2003	Driver	ONE22
	Passenger	ONE22
	Rear	ONE17
<b>ML400</b>		
2015	Driver	ONE26
	Passenger	ONE22
<b>ML430</b>		
2001-2000	Driver	ONE22
	Passenger	ONE22
	Rear	ONE17
1999-1998	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
<b>ML450</b>		
2011-2010	Driver	ONE28
	Passenger	ONE21
<b>ML500</b>		
2015-2013	Driver	ONE26
	Passenger	ONE22
2009-2006	Driver	ONE28
	Passenger	ONE21
2005-2002	Driver	ONE22
	Passenger	ONE22
	Rear	ONE17

<b>MERCEDES-BENZ (cont.)</b>		
<b>ML55 AMG</b>		
2003-2000	Driver	ONE22
	Passenger	ONE22
	Rear	ONE17
<b>ML550</b>		
2015-2012	Driver	ONE26
	Passenger	ONE22
2011-2008	Driver	ONE28
	Passenger	ONE21
<b>ML63 AMG</b>		
2015-2012	Driver	ONE26
	Passenger	ONE22
2011-2007	Driver	ONE28
	Passenger	ONE21
<b>R320</b>		
2009-2007	Driver	ONE28
	Passenger	ONE21
<b>R350</b>		
2013-2006	Driver	ONE28
	Passenger	ONE21
<b>R500</b>		
2008-2006	Driver	ONE28
	Passenger	ONE21
<b>R63 AMG</b>		
2007	Driver	ONE28
	Passenger	ONE21
<b>S320</b>		
1998-1994	Driver	ONE24
	Passenger	ONE24
<b>S350</b>		
2013-2012, 2006	Driver	ONE28
	Passenger	ONE28
1995-1994	Driver	ONE24
	Passenger	ONE24

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>MERCEDES-BENZ (cont.)</b>		
<b>S400</b>		
2013-2010	Driver	ONE28
	Passenger	ONE28
<b>S420</b>		
1998-1994	Driver	ONE24
	Passenger	ONE24
<b>S430</b>		
2006-1999	Driver	ONE28
	Passenger	ONE28
<b>S450</b>		
2011-2010	Driver	ONE28
	Passenger	ONE28
2009-2008	Driver	ONE26
	Passenger	ONE26
<b>S500</b>		
2006-2001	Driver	ONE28
	Passenger	ONE28
1998-1994	Driver	ONE24
	Passenger	ONE24
<b>S55 AMG</b>		
2006-2001	Driver	ONE28
	Passenger	ONE28
<b>S550</b>		
2013-2010, 2007	Driver	ONE28
	Passenger	ONE28
2009-2008	Driver	ONE26
	Passenger	ONE26
<b>S600</b>		
2013-2010, 2007-2001	Driver	ONE28
	Passenger	ONE28
2009-2008	Driver	ONE26
	Passenger	ONE26
1998-1994	Driver	ONE24
	Passenger	ONE24

<b>MERCEDES-BENZ (cont.)</b>		
<b>S63 AMG</b>		
2013-2010	Driver	ONE28
	Passenger	ONE28
2009-2008	Driver	ONE26
	Passenger	ONE26
<b>S65 AMG</b>		
2013-2010, 2007-2005	Driver	ONE28
	Passenger	ONE28
2009-2008	Driver	ONE26
	Passenger	ONE26
<b>SL320</b>		
1997-1994	Driver	ONE24
<b>SL500</b>		
2011-2002	Driver	ONE26
	Passenger	ONE26
2001-1994	Driver	ONE24
<b>SL55 AMG</b>		
2008-2002	Driver	ONE26
	Passenger	ONE26
<b>SL550</b>		
2011-2007	Driver	ONE26
	Passenger	ONE26
<b>SL60 AMG</b>		
1999-1997	Driver	ONE24
<b>SL600</b>		
2011-2002	Driver	ONE26
	Passenger	ONE26
2001-1994	Driver	ONE24
<b>SL63 AMG</b>		
2011-2009	Driver	ONE26
	Passenger	ONE26
<b>SL65 AMG</b>		
2011-2005	Driver	ONE26
	Passenger	ONE26





## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>MERCEDES-BENZ (cont.)</b>		
<b>SLK200</b>		
2015-2003	Driver	ONE22
	Passenger	ONE22
<b>SLK230</b>		
2004-1997	Driver	ONE22
	Passenger	ONE22
<b>SLK250</b>		
2015-2012	Driver	ONE22
	Passenger	ONE22
<b>SLK280</b>		
2008-2006	Driver	ONE22
	Passenger	ONE22
<b>SLK300</b>		
2011-2009	Driver	ONE22
	Passenger	ONE22
<b>SLK32 AMG</b>		
2004-2002	Driver	ONE22
	Passenger	ONE22
<b>SLK320</b>		
2004-2001	Driver	ONE22
	Passenger	ONE22
<b>SLK350</b>		
2015-2005	Driver	ONE22
	Passenger	ONE22
<b>SLK55 AMG</b>		
2015-2005	Driver	ONE22
	Passenger	ONE22
<b>SLR McLaren</b>		
2009-2005	Driver	ONE26
	Passenger	ONE26
<b>SLS AMG</b>		
2014-2013	Driver	ONE20
	Passenger	ONE20

<b>MERCEDES-BENZ (cont.)</b>		
<b>Sprinter</b>		
2012-2010	Driver	ONE26
	Passenger	ONE24
<b>Sprinter 2500</b>		
2014-2010	Driver	ONE26
	Passenger	ONE24
<b>Sprinter 3500</b>		
2014-2010	Driver	ONE26
	Passenger	ONE24
<b>MERCURY</b>		
<b>Bobcat</b>		
1980-1979	Driver	ONE16
<b>Capri</b>		
1986-1983	Driver	ONE16
	Passenger	ONE16
1982-1979	Driver	ONE16
	Passenger	ONE16
	Rear	ONE18
<b>Colony Park</b>		
1991-1987, 1974-1971	Driver	ONE18
	Passenger	ONE18
<b>Cougar</b>		
2002-1999	Driver	ONE22
	Passenger	ONE20
	Rear	ONE22
1997-1990	Driver	ONE22
	Passenger	ONE22
1989	Driver	ONE22
	Passenger	ONE20
1988-1983	Driver	ONE18
	Passenger	ONE18
1982-1974	Driver	ONE16
	Passenger	ONE16

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>MERCURY (cont.)</b>		
<b>Grand Marquis</b>		
2011-1993	Driver	ONE22
	Passenger	ONE22
1990-1975	Driver	ONE18
	Passenger	ONE18
<b>LN7</b>		
1983-1982	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>Lynx</b>		
1987-1981	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>Marauder</b>		
2004-2003	Driver	ONE22
	Passenger	ONE22
<b>Mariner</b>		
2011-2008	Driver	ONE20
	Passenger	ONE20
2007-2005	Driver	ONE20
	Passenger	ONE18
<b>Marquis</b>		
1986, 1983-1971	Driver	ONE18
	Passenger	ONE18
1985-1984	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>Milan</b>		
2011-2006	Driver	ONE24
	Passenger	ONE19
<b>Monarch</b>		
1980-1975	Driver	ONE16
	Passenger	ONE16

<b>MERCURY (cont.)</b>		
<b>Montego</b>		
2007-2005	Driver	ONE24
	Passenger	ONE20
1976-1970	Driver	ONE16
	Passenger	ONE16
<b>Monterey</b>		
2007-2004	Driver	ONE24
	Passenger	ONE20
	Rear	ONE16
1974-1971	Driver	ONE18
	Passenger	ONE18
<b>Mountaineer</b>		
2010-2006	Driver	ONE20
	Passenger	ONE20
2005	Driver	ONE20
	Passenger	ONE20
	Rear	ONE16
2004-2002	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
2001-1997	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14
<b>Mystique</b>		
2000-1995	Driver	ONE22
	Passenger	ONE20
<b>Sable</b>		
2009-2008	Driver	ONE24
	Passenger	ONE20
2005-1996	Driver	ONE24
	Passenger	ONE20
	Rear	ONE18
1995-1989	Driver	ONE20
	Passenger	ONE20



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>MERCURY (cont.)</b>		
<b>Sable (cont.)</b>		
1988-1986	Driver	ONE20
	Passenger	ONE20
	Rear	ONE15
<b>Topaz</b>		
1994-1986	Driver	ONE20
	Passenger	ONE20
1985	Driver	ONE19
	Passenger	ONE19
1984	Driver	ONE18
	Passenger	ONE18
<b>Tracer</b>		
1999-1991	Driver	ONE20
	Passenger	ONE18
	Rear	ONE14
<b>Villager</b>		
2002-1999	Driver	ONE22
	Passenger	ONE22
	Rear	ONE14
1998-1993	Driver	ONE22
	Passenger	ONE22
<b>Zephyr</b>		
1983-1978	Driver	ONE16
	Passenger	ONE16
<b>MINI</b>		
<b>Cooper</b>		
2015-2002	Driver	ONE18
	Passenger	ONE19
<b>Cooper Clubman</b>		
2012-2008	Driver	ONE18
	Passenger	ONE19
<b>Cooper Countryman</b>		
2015-2011	Driver	ONE19
	Passenger	ONE20

<b>MINI (cont.)</b>		
<b>Cooper Coupe</b>		
2015-2012	Driver	ONE20
	Passenger	ONE21
<b>Cooper Paceman</b>		
2015-2013	Driver	ONE19
	Passenger	ONE20
<b>Cooper Roadster</b>		
2015-2012	Driver	ONE20
	Passenger	ONE21
<b>MITSUBISHI</b>		
<b>3000GT</b>		
1999-1991	Driver	ONE21
	Passenger	ONE20
<b>Diamante</b>		
2004-1997	Driver	ONE22
	Passenger	ONE20
1996-1992	Driver	ONE20
	Passenger	ONE19
<b>Eclipse</b>		
2012-2006	Driver	ONE24
	Passenger	ONE22
	Rear	ONE17
2005-2001	Driver	ONE24
	Passenger	ONE21
	Rear	ONE22
2000	Driver	ONE24
	Passenger	ONE21
	Rear	ONE18
1999-1997	Driver	ONE24
	Passenger	ONE22
	Rear	ONE18
1996-1995	Driver	ONE24
	Passenger	ONE22
	Rear	ONE19

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>MITSUBISHI (cont.)</b>		
<b>Eclipse (cont.)</b>		
1994-1992	Driver	ONE20
	Passenger	ONE20
<b>Endeavor</b>		
2011-2010, 2008-2004	Driver	ONE26
	Passenger	ONE21
<b>Expo</b>		
1995-1992	Driver	ONE22
	Passenger	ONE18
	Rear	ONE16
<b>Expo LRV Wagon</b>		
1994-1992	Driver	ONE22
	Passenger	ONE18
	Rear	ONE16
<b>Galant</b>		
2012-2004	Driver	ONE26
	Passenger	ONE19
2003-1999	Driver	ONE24
	Passenger	ONE18
1998-1994	Driver	ONE21
	Passenger	ONE19
1993-1989	Driver	ONE19
	Passenger	ONE18
<b>Lancer</b>		
2015-2010	Driver	ONE26
	Passenger	ONE18
	Rear	ONE14
2009-2008	Driver	ONE26
	Passenger	ONE18
2007-2002	Driver	ONE24
	Passenger	ONE18
	Rear	ONE17
<b>Mirage</b>		
2015-2014	Driver	ONE24
	Passenger	ONE16

<b>MITSUBISHI (cont.)</b>		
<b>Mirage (cont.)</b>		
2002-1997	Driver	ONE21
	Passenger	ONE19
1996-1993	Driver	ONE20
	Passenger	ONE19
1992-1991	Driver	ONE20
	Passenger	ONE17
<b>Montero</b>		
2006-2001	Driver	ONE20
	Passenger	ONE20
	Rear	ONE16
2000-1992	Driver	ONE19
	Passenger	ONE19
<b>Montero Sport</b>		
2005-1997	Driver	ONE20
	Passenger	ONE20
	Rear	ONE17
<b>Outlander</b>		
2015-2014	Driver	ONE26
	Passenger	ONE18
2013-2007	Driver	ONE24
	Passenger	ONE21
2006-2003	Driver	ONE22
	Passenger	ONE19
<b>Outlander Sport</b>		
2015-2011	Driver	ONE24
	Passenger	ONE21
<b>Precis</b>		
1994-1990	Driver	ONE18
	Passenger	ONE18
1989-1987	Driver	ONE17
	Passenger	ONE17
	Rear	ONE17



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>MITSUBISHI (cont.)</b>		
<b>RVR</b>		
2013-2011	Driver	ONE24
	Passenger	ONE21
<b>Raider</b>		
2009-2006	Driver	ONE21
	Passenger	ONE21
<b>i-MiEV</b>		
2014, 2012	Driver	ONE24
	Passenger	ONE21
<b>NISSAN</b>		
<b>200SX</b>		
1998	Driver	ONE21
	Passenger	ONE18
1997-1995	Driver	ONE21
	Passenger	ONE19
1988-1984	Driver	ONE20
	Passenger	ONE20
<b>240SX</b>		
1998-1995	Driver	ONE21
	Passenger	ONE20
1994-1989	Driver	ONE20
	Passenger	ONE20
	Rear	ONE20
<b>300ZX</b>		
1996-1995	Driver	ONE21
	Passenger	ONE21
	Rear	ONE16
1994-1990	Driver	ONE21
	Passenger	ONE21
	Rear	ONE19
1989-1987	Driver	ONE19
	Passenger	ONE19
	Rear	ONE19
1986	Driver	ONE19
	Passenger	ONE19

<b>NISSAN (cont.)</b>		
<b>350Z</b>		
2009-2003	Driver	ONE20
	Passenger	ONE18
	Rear	ONE18
<b>370Z</b>		
2015-2009	Driver	ONE21
	Passenger	ONE19
<b>720</b>		
1986-1980	Driver	ONE16
	Passenger	ONE16
<b>Altima</b>		
2015-2013	Driver	ONE28
	Passenger	ONE16
2012-2007	Driver	ONE28
	Passenger	ONE17
2006-2002	Driver	ONE26
	Passenger	ONE17
2001-1993	Driver	ONE21
	Passenger	ONE20
<b>Altima Coupe</b>		
2013	Driver	ONE28
	Passenger	ONE17
<b>Altra EV</b>		
2001-1999	Driver	ONE22
	Passenger	ONE18
	Rear	ONE16
<b>Armada</b>		
2015-2005	Driver	ONE24
	Passenger	ONE22
<b>Axxess</b>		
1992-1990	Passenger	ONE22
	Rear	ONE16
<b>Cube</b>		
2014-2009	Driver	ONE20
	Passenger	ONE20

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>NISSAN (cont.)</b>		
<b>Frontier</b>		
2015-2005	Driver	ONE24
	Passenger	ONE18
2004-1998	Driver	ONE19
	Passenger	ONE19
<b>GT-R</b>		
2015-2009	Driver	ONE22
	Passenger	ONE19
<b>Juke</b>		
2015-2011	Driver	ONE22
	Passenger	ONE14
<b>Leaf</b>		
2015-2011	Driver	ONE26
	Passenger	ONE16
<b>Maxima</b>		
2015-2009	Driver	ONE28
	Passenger	ONE17
2008-2000	Driver	ONE26
	Passenger	ONE17
1999-1995	Driver	ONE22
	Passenger	ONE21
1994-1989	Driver	ONE21
	Passenger	ONE20
1988-1985	Driver	ONE19
	Passenger	ONE19
<b>Murano</b>		
2015, 2008-2006	Driver	ONE26
	Passenger	ONE18
2014-2009	Driver	ONE26
	Passenger	ONE16
2005-2003	Driver	ONE26
	Passenger	ONE19
<b>NV1500</b>		
2015-2012	Driver	ONE21
	Passenger	ONE21

<b>NISSAN (cont.)</b>		
<b>NV200</b>		
2014-2013	Driver	ONE21
	Passenger	ONE21
<b>NV2500</b>		
2015-2012	Driver	ONE21
	Passenger	ONE21
<b>NV350 Urvan</b>		
2014	Driver	ONE21
	Passenger	ONE21
<b>NV3500</b>		
2015-2012	Driver	ONE21
	Passenger	ONE21
<b>NX</b>		
1993-1991	Driver	ONE20
	Passenger	ONE19
	Rear	ONE20
<b>Pathfinder</b>		
2015-2013	Driver	ONE26
	Passenger	ONE17
2012-2005	Driver	ONE24
	Passenger	ONE18
2004-1996	Driver	ONE22
	Passenger	ONE21
1995-1987	Driver	ONE19
	Passenger	ONE19
<b>Pickup</b>		
1997-1995	Driver	ONE19
	Passenger	ONE19
<b>Platina</b>		
2008-2007	Driver	ONE21
	Passenger	ONE18
<b>Pulsar NX</b>		
1990-1987	Driver	ONE21
	Passenger	ONE21



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>NISSAN (cont.)</b>		
<b>Quest</b>		
2015-2011	Driver	ONE26
	Passenger	ONE19
2009-2004	Driver	ONE28
	Passenger	ONE18
2002-1993	Driver	ONE22
	Passenger	ONE22
<b>Rogue</b>		
2015-2014	Driver	ONE26
	Passenger	ONE17
2013-2008	Driver	ONE26
	Passenger	ONE14
<b>Sentra</b>		
2015	Driver	ONE28
	Passenger	ONE15
2014-2013	Driver	ONE28
	Passenger	ONE14
2012-2007	Driver	ONE26
	Passenger	ONE17
2006-2003	Driver	ONE22
	Passenger	ONE17
2002-2000	Driver	ONE22
	Passenger	ONE16
1999-1995	Driver	ONE21
	Passenger	ONE19
1994-1991	Driver	ONE20
	Passenger	ONE19
1990-1987	Driver	ONE19
	Passenger	ONE18
1986-1985	Driver	ONE18
	Passenger	ONE18
<b>Stanza</b>		
1992-1990	Driver	ONE20
	Passenger	ONE20

<b>NISSAN (cont.)</b>		
<b>Stanza (cont.)</b>		
1989-1987	Driver	ONE19
	Passenger	ONE19
<b>Stanza Wagon</b>		
1988-1986	Driver	ONE19
	Passenger	ONE19
<b>Titan</b>		
2015-2004	Driver	ONE24
	Passenger	ONE22
<b>Tsuru</b>		
2008-2007	Driver	ONE18
	Passenger	ONE18
<b>Van XE</b>		
1988-1987	Driver	ONE22
	Passenger	ONE19
<b>Versa</b>		
2014-2007	Driver	ONE26
	Passenger	ONE14
<b>X-Trail</b>		
2006-2005	Driver	ONE24
	Passenger	ONE15
	Rear	ONE17
<b>Xterra</b>		
2015-2005	Driver	ONE24
	Passenger	ONE18
2004-2000	Driver	ONE19
	Passenger	ONE19
<b>OLDSMOBILE</b>		
<b>88</b>		
1999-1992	Driver	ONE22
	Passenger	ONE22
<b>98</b>		
1990-1985	Driver	ONE19
	Passenger	ONE19

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>OLDSMOBILE (cont.)</b>		
<b>98 Regency</b>		
1994-1992	Driver	ONE22
	Passenger	ONE22
1984-1973	Driver	ONE18
	Passenger	ONE18
<b>Achieva</b>		
1998-1992	Driver	ONE19
	Passenger	ONE19
<b>Alero</b>		
2004-1999	Driver	ONE22
	Passenger	ONE17
<b>Aurora</b>		
2003-2001, 1999-1995	Driver	ONE22
	Passenger	ONE22
<b>Bravada</b>		
2004-2001	Driver	ONE22
	Passenger	ONE22
	Rear	ONE16
2000-1996	Driver	ONE20
	Passenger	ONE20
	Rear	ONE14
1994-1991	Driver	ONE16
	Passenger	ONE16
	Rear	ONE14
<b>Calais</b>		
1987-1985	Driver	ONE19
	Passenger	ONE19
<b>Custom Cruiser</b>		
1992-1991	Driver	ONE22
	Passenger	ONE22
	Rear	ONE17
1990-1971	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16

<b>OLDSMOBILE (cont.)</b>		
<b>Cutlass</b>		
1999-1997	Driver	ONE22
	Passenger	ONE19
1987-1985, 1981-1978	Driver	ONE18
	Passenger	ONE18
1977-1970	Driver	ONE16
	Passenger	ONE16
<b>Cutlass Calais</b>		
1991-1988	Driver	ONE19
	Passenger	ONE19
1984-1978	Driver	ONE18
	Passenger	ONE18
<b>Cutlass Ciera</b>		
1996-1984	Driver	ONE18
	Passenger	ONE18
<b>Cutlass Cruiser</b>		
1994-1987	Driver	ONE18
	Passenger	ONE18
1983-1980	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>Cutlass Supreme</b>		
1997-1988	Driver	ONE20
	Passenger	ONE20
1987-1978	Driver	ONE18
	Passenger	ONE18
1977-1968	Driver	ONE16
	Passenger	ONE16
<b>Delta 88</b>		
1991-1986	Driver	ONE19
	Passenger	ONE19
1985-1968	Driver	ONE18
	Passenger	ONE18





## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>OLDSMOBILE (cont.)</b>		
<b>F85</b>		
1972-1968	Driver	ONE16
	Passenger	ONE16
<b>Firenza</b>		
1988-1982	Driver	ONE16
	Passenger	ONE16
	Rear	ONE16
<b>Intrigue</b>		
2002-1998	Driver	ONE22
	Passenger	ONE22
<b>LSS</b>		
1999-1996	Driver	ONE22
	Passenger	ONE22
<b>Omega</b>		
1984-1980	Driver	ONE18
	Passenger	ONE18
1979-1973	Driver	ONE16
	Passenger	ONE16
<b>Regency</b>		
1998-1997	Driver	ONE22
	Passenger	ONE22
<b>Silhouette</b>		
2004-1997	Driver	ONE24
	Passenger	ONE24
	Rear	ONE16
1996-1990	Driver	ONE24
	Passenger	ONE24
	Rear	ONE14
<b>Toronado</b>		
1992-1986	Driver	ONE19
	Passenger	ONE19
1985-1971	Driver	ONE18
	Passenger	ONE18

<b>OLDSMOBILE (cont.)</b>		
<b>Toronado Trofeo</b>		
1992-1988	Driver	ONE19
	Passenger	ONE19
<b>Vista Cruiser</b>		
1975-1973	Driver	ONE18
	Passenger	ONE18
<b>PANOZ</b>		
<b>AIV Roadster</b>		
2000-1999	Driver	ONE19
	Passenger	ONE21
<b>PEUGEOT</b>		
<b>505</b>		
1991-1981	Driver	ONE18
	Passenger	ONE18
<b>604</b>		
1984-1979	Driver	ONE18
	Passenger	ONE18
<b>PLYMOUTH</b>		
<b>Acclaim</b>		
1995-1989	Driver	ONE18
	Passenger	ONE18
<b>Barracuda</b>		
1974-1970	Driver	ONE16
	Passenger	ONE16
<b>Breeze</b>		
2000-1996	Driver	ONE22
	Passenger	ONE22
<b>Caravelle</b>		
1989-1978	Driver	ONE16
	Passenger	ONE16
<b>Colt</b>		
1995	Driver	ONE20
	Passenger	ONE19
1994-1989	Driver	ONE20
	Passenger	ONE17

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>PLYMOUTH (cont.)</b>		
<b>Colt Vista</b>		
1994-1992	Rear	ONE16
<b>Colt Vista Wagon</b>		
1994-1992	Driver	ONE22
	Passenger	ONE18
<b>Fury</b>		
1978-1974	Driver	ONE18
	Passenger	ONE18
1973-1969	Driver	ONE16
	Passenger	ONE16
<b>Gran Fury</b>		
1989-1980, 1977-1974	Driver	ONE18
	Passenger	ONE18
1973-1972	Driver	ONE16
	Passenger	ONE16
<b>Grand Voyager</b>		
2000-1996	Driver	ONE28
	Passenger	ONE28
	Rear	ONE18
1995	Driver	ONE22
	Passenger	ONE22
	Rear	ONE18
1994	Driver	ONE22
	Passenger	ONE18
	Rear	ONE18
1993-1991	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
1990-1987	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>Laser</b>		
1994-1992	Driver	ONE20
	Passenger	ONE20

<b>PLYMOUTH (cont.)</b>		
<b>Neon</b>		
2001-2000	Driver	ONE22
	Passenger	ONE19
1999-1995	Driver	ONE21
	Passenger	ONE18
<b>Prowler</b>		
2001-1999, 1997	Driver	ONE17
	Passenger	ONE19
<b>Reliant</b>		
1989-1981	Driver	ONE16
	Passenger	ONE16
<b>Roadrunner</b>		
1975	Driver	ONE18
	Passenger	ONE18
1974-1971	Driver	ONE16
	Passenger	ONE16
<b>Satellite</b>		
1974-1971	Driver	ONE16
	Passenger	ONE16
<b>Sundance</b>		
1994-1987	Driver	ONE18
	Passenger	ONE18
<b>Voyager</b>		
2000-1996	Driver	ONE28
	Passenger	ONE28
	Rear	ONE18
1995	Driver	ONE22
	Passenger	ONE22
	Rear	ONE18
1994	Driver	ONE22
	Passenger	ONE18
	Rear	ONE18
1993-1991	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>PLYMOUTH (cont.)</b>		
<b>Voyager (cont.)</b>		
1990-1984	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>PONTIAC</b>		
<b>6000</b>		
1991-1984	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>Acadian</b>		
1987-1982	Driver	ONE16
	Passenger	ONE16
	Rear	ONE16
<b>Aztek</b>		
2005-2001	Driver	ONE24
	Passenger	ONE22
<b>Bonneville</b>		
2005-1992	Driver	ONE22
	Passenger	ONE22
1991-1987	Driver	ONE19
	Passenger	ONE19
1986-1971	Driver	ONE18
	Passenger	ONE18
<b>Catalina</b>		
1981-1970	Driver	ONE18
	Passenger	ONE18
<b>Executive</b>		
1970	Driver	ONE18
	Passenger	ONE18
<b>Fiero</b>		
1988-1984	Driver	ONE18
	Passenger	ONE18
<b>Firebird</b>		
2002-1998	Driver	ONE24
	Passenger	ONE24

<b>PONTIAC (cont.)</b>		
<b>Firebird (cont.)</b>		
1992-1990, 1981-1977	Driver	ONE18
	Passenger	ONE18
1989-1982	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>Firebird Trans Am</b>		
1976-1970	Driver	ONE16
<b>Firefly</b>		
2000-1995	Driver	ONE20
	Passenger	ONE19
1994, 1991- 1989	Driver	ONE20
	Passenger	ONE18
	Rear	ONE15
1988-1985	Driver	ONE16
	Passenger	ONE16
	Rear	ONE15
<b>G3</b>		
2010-2009	Driver	ONE22
	Passenger	ONE18
<b>G5</b>		
2010-2007	Driver	ONE22
	Passenger	ONE17
<b>G6</b>		
2010-2005	Driver	ONE24
	Passenger	ONE21
<b>G8</b>		
2009-2008	Driver	ONE26
	Passenger	ONE15
<b>GTO</b>		
2006-2004	Driver	ONE22
	Passenger	ONE20
1973-1968	Driver	ONE16
	Passenger	ONE16

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>PONTIAC (cont.)</b>		
<b>Grand Am</b>		
1974-1973	Driver	ONE16
	Passenger	ONE16
<b>Grand Am Coupe</b>		
2005-1999	Driver	ONE22
	Passenger	ONE17
1998-1985	Driver	ONE19
	Passenger	ONE19
1980-1978	Driver	ONE18
	Passenger	ONE18
1975	Driver	ONE16
	Passenger	ONE16
<b>Grand Am Sedan</b>		
2005-1999	Driver	ONE22
	Passenger	ONE17
1998-1986	Driver	ONE19
	Passenger	ONE19
1979-1978	Driver	ONE18
	Passenger	ONE18
1975	Driver	ONE16
	Passenger	ONE16
<b>Grand LeMans</b>		
1983-1975	Driver	ONE16
	Passenger	ONE16
<b>Grand Prix</b>		
2008-1997	Driver	ONE22
	Passenger	ONE22
1996-1988	Driver	ONE20
	Passenger	ONE20
1987-1978	Driver	ONE18
	Passenger	ONE18
1977-1968	Driver	ONE16
	Passenger	ONE16

<b>PONTIAC (cont.)</b>		
<b>Grand Safari</b>		
1978-1973	Driver	ONE16
	Passenger	ONE16
<b>Grandville</b>		
1975-1971	Driver	ONE18
	Passenger	ONE18
<b>J2000</b>		
1983-1982	Driver	ONE16
	Passenger	ONE16
	Rear	ONE16
<b>J2000 Sunbird</b>		
1985-1984	Driver	ONE16
	Passenger	ONE16
	Rear	ONE16
<b>Laurentian</b>		
1981-1976	Driver	ONE18
	Passenger	ONE18
<b>LeMans</b>		
1993-1988, 1981-1978	Driver	ONE18
	Passenger	ONE18
1977-1968	Driver	ONE16
	Passenger	ONE16
<b>Montana</b>		
2009-2006	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16
2005-1999	Driver	ONE24
	Passenger	ONE24
	Rear	ONE16
<b>Montana SV6</b>		
2005	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>PONTIAC (cont.)</b>		
<b>Optima</b>		
1991-1988	Driver	ONE18
	Passenger	ONE18
<b>Parisienne</b>		
1986-1976	Driver	ONE18
	Passenger	ONE18
<b>Phoenix</b>		
1984-1980	Driver	ONE18
	Passenger	ONE18
1979-1977	Driver	ONE16
	Passenger	ONE16
<b>Pursuit</b>		
2006-2005	Driver	ONE22
	Passenger	ONE17
<b>Safari Wagon</b>		
1989-1987	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>Solstice</b>		
2009-2006	Driver	ONE16
	Passenger	ONE22
<b>Sunbird</b>		
1994-1990	Driver	ONE17
	Passenger	ONE17
1989-1986	Driver	ONE16
	Passenger	ONE16
<b>Sunburst</b>		
1988-1985	Driver	ONE18
	Passenger	ONE18
<b>Sunfire</b>		
2005-1995	Driver	ONE22
	Passenger	ONE17
<b>Sunrunner</b>		
1997-1994	Driver	ONE17
	Passenger	ONE17

<b>PONTIAC (cont.)</b>		
<b>T1000</b>		
1982	Driver	ONE16
	Passenger	ONE16
<b>Tempest</b>		
1991-1987	Driver	ONE19
	Passenger	ONE19
1970-1968	Driver	ONE16
	Passenger	ONE16
<b>Torrent</b>		
2009-2006	Driver	ONE24
	Passenger	ONE19
	Rear	ONE15
<b>Trans Sport</b>		
1999-1997	Driver	ONE24
	Passenger	ONE24
	Rear	ONE16
1996-1990	Driver	ONE24
	Passenger	ONE24
	Rear	ONE14
<b>Ventura</b>		
1977-1971	Driver	ONE16
	Passenger	ONE16
<b>Vibe</b>		
2010-2009	Driver	ONE26
	Passenger	ONE17
2008-2003	Driver	ONE21
	Passenger	ONE18
<b>Wave</b>		
2008-2005	Driver	ONE22
	Passenger	ONE19
	Rear	ONE15
<b>Wave Sedan</b>		
2008-2007	Driver	ONE22
	Passenger	ONE18
	Rear	ONE15

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>PORSCHE</b>		
<b>911</b>		
2012-2006, 2004-1999	Driver	ONE22
	Passenger	ONE22
	Rear	ONE22
2005	Driver	ONE22
	Passenger	ONE22
1998-1995	Driver	ONE15
	Passenger	ONE18
<b>944</b>		
1991-1985	Driver	ONE19
	Passenger	ONE19
<b>968</b>		
1995-1992	Driver	ONE19
	Passenger	ONE19
	Rear	ONE20
<b>Boxster</b>		
2012-1997	Driver	ONE22
	Passenger	ONE22
<b>Carrera GT</b>		
2006-2004	Driver	ONE22
	Passenger	ONE22
<b>Cayenne</b>		
2015-2013	Driver	ONE24
	Passenger	ONE24
2012-2008, 2006-2003	Driver	ONE26
	Passenger	ONE26
<b>Cayman</b>		
2012-2006	Driver	ONE22
	Passenger	ONE22
<b>Panamera</b>		
2013-2010	Driver	ONE24
	Passenger	ONE21

<b>RAM</b>		
<b>1500</b>		
2014-2011	Driver	ONE22
	Passenger	ONE22
<b>2500</b>		
2014-2011	Driver	ONE22
	Passenger	ONE22
<b>3500</b>		
2014-2011	Driver	ONE22
	Passenger	ONE22
<b>4500</b>		
2014-2011	Driver	ONE22
	Passenger	ONE22
<b>5500</b>		
2014-2011	Driver	ONE22
	Passenger	ONE22
<b>C/V</b>		
2015-2012	Driver	ONE26
	Passenger	ONE20
<b>Dakota</b>		
2012-2010	Driver	ONE21
	Passenger	ONE21
<b>ProMaster 1500</b>		
2015-2014	Driver	ONE26
	Passenger	ONE22
<b>ProMaster 2500</b>		
2015-2014	Driver	ONE26
	Passenger	ONE22
<b>ProMaster 3500</b>		
2015-2014	Driver	ONE26
	Passenger	ONE22
<b>ProMaster City</b>		
2015	Driver	ONE26
	Passenger	ONE22



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>RAM (cont.)</b>		
<b>Ram</b>		
2015	Driver	ONE22
	Passenger	ONE22
<b>Ram Pickup</b>		
2015	Driver	ONE22
	Passenger	ONE22
<b>RENAULT</b>		
<b>Alliance</b>		
1987-1983	Driver	ONE18
	Passenger	ONE18
<b>Alliance GTA Convertible</b>		
1987	Driver	ONE18
	Passenger	ONE18
<b>Encore</b>		
1986-1984	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>R15</b>		
1976-1972	Driver	ONE16
	Passenger	ONE16
<b>R17</b>		
1979-1972	Driver	ONE16
	Passenger	ONE16
<b>R18i</b>		
1986-1981	Driver	ONE16
	Passenger	ONE16
<b>ROLLS ROYCE</b>		
<b>Corniche</b>		
2002-2000	Driver	ONE22
	Passenger	ONE22
<b>Corniche II</b>		
1992	Driver	ONE16
	Passenger	ONE14

<b>ROLLS ROYCE (cont.)</b>		
<b>Silver Seraph</b>		
2002-1999	Driver	ONE22
	Passenger	ONE22
<b>Silver Spur</b>		
1988-1981	Driver	ONE18
	Passenger	ONE18
<b>SAAB</b>		
<b>9-2X</b>		
2006-2005	Driver	ONE22
	Passenger	ONE17
<b>9-3</b>		
2007-2004	Driver	ONE22
	Passenger	ONE22
2002-1999	Driver	ONE21
	Passenger	ONE21
	Rear	ONE20
<b>9-3 Convertible</b>		
2003	Driver	ONE21
	Passenger	ONE21
<b>9-3 Sedan</b>		
2003	Driver	ONE22
	Passenger	ONE22
<b>9-5</b>		
2011-2010	Driver	ONE24
	Passenger	ONE21
2007-1999	Driver	ONE22
	Passenger	ONE22
<b>9-7x</b>		
2009-2005	Driver	ONE22
	Passenger	ONE22
<b>900</b>		
1998-1994	Driver	ONE21
	Passenger	ONE21
	Rear	ONE20

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>SAAB (cont.)</b>		
<b>900 (cont.)</b>		
1993-1979	Driver	ONE16
	Passenger	ONE16
<b>900 Convertible</b>		
1994-1991	Driver	ONE18
	Passenger	ONE18
<b>9000</b>		
1998-1986	Driver	ONE21
	Passenger	ONE21
	Rear	ONE21
<b>SATURN</b>		
<b>Astra</b>		
2009-2008	Driver	ONE21
	Passenger	ONE17
<b>Aura</b>		
2009-2007	Driver	ONE24
	Passenger	ONE21
<b>Ion</b>		
2007-2003	Driver	ONE22
	Passenger	ONE19
<b>Ion Coupe</b>		
2007-2003	Driver	ONE22
	Passenger	ONE19
<b>L100</b>		
2002-2001	Driver	ONE19
	Passenger	ONE19
<b>L200</b>		
2003-2001	Driver	ONE19
	Passenger	ONE19
<b>L300</b>		
2005-2001	Driver	ONE19
	Passenger	ONE19
<b>LS</b>		
2000	Driver	ONE19
	Passenger	ONE19

<b>SATURN (cont.)</b>		
<b>LS1</b>		
2000	Driver	ONE19
	Passenger	ONE19
<b>LS2</b>		
2000	Driver	ONE19
	Passenger	ONE19
<b>LW1</b>		
2000	Driver	ONE19
	Passenger	ONE19
<b>LW2</b>		
2000	Driver	ONE19
	Passenger	ONE19
<b>LW200</b>		
2003-2001	Driver	ONE19
	Passenger	ONE19
<b>LW300</b>		
2003-2001	Driver	ONE19
	Passenger	ONE19
<b>Outlook</b>		
2010-2007	Driver	ONE24
	Passenger	ONE21
<b>Relay</b>		
2007-2005	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16
<b>SC</b>		
1992-1991	Driver	ONE22
	Passenger	ONE21
	Rear	ONE16
<b>SL</b>		
2002-1991	Driver	ONE22
	Passenger	ONE21
	Rear	ONE16





## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>SATURN (cont.)</b>		
<b>SW1</b>		
1999-1993	Driver	ONE22
	Passenger	ONE21
	Rear	ONE16
<b>SW2</b>		
2001-1993	Driver	ONE22
	Passenger	ONE21
	Rear	ONE16
<b>Sky</b>		
2010-2007	Driver	ONE16
	Passenger	ONE22
<b>Vue</b>		
2010-2008	Driver	ONE24
	Passenger	ONE16
2007-2002	Driver	ONE24
	Passenger	ONE19
<b>SCION</b>		
<b>FR-S</b>		
2015-2013	Driver	ONE22
	Passenger	ONE20
<b>iQ</b>		
2015-2012	Driver	ONE24
	Passenger	ONE18
<b>tC</b>		
2015-2011	Driver	ONE24
	Passenger	ONE18
2010-2005	Driver	ONE26
	Passenger	ONE16
<b>xA</b>		
2006-2004	Driver	ONE24
	Passenger	ONE16
<b>xB</b>		
2015-2008	Driver	ONE22
	Passenger	ONE20

<b>SCION (cont.)</b>		
<b>xB (cont.)</b>		
2006-2004	Driver	ONE20
	Passenger	ONE20
<b>xD</b>		
2014-2008	Driver	ONE26
	Passenger	ONE14
<b>SMART</b>		
<b>Forfour</b>		
2006-2005	Driver	ONE22
	Passenger	ONE18
<b>Fortwo</b>		
2015	Driver	ONE22
	Passenger	ONE21
2006-2005	Driver	ONE21
	Passenger	ONE21
<b>STERLING</b>		
<b>825</b>		
1988-1987	Driver	ONE19
	Passenger	ONE19
<b>827</b>		
1991-1989	Driver	ONE19
	Passenger	ONE19
<b>SUBARU</b>		
<b>BRZ</b>		
2015-2013	Driver	ONE22
	Passenger	ONE20
<b>Baja</b>		
2006-2003	Driver	ONE22
	Passenger	ONE20
<b>Forester</b>		
2015-2014	Driver	ONE26
	Passenger	ONE17
2013-2009	Driver	ONE24
	Passenger	ONE18

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>SUBARU (cont.)</b>		
<b>Forester (cont.)</b>		
2008-2004	Driver	ONE22
	Passenger	ONE19
2003	Driver	ONE22
	Passenger	ONE19
	Rear	ONE15
2002-1998	Driver	ONE21
	Passenger	ONE19
	Rear	ONE15
<b>Impreza</b>		
2015-2012	Driver	ONE26
	Passenger	ONE16
2011-2008	Driver	ONE24
	Passenger	ONE16
2007-2004	Driver	ONE22
	Passenger	ONE17
2003-2002	Driver	ONE22
	Passenger	ONE17
	Rear	ONE15
2001-1993	Driver	ONE21
	Passenger	ONE18
	Rear	ONE15
<b>Impreza WRX STI</b>		
2014-2010	Driver	ONE24
	Passenger	ONE16
<b>Justy</b>		
1995-1993, 1989	Driver	ONE18
	Passenger	ONE17
1992-1990	Driver	ONE18
	Passenger	ONE17
	Rear	ONE15
1988-1987	Driver	ONE17
	Passenger	ONE17
<b>Legacy</b>		
2015	Driver	ONE26

<b>SUBARU (cont.)</b>		
<b>Legacy (cont.)</b>		
2014-2010	Driver	ONE26
	Passenger	ONE19
2009-2005	Driver	ONE24
	Passenger	ONE18
2004-2000	Driver	ONE22
	Passenger	ONE20
	Rear	ONE15
1999-1995	Driver	ONE21
	Passenger	ONE19
	Rear	ONE15
1994-1990	Driver	ONE20
	Passenger	ONE18
	Rear	ONE15
<b>Outback</b>		
2014-2010	Driver	ONE26
	Passenger	ONE19
2009-2005	Driver	ONE24
	Passenger	ONE18
2004-2000	Driver	ONE22
	Passenger	ONE20
	Rear	ONE15
<b>SVX</b>		
1997-1992	Driver	ONE22
	Passenger	ONE20
	Rear	ONE18
<b>Tribeca</b>		
2014-2008	Passenger	ONE20
<b>WRX STI</b>		
2015	Driver	ONE24
	Passenger	ONE16
<b>XV Crosstrek</b>		
2015-2013	Driver	ONE26
	Passenger	ONE16



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>SUZUKI</b>		
<b>Aerio</b>		
2007-2002	Driver	ONE22
	Passenger	ONE18
<b>Equator</b>		
2012-2009	Driver	ONE24
	Passenger	ONE18
<b>Esteem</b>		
2002-1995	Driver	ONE20
	Passenger	ONE18
<b>Forenza</b>		
2008-2004	Driver	ONE22
	Passenger	ONE19
<b>Grand Vitara</b>		
2013-2005	Driver	ONE19
	Passenger	ONE19
2004-1999	Driver	ONE19
	Passenger	ONE19
	Rear	ONE15
<b>Kizashi</b>		
2014-2010	Driver	ONE24
	Passenger	ONE20
<b>Reno</b>		
2008-2005	Driver	ONE22
	Passenger	ONE19
	Rear	ONE18
<b>SX4</b>		
2013-2007	Driver	ONE26
	Passenger	ONE14
<b>Sidekick</b>		
1998-1989	Driver	ONE17
	Passenger	ONE17
	Rear	ONE15

<b>SUZUKI (cont.)</b>		
<b>Swift</b>		
2010-2009	Driver	ONE21
	Passenger	ONE18
	Rear	ONE15
2008-2007	Driver	ONE22
	Passenger	ONE19
	Rear	ONE15
2001-1995	Driver	ONE20
	Passenger	ONE19
	Rear	ONE15
1994-1989	Driver	ONE20
	Passenger	ONE18
	Rear	ONE15
<b>Verona</b>		
2006-2004	Driver	ONE22
	Passenger	ONE20
<b>Vitara</b>		
2004-1999	Driver	ONE19
	Passenger	ONE19
	Rear	ONE15
<b>X-90</b>		
1998-1996	Driver	ONE17
	Passenger	ONE18
<b>XL-7</b>		
2009-2007	Driver	ONE24
	Passenger	ONE19
2006-2005	Driver	ONE19
	Passenger	ONE19
2004-2002	Driver	ONE19
	Passenger	ONE19
	Rear	ONE15
<b>TESLA</b>		
<b>Roadster</b>		
2011-2008	Driver	ONE26
	Passenger	ONE26

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>TESLA (cont.)</b>		
<b>S</b>		
2015-2012	Driver	ONE28
	Passenger	ONE17
<b>TOYOTA</b>		
<b>4Runner</b>		
2015-2010	Driver	ONE24
	Passenger	ONE20
2009-2003	Driver	ONE22
	Passenger	ONE20
2002-1993	Driver	ONE17
	Passenger	ONE17
<b>Avalon</b>		
2015-2013	Driver	ONE26
	Passenger	ONE18
2012-2005	Driver	ONE26
	Passenger	ONE20
2004-2000	Driver	ONE24
	Passenger	ONE17
1999-1995	Driver	ONE21
	Passenger	ONE19
<b>Camry</b>		
2015-2012	Driver	ONE26
	Passenger	ONE18
2011-2007	Driver	ONE24
	Passenger	ONE20
2006-2002	Driver	ONE24
	Passenger	ONE19
2001-1992	Driver	ONE21
	Passenger	ONE19
<b>Celica</b>		
2005-2000	Driver	ONE26
	Passenger	ONE16
	Rear	ONE20

<b>TOYOTA (cont.)</b>		
<b>Celica (cont.)</b>		
1999-1994	Driver	ONE21
	Passenger	ONE20
	Rear	ONE20
<b>Corolla</b>		
2015-2009	Driver	ONE26
	Passenger	ONE16
2008-2002	Driver	ONE24
	Passenger	ONE18
2001-1997	Driver	ONE20
	Passenger	ONE18
1996-1993	Driver	ONE20
	Passenger	ONE18
	Rear	ONE16
<b>Echo</b>		
2005-2000	Driver	ONE22
	Passenger	ONE14
<b>FJ Cruiser</b>		
2014-2007	Driver	ONE16
	Passenger	ONE14
	Front	ONE14
<b>Highlander</b>		
2015-2008	Driver	ONE26
	Passenger	ONE20
2007-2001	Driver	ONE22
	Passenger	ONE19
<b>Land Cruiser</b>		
2015-2013, 2011-2008	Driver	ONE24
	Passenger	ONE22
2007-2000	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16
1999-1998	Driver	ONE20
	Passenger	ONE20
	Rear	ONE16



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>TOYOTA (cont.)</b>		
<b>Land Cruiser (cont.)</b>		
1997-1993	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>MR2</b>		
1995-1993	Driver	ONE20
	Passenger	ONE19
<b>MR2 Spyder</b>		
2006-2000	Driver	ONE20
	Passenger	ONE19
<b>Matrix</b>		
2014-2009	Driver	ONE26
	Passenger	ONE17
2008-2003	Driver	ONE21
	Passenger	ONE18
<b>Paseo</b>		
1999-1992	Driver	ONE21
	Passenger	ONE18
<b>Pickup</b>		
1995-1993	Driver	ONE17
	Passenger	ONE17
<b>Prius</b>		
2015-2010	Driver	ONE26
	Passenger	ONE19
2009-2004	Driver	ONE26
	Passenger	ONE18
2003-2001	Driver	ONE24
	Passenger	ONE17
<b>Prius C</b>		
2015-2012	Driver	ONE28
	Passenger	ONE14
<b>Prius V</b>		
2015-2012	Driver	ONE26
	Passenger	ONE19

<b>TOYOTA (cont.)</b>		
<b>RAV4</b>		
2015-2013	Driver	ONE26
	Passenger	ONE16
2012-2006	Driver	ONE24
	Passenger	ONE17
2005-2001	Driver	ONE22
	Passenger	ONE19
2000-1996	Driver	ONE20
	Passenger	ONE18
	Rear	ONE14
<b>RAV4 EV</b>		
2014-2013	Driver	ONE24
	Passenger	ONE17
<b>Sequoia</b>		
2015-2008	Driver	ONE26
	Passenger	ONE22
2007-2001	Driver	ONE19
	Passenger	ONE19
<b>Sienna</b>		
2015-2011	Driver	ONE28
	Passenger	ONE20
2010-2006	Driver	ONE26
	Passenger	ONE19
	Rear	ONE16
2005-2004	Driver	ONE26
	Passenger	ONE19
2003-1998	Driver	ONE24
	Passenger	ONE18
	Rear	ONE17
<b>Solara</b>		
2008-2004	Driver	ONE24
	Passenger	ONE19
2003-1999	Driver	ONE22
	Passenger	ONE21

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>TOYOTA (cont.)</b>		
<b>Supra</b>		
1998-1994	Driver	ONE21
	Passenger	ONE19
	Rear	ONE18
<b>T100</b>		
1998-1993	Driver	ONE19
	Passenger	ONE19
<b>Tacoma</b>		
2015-2005	Driver	ONE22
	Passenger	ONE21
2004-1995	Driver	ONE17
	Passenger	ONE17
<b>Tercel</b>		
1999-1991	Driver	ONE18
	Passenger	ONE18
<b>Tundra</b>		
2015-2007	Driver	ONE26
	Passenger	ONE22
2006-2000	Driver	ONE19
	Passenger	ONE19
<b>Venza</b>		
2015-2009	Driver	ONE26
	Passenger	ONE22
<b>Yaris</b>		
2015-2012	Driver	ONE28
2011-2006, 2004	Driver	ONE26
	Passenger	ONE14
<b>VOLKSWAGEN</b>		
<b>Beetle</b>		
2011-1998	Driver	ONE21
	Passenger	ONE21
<b>CC</b>		
2012-2009	Driver	ONE24
	Passenger	ONE19

<b>VOLKSWAGEN (cont.)</b>		
<b>Cabrio</b>		
2002-1995	Driver	ONE21
	Passenger	ONE19
<b>Cabriolet</b>		
1993-1985	Driver	ONE16
	Passenger	ONE16
<b>Corrado</b>		
1995-1990	Driver	ONE19
	Passenger	ONE19
	Rear	ONE18
<b>Dasher</b>		
1981-1974	Driver	ONE16
	Passenger	ONE16
<b>Eos</b>		
2015-2007	Driver	ONE24
	Passenger	ONE19
<b>EuroVan</b>		
2004-1999, 1997-1995	Driver	ONE21
	Passenger	ONE21
	Rear	ONE16
1994-1992	Driver	ONE21
	Passenger	ONE21
	Rear	ONE18
<b>Fox</b>		
1993-1987	Driver	ONE18
	Passenger	ONE18
	Rear	ONE18
<b>GTI</b>		
2014-2006	Driver	ONE24
	Passenger	ONE19
<b>Golf</b>		
2014-2010, 2007	Driver	ONE24
	Passenger	ONE19
2006-1993	Driver	ONE21
	Passenger	ONE19



## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>VOLKSWAGEN (cont.)</b>		
<b>Golf (cont.)</b>		
1992-1985	Driver	ONE16
	Passenger	ONE16
	Rear	ONE16
<b>Jetta</b>		
2010-2006	Driver	ONE24
	Passenger	ONE19
2005-1993	Driver	ONE21
	Passenger	ONE19
	Rear	ONE15
1992-1980	Driver	ONE16
	Passenger	ONE16
<b>Jetta Wagon</b>		
2014-2011	Driver	ONE24
	Passenger	ONE19
<b>Passat</b>		
2010-2006	Driver	ONE24
	Passenger	ONE19
2005-2002	Driver	ONE21
	Passenger	ONE19
	Rear	ONE15
2001-1997	Driver	ONE21
	Passenger	ONE21
	Rear	ONE15
1996-1990	Driver	ONE21
	Passenger	ONE21
	Rear	ONE16
<b>Phaeton</b>		
2006-2004	Driver	ONE24
	Passenger	ONE21
<b>Quantum</b>		
1988-1982	Driver	ONE18
	Passenger	ONE18
	Rear	ONE14

<b>VOLKSWAGEN (cont.)</b>		
<b>R32</b>		
2008	Driver	ONE24
	Passenger	ONE19
<b>Rabbit</b>		
2009-2006	Driver	ONE24
	Passenger	ONE19
1984-1975	Driver	ONE16
	Passenger	ONE16
	Rear	ONE16
<b>Routan</b>		
2012-2011	Driver	ONE26
	Passenger	ONE20
	Rear	ONE16
2010-2009	Driver	ONE26
	Passenger	ONE20
<b>Scirocco</b>		
1989-1986	Driver	ONE19
	Passenger	ONE19
	Rear	ONE16
1985-1975	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>Tiguan</b>		
2015-2009	Driver	ONE24
	Passenger	ONE21
<b>Touareg</b>		
2015-2004	Driver	ONE26
	Passenger	ONE26
<b>Transporter</b>		
1994-1992	Driver	ONE21
	Passenger	ONE21
	Rear	ONE18
1991-1985	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16

# APPLICATION GUIDE

## PASSENGER CARS & LIGHT TRUCKS



Make / Model / Year

<b>VOLKSWAGEN (cont.)</b>		
<b>Transporter (cont.)</b>		
1979-1968	Driver	ONE16
	Passenger	ONE16
<b>Vanagon</b>		
1991-1980	Driver	ONE18
	Passenger	ONE18
	Rear	ONE16
<b>VOLVO</b>		
<b>240</b>		
1993-1990	Driver	ONE16
	Passenger	ONE16
	Rear	ONE17
<b>745</b>		
1985	Driver	ONE20
	Passenger	ONE20
<b>760</b>		
1990-1989	Driver	ONE21
	Passenger	ONE21
	Rear	ONE14
1988-1983	Driver	ONE19
	Passenger	ONE19
<b>780</b>		
1991-1987	Driver	ONE20
	Passenger	ONE20
<b>850</b>		
1997-1993	Driver	ONE21
	Passenger	ONE21
	Rear	ONE17
<b>940</b>		
1995-1991	Driver	ONE20
	Passenger	ONE20
	Rear	ONE14

<b>VOLVO (cont.)</b>		
<b>960</b>		
1997-1992	Driver	ONE21
	Passenger	ONE21
	Rear	ONE14
<b>C30</b>		
2013-2007	Driver	ONE26
	Passenger	ONE20
<b>C70</b>		
2013-2006	Driver	ONE26
	Passenger	ONE19
2005-1998	Driver	ONE21
	Passenger	ONE21
<b>DL</b>		
1984	Driver	ONE16
	Passenger	ONE16
<b>GLE</b>		
1984	Driver	ONE16
	Passenger	ONE16
<b>S40</b>		
2012-2004	Driver	ONE26
	Passenger	ONE20
2003-1999	Driver	ONE21
	Passenger	ONE20
<b>S60</b>		
2015-2011	Driver	ONE26
	Passenger	ONE20
2009-2001	Driver	ONE24
	Passenger	ONE22
<b>S70</b>		
2000-1998	Driver	ONE21
	Passenger	ONE21
<b>S80</b>		
2015-2007	Driver	ONE26
	Passenger	ONE20





## APPLICATION GUIDE PASSENGER CARS & LIGHT TRUCKS

Make / Model / Year

<b>VOLVO (cont.)</b>		
<b>S80 (cont.)</b>		
2006-1999	Driver	ONE24
	Passenger	ONE22
<b>S90</b>		
1998-1997	Driver	ONE21
	Passenger	ONE21
<b>V40</b>		
2004-1999	Driver	ONE21
	Passenger	ONE20
	Rear	ONE16
<b>V50</b>		
2011-2005	Driver	ONE26
	Passenger	ONE20
<b>V60</b>		
2015	Driver	ONE26
	Passenger	ONE20
<b>V70</b>		
2010-2008	Driver	ONE26
	Passenger	ONE20
2007-2005	Driver	ONE24
	Passenger	ONE22
2004-2001	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16
2000-1998	Driver	ONE21
	Passenger	ONE21
	Rear	ONE17
<b>V90</b>		
1998-1997	Driver	ONE21
	Passenger	ONE21
<b>XC60</b>		
2015-2010	Driver	ONE26
	Passenger	ONE20

<b>VOLVO (cont.)</b>		
<b>XC70</b>		
2015-2008	Driver	ONE26
	Passenger	ONE20
2007-2005	Driver	ONE24
	Passenger	ONE22
2004-2003	Driver	ONE24
	Passenger	ONE22
	Rear	ONE16
<b>XC90</b>		
2014-2003	Driver	ONE24
	Passenger	ONE22



**NOTES**


A large, empty area for taking notes, consisting of 20 horizontal lines. A light gray curved graphic element is visible on the left side of the page, partially overlapping the top of the lined area.

# ***FIRST***

## INTERCHANGE GUIDE



**IMPORTANT NOTICE:** In preparation for this catalog, every effort has been made to obtain accurate and complete information at the time of printing. Valeo Service assumes no responsibility or liability for any errors or omissions contained in this catalog. All references to the original manufacturer trade names and part numbers are for identification purposes only.





## INTERCHANGE GUIDE

<b>AC DELCO</b>	
<b>AC DELCO Beam Blade</b>	
<b>AC DELCO Part No.</b>	<b>Valeo Part No.</b>
8-916	ONE16
8-917	ONE17
8-918	ONE18
8-919	ONE19
8-920	ONE20
8-921	ONE21
8-922	ONE22
8-924	ONE24
8-926	ONE26
8-928	ONE28
<b>ANCO</b>	
<b>ANCO Contour</b>	
<b>ANCO Part No.</b>	<b>Valeo Part No.</b>
C-14-UB	ONE14
C-15-UB	ONE15
C-16-UB	ONE16
C-17-UB	ONE17
C-18-UB	ONE18
C-19-UB	ONE19
C-20-UB	ONE20
C-21-UB	ONE21
C-22-UB	ONE22
C-24-UB	ONE24
C-26-UB	ONE26
C-28-UB	ONE28
C-15-OE	ONE15
C-16-OE	ONE16
C-17-OE	ONE17
C-18-OE	ONE18
C-19-OE	ONE19
C-20-OE	ONE20

<b>ANCO Contour (cont.)</b>	
<b>ANCO Part No.</b>	<b>Valeo Part No.</b>
C-21-OE	ONE21
C-22-OE	ONE22
C-23-OE	ONE22
C-24-OE	ONE24
C-26-OE	ONE26
C-28-OE	ONE28
<b>ANCO Profile</b>	
<b>ANCO Part No.</b>	<b>Valeo Part No.</b>
A-14-UB	ONE14
A-15-UB	ONE15
A-16-UB	ONE16
A-17-UB	ONE17
A-18-UB	ONE18
A-19-UB	ONE19
A-20-UB	ONE20
A-21-UB	ONE21
A-22-UB	ONE22
A-24-UB	ONE24
A-26-UB	ONE26
A-28-UB	ONE28
A-14-M	ONE14
A-15-M	ONE15
A-16-M	ONE16
A-17-M	ONE17
A-18-M	ONE18
A-19-M	ONE19
A-20-M	ONE20
A-21-M	ONE21
A-22-M	ONE22
A-24-M	ONE24
A-26-M	ONE26
A-28-M	ONE28
A-15-OE	ONE15

<b>ANCO Profile (cont.)</b>	
<b>ANCO Part No.</b>	<b>Valeo Part No.</b>
A-17-OE	ONE17
A-18-OE	ONE18
A-19-OE	ONE19
A-20-OE	ONE20
A-21-OE	ONE21
A-22-OE	ONE22
A-24-OE	ONE24
A-26-OE	ONE26
A-28-OE	ONE28
<b>Bosch</b>	
<b>Bosch Clear Advantage</b>	
<b>Bosch Part No.</b>	<b>Valeo Part No.</b>
15-CA	ONE15
16-CA	ONE16
17-CA	ONE17
18-CA	ONE18
19-CA	ONE19
20-CA	ONE20
21-CA	ONE21
22-CA	ONE22
24-CA	ONE24
26-CA	ONE26
28-CA	ONE28
190E-CA	ONE19
200E-CA	ONE20
210E-CA	ONE21
220E-CA	ONE22
240E-CA	ONE24
260E-CA	ONE26
280E-CA	ONE28

<b>Bosch Evolution</b>	
<b>Bosch Part No.</b>	<b>Valeo Part No.</b>
4815	ONE15
4816	ONE16
4817	ONE17
4818	ONE18
4819	ONE19
4820	ONE20
4821	ONE21
4822	ONE22
4824	ONE24
4826	ONE26
4828	ONE28
4836	ONE17
4837	ONE18
4838	ONE19
4839	ONE20
4840	ONE21
4841	ONE22
4842	ONE24
4843	ONE26
4844	ONE28
<b>Bosch Icon</b>	
<b>Bosch Part No.</b>	<b>Valeo Part No.</b>
15A	ONE15
16A	ONE16
17A	ONE17
17B	ONE17
18A	ONE18
18B	ONE18
19A	ONE19
19B	ONE19
20A	ONE20
20B	ONE20
21A	ONE21

## INTERCHANGE GUIDE



Bosch Icon (cont.)	
Bosch Part No.	Valeo Part No.
21B	ONE21
22A	ONE22
22B	ONE22
24A	ONE24
26A	ONE26
28A	ONE28
28B	ONE28
150E	ONE15
170E	ONE17
180E	ONE18
190E	ONE19
200E	ONE20
210E	ONE21
220E	ONE22
240E	ONE24
260E	ONE26
280E	ONE28
Bosch Marathon	
Bosch Part No.	Valeo Part No.
4615	ONE15
4616	ONE16
4617	ONE17
4618	ONE18
4619	ONE19
4620	ONE20
4621	ONE21
4622	ONE22
4624	ONE24
4626	ONE26
4628	ONE28
4636	ONE17
4637	ONE18
4638	ONE19

Bosch Marathon (cont.)	
Bosch Part No.	Valeo Part No.
4639	ONE20
4640	ONE21
4641	ONE22
4642	ONE24
4643	ONE26
4644	ONE28
CARQUEST	
CARQUEST XtraClear	
CARQUEST Part No.	Valeo Part No.
B255-160	ONE16
B255-170	ONE17
B255-175	ONE17
B255-180	ONE18
B255-185	ONE18
B255-190	ONE19
B255-195	ONE19
B255-200	ONE20
B255-205	ONE20
B255-210	ONE21
B255-215	ONE21
B255-220	ONE22
B255-225	ONE22
B255-240	ONE24
B255-245	ONE24
B255-260	ONE26
B255-265	ONE26
B255-280	ONE28
B255-285	ONE28



## INTERCHANGE GUIDE

<b>ClearPlus</b>	
<b>ClearPlus Hybrid</b>	
<b>ClearPlus Part No.</b>	<b>Valeo Part No.</b>
40161	ONE16
40171	ONE17
40181	ONE18
40191	ONE19
40201	ONE20
40211	ONE21
40221	ONE22
40241	ONE24
40261	ONE26
40281	ONE28
<b>ClearPlus Signature</b>	
<b>ClearPlus Part No.</b>	<b>Valeo Part No.</b>
17161	ONE16
17171	ONE17
17181	ONE18
17191	ONE19
17201	ONE20
17211	ONE21
17221	ONE22
17241	ONE24
17261	ONE26
17281	ONE28
<b>ClearPlus Signature Gold</b>	
<b>ClearPlus Part No.</b>	<b>Valeo Part No.</b>
91141	ONE14
91161	ONE16
91911	ONE17
91181	ONE18
91191	ONE19
91201	ONE20

<b>ClearPlus Signature Gold (cont.)</b>	
<b>ClearPlus Part No.</b>	<b>Valeo Part No.</b>
91211	ONE21
91221	ONE22
91241	ONE24
91261	ONE26
91281	ONE28
<b>DENSO</b>	
<b>DENSO First Time Fit</b>	
<b>DENSO Part No.</b>	<b>Valeo Part No.</b>
161-0115	ONE15
161-0118	ONE18
161-0119	ONE19
161-0120	ONE20
161-0121	ONE21
161-0122	ONE22
161-0123	ONE22
161-0124	ONE24
161-0126	ONE26
161-0128	ONE28
161-0221	ONE21
161-0222	ONE22
161-0224	ONE24
161-0229	ONE28
161-0517	ONE17
161-0519	ONE19
161-0520	ONE20
161-0521	ONE21
161-0524	ONE24
161-0526	ONE26
161-0719	ONE19
161-0720	ONE20
161-0721	ONE21
161-0724	ONE24



## DENSO First Time Fit (cont.)

DENSO Part No.	Valeo Part No.
161-0726	ONE26
161-0818	ONE18
161-0819	ONE19
161-0824	ONE24
161-1021	ONE21
161-1022	ONE22
161-1024	ONE24
161-1029	ONE28
161-1316	ONE16
161-1317	ONE17
161-1318	ONE18
161-1319	ONE19
161-1320	ONE20
161-1321	ONE21
161-1322	ONE22
161-1324	ONE24
161-1326	ONE26
161-1328	ONE28

## DURALAST

### Duralast Flex

Duralast Part No.	Valeo Part No.
DLF14	ONE14
DLF15	ONE15
DLF16	ONE16
DLF17	ONE17
DLF18	ONE18
DLF19	ONE19
DLF20	ONE20
DLF21	ONE21
DLF22	ONE22
DLF24	ONE24
DLF26	ONE26

## Duralast Flex (cont.)

Duralast Part No.	Valeo Part No.
DLF28	ONE28
SPC-F	ONE20
SPC-H	ONE22
SPC-J	ONE24
SPC-K	ONE26
SPC-L	ONE28

## Goodyear

### Goodyear Hybrid

Goodyear Part No.	Valeo Part No.
770-16	ONE16
770-17	ONE17
770-18	ONE18
770-19	ONE19
770-20	ONE20
770-21	ONE21
770-22	ONE22
770-24	ONE24
770-26	ONE26
770-28	ONE28

## Michelin

### Michelin Stealth

Michelin Part No.	Valeo Part No.
5016	ONE16
5017	ONE17
5018	ONE18
5019	ONE19
5020	ONE20
5021	ONE21
5022	ONE22
5024	ONE24





## INTERCHANGE GUIDE

### Michelin Stealth (cont.)

Michelin Part No.	Valeo Part No.
5026	ONE26
5028	ONE28

### Michelin Stealth Ultra

Michelin Part No.	Valeo Part No.
8516	ONE16
8517	ONE17
8518	ONE18
8519	ONE19
8520	ONE20
8521	ONE21
8522	ONE22
8524	ONE24
8526	ONE26
8528	ONE28

## NAPA

### NAPA Accufit

NAPA Part No.	Valeo Part No.
60-015-PP	ONE15
60-017-PP	ONE17
60-017-SP	ONE17
60-019-PP	ONE19
60-019-SP	ONE19
60-020-PP	ONE20
60-020-SP	ONE20
60-021-PP	ONE21
60-021-SP	ONE21
60-022-PP	ONE22
60-024-PP	ONE24
60-024-SP	ONE24
60-026-PP	ONE26
60-026-SP	ONE26

### NAPA Accufit (cont.)

NAPA Part No.	Valeo Part No.
60-028-PP	ONE28
60-028-SP	ONE28

### NAPA Vista

NAPA Part No.	Valeo Part No.
60-1443	ONE14
60-1643	ONE16
60-1743	ONE17
60-1843	ONE18
60-1943	ONE19
60-1943-12	ONE19
60-1943-15	ONE19
60-2043	ONE20
60-2043-1	ONE20
60-2043-12	ONE20
60-2143	ONE21
60-2143-1	ONE21
60-2143-12	ONE21
60-2243	ONE22
60-2243-1	ONE22
60-2443	ONE24
60-2443-1	ONE24
60-2443-12	ONE24
60-2643	ONE26
60-2643-12	ONE26
60-2643-13	ONE26
60-2843	ONE28
60-2843-1	ONE28
60-2843-12	ONE28
60-1443-19	ONE14
60-1743-19	ONE17
60-1843-19	ONE18
60-1943-19	ONE19
60-2043-19	ONE20



<b>NAPA Vista (cont.)</b>	
<b>NAPA Part No.</b>	<b>Valeo Part No.</b>
60-2143-19	ONE21
60-2243-19	ONE22
60-2443-19	ONE24
60-2643-19	ONE26
<b>PIAA</b>	
<b>PIAA SI-Tech</b>	
<b>PIAA Part No.</b>	<b>Valeo Part No.</b>
97040	ONE16
97043	ONE17
97045	ONE18
97048	ONE19
97050	ONE20
97053	ONE21
97055	ONE22
97060	ONE24
97065	ONE26
<b>Pylon</b>	
<b>Pylon Hybrid</b>	
<b>Pylon Part No.</b>	<b>Valeo Part No.</b>
5016	ONE16
5017	ONE17
5018	ONE18
5019	ONE19
5020	ONE20
5021	ONE21
5022	ONE22
5024	ONE24
5026	ONE26
5028	ONE28
8516	ONE16

<b>Pylon Hybrid (cont.)</b>	
<b>Pylon Part No.</b>	<b>Valeo Part No.</b>
8517	ONE17
8518	ONE18
8519	ONE19
8520	ONE20
8521	ONE21
8522	ONE22
8524	ONE24
8526	ONE26
8528	ONE28
<b>Rain-X</b>	
<b>Rain-X Latitude</b>	
<b>Rain-X Part No.</b>	<b>Valeo Part No.</b>
5079274-1	ONE16
5079283-1	ONE17
5079275-1	ONE18
5079276-1	ONE19
5079277-1	ONE20
5079278-1	ONE21
5079279-1	ONE22
5079280-1	ONE24
5079281-1	ONE26
5079282-1	ONE28
<b>Trico</b>	
<b>Trico ExactFit</b>	
<b>Trico Part No.</b>	<b>Valeo Part No.</b>
19-1B	ONE19
22-1B	ONE22
24-1B	ONE24
26-1B	ONE26
15-15B	ONE15



## INTERCHANGE GUIDE

Trico ExactFit (cont.)	
Trico Part No.	Valeo Part No.
17-12B	ONE17
17-15B	ONE17
19-12B	ONE19
19-15B	ONE19
20-12B	ONE20
20-15B	ONE20
21-12B	ONE21
21-15B	ONE21
22-15B	ONE22
24-12B	ONE24
24-15B	ONE24
26-12B	ONE26
26-15B	ONE26
28-12B	ONE28
28-15B	ONE28
29-15B	ONE28
Trico Flex	
Trico Part No.	Valeo Part No.
18-150	ONE15
18-160	ONE16
18-170	ONE17
18-180	ONE18
18-190	ONE19
18-200	ONE20
18-210	ONE21
18-220	ONE22
18-240	ONE24
18-260	ONE26
18-280	ONE28
18-290	ONE28

Trico Force	
Trico Part No.	Valeo Part No.
25-140	ONE14
25-150	ONE15
25-160	ONE16
25-170	ONE17
25-180	ONE18
25-190	ONE19
25-200	ONE20
25-210	ONE21
25-220	ONE22
25-240	ONE24
25-251	ONE24
25-260	ONE26
25-280	ONE28
25-281	ONE28
25-290	ONE28
25-291	ONE28
Trico Ice	
Trico Part No.	Valeo Part No.
35-160	ONE16
65-170	ONE17
35-180	ONE18
35-190	ONE19
35-200	ONE20
35-210	ONE21
35-220	ONE22
35-240	ONE24
35-260	ONE26
35-280	ONE28



## INTERCHANGE GUIDE

Trico Instinct	
Trico Part No.	Valeo Part No.
28-140	ONE14
28-150	ONE15
28-160	ONE16
28-170	ONE17
28-180	ONE18
28-190	ONE19
28-200	ONE20
28-210	ONE21
28-220	ONE22
28-240	ONE24
28-260	ONE26
28-280	ONE28
Trico NeoForm	
Trico Part No.	Valeo Part No.
16-140	ONE14
16-160	ONE16
16-170	ONE17
16-180	ONE18
16-190	ONE19
16-200	ONE20
16-210	ONE21
16-220	ONE22
16-240	ONE24
16-260	ONE26
16-280	ONE28
16-1515	ONE15
16-1715	ONE17
16-1912	ONE19
16-1915	ONE19
16-2012	ONE20
16-2013	ONE20
16-2015	ONE20
16-2112	ONE21

Trico NeoForm (cont.)	
Trico Part No.	Valeo Part No.
16-2213	ONE21
16-2115	ONE21
16-2213	ONE22
16-2412	ONE24
16-2413	ONE24
16-2415	ONE24
16-2515	ONE24
16-2612	ONE26
16-2613	ONE26
16-2812	ONE28
16-2813	ONE28
16-2815	ONE28
Trico Onyx	
Trico Part No.	Valeo Part No.
26-140	ONE14
26-150	ONE15
26-160	ONE16
26-170	ONE17
26-180	ONE18
26-190	ONE19
26-200	ONE20
26-210	ONE21
26-220	ONE22
26-240	ONE24
26-251	ONE24
26-260	ONE26
26-280	ONE28
26-281	ONE28
26-290	ONE28
26-291	ONE28



## INTERCHANGE GUIDE

Trico Sentry	
Trico Part No.	Valeo Part No.
32-140	ONE14
32-150	ONE15
32-160	ONE16
32-170	ONE17
32-180	ONE18
32-190	ONE19
32-200	ONE20
32-210	ONE21
32-220	ONE22
32-240	ONE24
32-260	ONE26
32-280	ONE28
Trico Tech	
Trico Part No.	Valeo Part No.
19-150	ONE15
19-160	ONE16
19-170	ONE17
19-180	ONE18
19-190	ONE19
19-200	ONE20
19-210	ONE21
19-220	ONE22
19-240	ONE24
19-260	ONE26
19-280	ONE28
19-290	ONE28




# ***FIRST***

## INSTALLATION INSTRUCTIONS



**IMPORTANT NOTICE:** In preparation for this catalog, every effort has been made to obtain accurate and complete information at the time of printing. Valeo Service assumes no responsibility or liability for any errors or omissions contained in this catalog. All references to the original manufacturer trade names and part numbers are for identification purposes only.




# INSTALLATION INSTRUCTIONS

## Installation with a Hook Connection




## Installation with a Side Pin Connection






### Installation with other Beam Blade Connections


**FLAT BLADE CONNECTIONS**  
**LIMPIAPARABRISAS MULTICONEXIONES**  
**CONNECTIONS BALAIS PLATS**



**A**




**B**




**C**


- ▶ Remove the pre-mounted hook adaptor. Install the module "MA" on the base.
- ▶ Limpiarparabrisas multiconexiones. Remueva el adaptador pre-ensamblado de gancho. Coloque el modulo "MA" sobre la base.
- ▶ Connexions essuie-glaces plats. Démontez le connecteur crochet pré-monté. Montez le module "MA" sur la base.




**1**



**2**



**3**



**4**

### Installation with a Top Lock Pinch Tab

**TOP LOCK PINCH TAB**  
**CANDADO LATERAL DEL BRAZO ORIGINAL**  
**BRAS PATTE DE SERRAGE**

**A**



**5**



**6**



**7**

**CLICK!**







**NOTES**

A large section of the page is dedicated to notes, featuring a series of horizontal lines. A light gray, curved brushstroke graphic is located at the top left, partially overlapping the first few lines. The lines are evenly spaced and extend across most of the page width.



**NOTES**



A series of horizontal lines for taking notes, starting from the top left and extending across the page. A grey curved graphic element is located on the left side of the page, overlapping the top of the first line.














Valeo is a world leading automotive supplier.

Valeo is an automotive supplier, partner to all automakers worldwide. As a technology company, Valeo proposes innovative products and systems that contribute to the reduction of CO2 emissions and to the development of intuitive driving.

Valeo Service USA is dedicated to offering these innovative products with the highest level of superior service to US and Canadian automotive aftermarkets. Our success is built upon the quality of our products, the excellence of our customers, and the skills & integrity of our people.





# Valeo

## The Wiper Systems Expert

As a worldwide leader in original equipment wiper systems, Valeo delivers expertise to the automotive aftermarket with a comprehensive wiper solution.

Our wide range of wiper blades and wiper motors offer proven quality, reliability and performance to meet the rigorous demands of the road, and most importantly, our customers.

PART NO: FIRSTCAT2016

[valeserviceusa.com](http://valeserviceusa.com)

Customer Support: 888.71.VALEO (82536)

Valeo Service USA  
301 West Park Lane, Ste 301  
Hampton, VA 23666

Automotive technology, naturally

